




Owner's Manual



Model: DPT40-B Puller / Tensioner

Serial Number 1- -) &\$%01





TSE International Inc. Warranty Policy

- Contact the TSE International Inc. service department to discuss problem and obtain a warranty claim number. Claim numbers will remain valid for 30 days allowing for sufficient time for submission to TSE. Warranties claimed without a valid claim number may be denied.
- 2. Please retain any defective parts for a period of 60 days. TSE reserves the right to inspect and/or evaluate any parts submitted for warranty consideration. Should TSE elect to inspect the parts, a RGA (Return Goods Authorization) number will be issued and the parts are to be returned prepaid to TSE. Items not returned within 30 days will result in the RGA closure and may result in a denial of the claim.
- 3. Warranty submission must be on the standard TSE International Inc. claim form. Claims that are not will be classified as pending until proper forms are submitted. All claims must have an estimated cost associated with each item under discrepancy.
- 4. Major subcomponents are warranted under separate manufacturer warranties. It is the responsibility of the owner/dealer of the equipment to fill out and register all subcomponent manufactures warranties. In the event of failure, arrangements can be made to deal with the subcomponent supplier directly. Examples for subcomponent manufactures are: Engines– John Deere, Cummins, Caterpillar, etc.

Claims submitted as per above TSE International Inc. Equipment Warranty policy will be resolved within 30 days of receipt





Recommendations for improving this publication are encouraged and should be forwarded to:

TSE INTERNATIONAL 5301 Shreveport-Blanchard Hwy. Shreveport, Louisiana 71107

This is not a tension stringing operation procedures manual. No attempt is made or implied herein to instruct the user in methods peculiar to the individual application of the equipment described in this manual. The contents of this manual are intended as a basis of for operation, maintenance, and parts listing of the unit in its intended and anticipated use, as it stands alone in conjunction with other equipment.

The Equipment described in this manual is potentially dangerous if improperly or carelessly operated. For the protection of personnel and equipment, only competently trained operators who are critically aware of the proper procedures, operating parameters, and limitations, potential dangers, and application of this equipment should be allowed to touch the controls at any time.





PREMIUM CUSTOMER SERVICES

TSE supports its innovative products with Premium Customer Service. Our comprehensive Service Department provides TSE customers with the service, parts, and technical assistance they need to maintain their equipment in top operating condition.

For Customer Service on Your

Model DPT40-B

Serial No. <u>19-5201-01</u>

PLEASE CALL 1-800-825-2402

Our People Care: Our Equipment is the Proof.





HOW TO ORDER REPLACEMENT PARTS

In order that we may promptly send the exact replacement part required in the least amount of down time for you, the information listed below is necessary.

To order the replacement part, locate the part from the drawings in this manual and give the following information:

- 1. Unit Model No. (From the plates on the unit's frame)
- 2. Unit Serial No. (From the plate on the unit's frame, will contain numbers only)
- 3. Part Number (If available)
- 4. Description (If part no. not available)
- 5. Quantity Required

On large components such as transmissions, engines, multiple pump drives, etc., the manufacturer's serial number and spec. number is necessary to ensure receiving the proper replacement part.





WARNING

The equipment described in this manual is neither designed nor intended for any application, alone or with in conjunction with any other equipment, that involves the lifting or moving of persons.

Safe operation of this equipment is dependent on use in compliance with the procedures outline in this section and the maintenance and inspection procedures in SECTION III with consideration of prevailing conditions.

The equipment described in this manual is potentially dangerous if improperly and carelessly operated. For the protection of personnel and equipment, only competently trained operators who are critically aware of the proper procedures, operating parameters and limitations, potential dangers, and application of this equipment should be allowed to touch the controls at any time.

There is potential DANGER of ELECTRICAL SHOCK when operating this machine. Ground the unit in accordance with the regulations of the using organization. Various methods of bonding, isolation and grounding can be used; a means suitable to the user should be selected and rigidly adhered to by ALL operating personnel.

Keep all shields and guards in place. Keep hands, feet and clothing away from power driven parts and moving parts. Observe all warning decals placed on the machine.

Make certain all personnel are clear of this equipment before starting engine or operation.

Before leaving the operators position, make sure that directional controls are in the neutral position and all brakes are set.





EQUIPMENT WARRANTY

TSE International Inc. (hereinafter sometimes referred to as "TSE") warrants that it will repair f.o.b. its factory, or furnish without charge f.o.b. its factory, a similar part to replace any material in its machinery which, during the earlier of 90 days after the said machinery is put into operation or six months after the date of shipment of the machinery from the plant, is proved to the satisfaction of the company to have been defective at the time it was sold, provided that all parts claimed defective shall be returned, properly identified, to TSE's factory, charges prepaid.

This Warranty to repair applies only to new and unused machinery, which, after shipment from the factory of TSE, has not been altered, changed, repaired or treated in any manner whatsoever unless such alteration, change, repair or treatment has been previously authorized in writing by TSE or has been performed by the authorized service representative of TSE.

This Warranty to repair is the only Warranty either express, implied or statutory, upon which the said machinery is sold; the companies liability in connection with this transaction is expressly limited to the repair or replacement of defective parts, all other damages and warranties, statutory or otherwise, being hereby expressly waived by the purchaser.

No representative of TSE has authority to change this Warranty or this contract in any manner whatsoever and no attempt to repair or promise to repair or improve the machinery covered by this contract by any representative of TSE shall waive any consideration of the contract or change or extend this Warranty in any manner whatsoever.





GROUNDING EQUIPMENT AND METHODS

Grounding Equipment and Methods information is covered in the following publication:

"IEEE GUIDE TO INSTALLATION OF OVERHEAD TRANSMISSION LINE CONDUCTORS IEEE STD 524-2003"

The above publication is available through the following organization:

THE INSTITUTE OF ELECTRICAL AND ELECTRONICS ENGINEERS, INC. 3 PARK AVENUE NEW YORK, NY 10016-5997 USA





DECALS

Your equipment was shipped from the factory with the decals on the following sheet.

Should any of these decals be missing, they could prevent the proper operation and/or maintenance of the unit which may result in personal injury or property damage.

If any of these decals are missing, please contact us for a replacement.

Order the decal(s) by stating the decal description, number, and quantity.

TSE INTERNATIONAL 5301 SHREVEPORT-BLANCHARD HWY. SHREVEPORT, LA 71107

ATTENTION: SERVICE MANAGER

TELEPHONE:800-825-2402FAX:318-929-4853

RE∨	DATE CHANGE NUMBER		iE R	AMENDMENTS	BY	APPD		
В	29JAN13	29JAN13 LIST UI		IST UPDATED; ITEMS #33 & 34 ADDED	UPDATED; ITEMS #33 & 34 ADDED			
				TSE LOGOS REQUIRED			_	
25	D0002	14	1	DECAL- THIS MACHINE IS NEGATIVE GROUND		R	EF	
24	D5917	12	4	LUBRICATE WEEKLY		R	EF	
23	D5900	53	3	DANGER KEEP HANDS AWAY		RE	EF	
22	D5925	83	1	REMOVING REELSHAFT		R	EF	
21	D5916	89	1	REELSHAFT WARNING		R	EF	
20	D59144	40A	1	WARNING: REEL SHAFT BUSHING		RE	EF	
19	D5900	90	1	ENGINE THROTTLE		RE	EF	
18	D5927	27	3	DANGER		RE	EF	
17	D5920	64	1	WARNING-UNCOUPLING THE BREAKAWAY		RE	EF	
16	D0000	27	2	DECAL- LIFTING LUG		R	EF	
15	D0007	22	1	DECAL- AW-46 PREMIUM HYD FLUID		R	EF	
14	D0003	24	1	DECAL- CAUTION: REEL LIFT ARM MUST BE		RE	EF	
13	D5917	48	1	MAINTENANCE SCHEDULE		R	EF	
12	D0002	13	1	DECAL- WARNING: BEFORE USING THIS		RE	EF	
11	D5900	30	1	CAUTION		RE	EF	
10	D0005	06	1	DECAL- CAUTION: DO NOT OPERATE		R	EF	
9	D0001	56	1	DECAL- DIESEL FUEL ONLY		RE	EF	
8	D0004	00	1	DECAL- DO NOT ENGAGEENGINE RNG		RE	EF	
7	D5914	37	4	ANCHORING LUG		RE	EF	
6	D0000	28	2	DECAL– GROUNDING BAR		RE	EF	
5	D5924	-38	1	HIGH SPEED POLEMASTER DRIVE		RE	EF	
4	D5911	96	1	FREE WHEELING DISCONNECT INSIDE		R	EF	
3	D59143	38G	1	DECAL- OPERATIONS - DPT40-B		RE	EF	
2	D0000	25	1	DECAL- 12 VOLT		R	EF	
1	D000C)21	1	DECAL- MADE IN USA		R		
ITEM	PART NU		DPER DESC	DESCRIPTION	MATERIAL	Q		
This prin be repro or for th	t is the property of TS duced, copied or other he making of apparatus	E International wise disposed s or parts the	I Incorporate of directly reof except	ed. It is loaned with the express agreement that the drawing and the information contained therein are the propert or indirectly, and will not be used in whole or in part to assist in making or to furnish any information for makin upon written permission of TSE International Incorporated. The acceptance of the print will be construed as an acc	y of TSE International Incorpor g drawings, prints or other re septance of the foregoing agre	rated and v productions eement.	<i>i</i> ill not thereof,	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE INCHES DIMENSIONS IN [] ARE MM -TOLERANCES-							_	
	NGULAR ECIMAL (DNE)	.X	±	1/2* MATL N/R TITLE DECAL PACKAGE, DPT40	-В			
		.XX EXXX. CE		.01 TEST N/R ASSEMBLY FRD		4A		
1.			±	1/32 VELD TEST N/R FIRST USED SHEE	T OF		2	
	2. SAWING, FLA CUTTING, SH & BREAKING 8. WELDING			1/16 EST LBS N/A DRAWN SB CHECKED APPRIVED 1/8 ACT LBS N/A DATE 29JAN13 SCALE 1/1	5600297	RE	B	

REV	DATE	CHANG NUMBE	iE R			AMENDMENT	S		BY	APPD
										_
										_
34	D6004	67	1	DECA	L, USE HYDRAULIC F	LUID ONLY		OPTIONAL	R	EF
33	D5936	89	2	DECA	L, TORQUE NUTS TO	200 FT/LBS			R	EF
32	D0005		1		L- POLEMASTER LEV				R	EF
31	D5917	55	1	DECA	L- BRAKE CONTROL			OPTIONAL	R	EF
30	D0006	70	1	DECA	L– FRONT JACK			OPTIONAL	R	EF
29	D0001	16	1		L- CAUTION MOVING		KEEP	OPTIONAL	R	EF
28	D5958	35	1	DECA	L- QUALIFIED OPERA	ATORS ONLY			R	EF
27	D6002		1		ORING DIAGRAM, DPT					EF
26	D0004	31	1	DECA	L- PULLING CHART	DPT-40-B				EF
ITEM	PART NUM		DPER DESC			DESCRIPTION		MATERIAL	Q	NIT TY
This print be reprod or for the	is the property of TSI luced, copied or otherw e making of apparatus	E International vise disposed or parts the	l Incorporate of directly reof except	ed. It is loa or indirectly upon writte	ed with the express agreement that the and will not be used in whole or in pa permission of TSE International Incorpo	e drawing and the informa art to assist in making or vrated. The acceptance of	tion contained therein are the to furnish any information fo the print will be construed as	property of TSE International Incorpor r making drawings, prints or other rej an acceptance of the foregoing agree	ated and productions ement.	will not thereof,
UNLE	ESS OTHER	WISE S	SPECIE	FIED						
)IMENSIONS MENSIONS I							ATIONAL		
	-TOLER		-			Shrevepor	t, Louisiana, U	nited States of A	meric	a
	IGULAR CIMAL (ONE)	.x	±	1/2* .06	CERT N/R	ITLE DECAL I	PACKAGE, DP	Г40-В		
		XX. XXX. C		.02 .01	MATL N/D N	EXT SSEMBLY		DERIVED FR⊡m 560243	4A	
1.			±	1/32	WELD N/R FI	IRST USED N WD		SHEET DF		2
2.	SAWING, FLA CUTTING, SHE		±	1/16	EST DI	RAWN CHECK	ED APPROVED	P	RI	EV
3.	& BREAKING WELDING		±	1/8		ATE 29JAN13	SCALE 1/1	5600297		В
L							· · ·	1		

CONTENTS DPT40-B

SECTION I		INTRODUCTION
SECTION II		OPERATIONS
SECTION III		MAINTENANCE
SECTION IV		PARTS LIST
	F602474-B 8602060-D 7601126-C 713440-G 860759-D 8602068-D 7601116-C 7601128 8600484-A 760188-N 7600250-E 8602493 860106-O 563016-C 860952-G 880256-G	GENERAL ASSEMBLY – DPT-40B ENGINE AND PUMP ASSEMBLY DRIVE ASSEMBLY REEL SHAFT ASSEMBLY HYDRAULIC SCHEMATIC LIGHTING DIAGRAM CONTROL PANEL ASSEMBLY OVERHEAD LEVELWIND ASSEMBLY LEVELWIND ASSEMBLY LEVELWIND PLUMBING LEVELWIND, OVER/UNDER – DPT40-B OVERHEAD/UNDERGROUND BOOM-OPTIONAL HIGH SPEED POLEMASTER–OPTIONAL POLEMASTER LEVELWIND ASSEMBLY–OPTIONAL
SECTION V		VENDOR INFORMATION

ENGINE PUMP MOTOR BRAKE GEARBOX AXLE

SECTION I INTRODUCTION

GENERAL DESCRIPTION

The TSE Model DPT40-B is a trailer mounted single drum puller/tensioner powered by a three cylinder diesel engine and hydrostatic transmission. It incorporates the Timberland Quick-Change Reel Shaft System. The speed, torque, and direction of the transmission are regulated from the elevated, centrally located control panel to allow an infinitely variable control of line tension and speed within the specified performance parameters of the unit in both the pulling and tensioning mode of operation. Efficient cable wrapping is promoted by the hydraulically-powered, post-type levelwind.

WARNING/CAUTION: WHEN THIS SIGN APPEARS ON THESE PAGES, IT INDICATES WHERE SPECIAL ATTENTION SHOULD BE PAID TO THE INSTRUCTIONS GIVEN. PERSONAL INJURY OR DAMAGE TO THE EQUIPMENT MAY OCCUR IF THE INSTRUCTIONS ARE NOT FOLLOWED.

DIMENSIONS

Length	199 inches
Width	89 inches
Height	73 inches

PERFORMANCE

Continuous Torque: Intermittent Torque: Speed Range: 70,000 in-lbs 80,000 in-lbs 0-4 mph



WARNING: THESE VALUES ARE A MAXIMUM AND MUST NOT BE EXCEEDED.

REEL SPECIFICATIONS

Maximum Reel Diameter: Maximum Width: Maximum Weight: Reel Shaft Diameter: 72 inch 54 inch 6,000 lbs 2-5/8 inch



WARNING: THESE VALUES ARE A MAXIMUM AND MUST NOT BE EXCEEDED.

UNDERCARRIAGE

Axle Tires Brakes Leveling Jacks Tandem 12,000 lb capacity ST235/80R16 Electric Manual Screw Type

SECTION II OPERATION

CONTROLS

The controls in Figure 1 are described below.



BEFORE OPERATING THIS EQUIPMENT FAMILIARIZE YOURSELF WITH ALL CONTROLS AND THEIR FUNCTION. ONLY FULLY TRAINED PERSONNEL SHOULD OPERATE THIS EQUIPMENT.




Figure 1: Control Panel

- 1. **Hydraulic Pressure Gauge** This gauge shows the hydraulic pressure in the system. Do not continuously exceed 3000 psi during the operation of the machine.
- 2. Linepull Control The pressure in the hydraulic system is regulated with this control knob also shown in Figure 2. Clockwise rotation of the Linepull Control increases pressure and therefore increases the Linepull. Counter clockwise rotation of the Linepull Control decreases pressure and therefore decreases the Linepull. Once the system pressure is set with the Linepull Control, the maximum Linepull will not exceed this setting. The Linepull can be set at any level from zero to the maximum Linepull rating.

Figure 2: Linepull Control Knob



3. Brake Control - The brake is spring applied and released by hydraulic pressure also shown in Figure 3. To hold the reel stationary, turn the Reel Brake Lever to the APPLY position. Turn to the RELEASE position before driving the reel.

CAUTION: THE BRAKE IS DESIGNED TO HOLD THE CONDUCTOR UNDER STATIC CONDITIONS ONLY.

WARNING: THE HOLDING POWER OF THE BRAKES AND PROPER FUNCTIONING OF ALL MACHINE CONTROLS MUST BE VERIFIED BEFORE THE UNIT IS PUT INTO SERVICE TO ENSURE SAFE OPERATION. THIS IS PARTICULARLY IMPORTANT WHEN STRINGING IN THE VICINITY OF ENERGIZED LINES.



Figure 3: Brake Control

4. Direction Control - The reel turning speed (Linespeed) and direction is controlled by a single lever that regulates the degree of pump stroke in both directions from the NEUTRAL Position, also shown in Figure 4. Movement of the Direction Control Lever in either direction, away from the operator for 'Pay Out' and toward the operator for 'Pull In', increases the rotating speed of the reel. The reel will remain stationary with the Direction Control Lever in the NEUTRAL position.

Figure 4 – Direction Control



- 5. **Direction Lever Stop** A Stop positioned in front of the Direction Control Lever will not allow the Lever to be put in the 'Pay Out' direction without the operator lifting the Stop handle to allow the Direction Control Lever to pass. The Stop automatically falls back into place when the lever is returned to the NEUTRAL position or to the 'Pull In' direction.
- Levelwind Direction Control Lateral movement of the Levelwind post is accomplished by moving the Levelwind Direction Control lever sideways in the direction you wish the Levelwind post to move.
- 7. Levelwind Speed Control Sideways speed of the Levelwind post can be regulated with the Levelwind Speed Control knob.
- 8. **Charge Pressure Gauge** This gauge indicates the system charge pressure and should be approximately 300 psi.

TOWING

Before towing always check the following:

- 1. Front and rear jacks are fully retracted
- 2. Operator protective screen is folded down
- 3. Wheel brakes are operational
- 4. Tires are inflated to proper pressure.
- 5. Wheel chocks are removed and stored away properly.
- 6. Lights are operational.
- 7. All reel shaft pins/locking pins are properly engaged.
- 8. Safety chains and breakaway switch connected.

FIELD SET UP

Prepare the unit for operation as follows:

- 1. Locate the unit on level ground if possible, ensuring that the unit is aligned properly with the line to be pulled or tensioned.
- 2. Level the unit using the front and rear jacks.
- 3. It is highly recommended to put wheel chocks around each trailer tire to prevent movement of the trailer.



4. **PROPER ANCHORING OF THE MACHINE IS VERY IMPORTANT!** Anchor the unit using the anchoring lugs provided. Use an anchor that will hold three times the maximum pull of the unit.




Figure 5: Anchoring Diagram

- 5. **PROPER GROUNDING OF THE MACHINE IS VERY IMPORTANT!** The machine is equipped with grounding bars. To protect against electrical hazards due to induction or electrical contact, the system must be connected to a proper ground rod or the electrical system neutral. Follow proper grounding procedures as required by IEEE and/or the applicable standards in your area. Use of a ground mat and a running ground on the conductor are highly recommended.
- 6. Put a hazard barrier around the perimeter of the unit to keep unauthorized personnel away from the equipment.
- 7. Perform daily inspection and preventive maintenance as required.

PRE START CHECKLIST

- 1. Ensure that the Direction Control is in the NEUTRAL position.
- 2. Ensure that the Brake Control is in the APPLY position.

ENGINE START-UP

The engine manufacturer's manual, included in the Section V, contains detailed technical information regarding the engine including start up procedure. Make sure you read and understand the operating instructions contained therein.



CAUTION: DO NOT ALTER THE RPM GOVERNER SETTING OF THE ENGINE. THE HYDRAULIC PUMP IS LIMITED TO A SPECIFIC MAXIMUM RPM AND CAN BE DAMAGED IF DRIVEN FASTER THAN THE GOVERNED ENGINE SPEED.

STOPPING THE ENGINE

- 1. Move the Direction Control to the NEUTRAL position.
- 2. Move the Brake Control to the APPLY position.
- 3. Decrease the engine speed to idle.
- 4. Allow the engine to idle for a few minutes to cool down.
- 5. Shut down the engine.

HYDRAULIC WARM UP (COLD WEATHER START-UP)

- 1. Start the engine.
- 2. Leave the Direction Control in the NEUTRAL position.
- 3. Allow the system to run slightly above idle for twenty minutes or until the indicator gauge on the suction filter reads less than ten inches vacuum.
- 4. Ensure that the Brake Control is in the APPLY position.
- 5. Increase engine speed to half-throttle.
- 6. Move the Direction Control to approximately half-stroke in the PULL IN direction.
- 7. Turn in Linepull Control clockwise until the Pressure Gauge reads 1,000 psi.
- 8. Allow system to run for:
 - a. Ten minutes
 - b. or until hydraulic oil reservoir feels warm to the touch
 - c. or until the indicator gauge on the suction filter reads less than five inches vacuum

In extreme cold weather operations, special low temperature hydraulic oil is recommended.

PULLING (BEGINNING WITH SLACK ROPE)

The following procedure describes how to operate the DPT40-B when it is used as a puller and the rope is not under tension.



CAUTION: DO NOT FOLLOW THIS PROCEDURE WHEN THERE IS TENSION ON THE PULLING ROPE.

- 1. Increase the engine speed to full throttle. An engine operated at idle speed does not sufficiently power the hydraulic system and may let the brake drag causing damage or overheating of the brake and erratic control.
- 2. Ensure that the Brake Control is in the APPLY position.
- 3. Pull the Direction Control slightly in the PULL IN position.
- 4. Turn the Linepull Control clockwise until the Hydraulic Pressure Gauge reads 800 psi. This presets the linepull.
- 5. Move the Direction Control to the NEUTRAL position.
- 6. Confirm that the tensioner operator knows the pull is about to begin and has the tensioner correctly set.
- 7. Turn the Brake Control to the RELEASE position.
- 8. Slowly pull Direction Control slightly to the PULL IN position. The pulling reel should start to turn and tighten the pulling rope. When the pulling rope starts to move and pull the conductor, turn in the Linepull Control clockwise another ½ turn to have the relief pressure in the system set just slightly above the linepull at which you are working.

9. Slowly pull the Directional Control more into the PULL IN position until the desired linespeed is achieved.

NOTE: It may be necessary to turn the Linepull Control in several times from its initial setting as the pulling rope builds up on the pulling reel to maintain proper linepull and speed. Always turn the Linepull Control in ½ turn further than what is required to move the conductor, and this will ensure the puller will stall if a snag in the pulling rope or conductor occurs.

10. To stop the pull, move the Direction Control to the NEUTRAL position and turn the Brake Control to the APPLY position.

RESUMING A PULL AFTER STOPPING

This procedure describes how to start the pulling process after stopping while the pulling rope is still under tension. This procedure assumes the Linepull Control setting has not been changed from the previous operating position during the stop.

- 1. Confirm that the tensioner operator knows the pull is about to begin and has the tensioner correctly set.
- 2. Turn the Brake Control to the RELEASE position.
- 3. Move the Direction Control to the desired PULL IN position.

NOTE: This should start the pulling rope or conductor moving again at the same linepull as when you stopped. If the pulling rope or conductor remains stationary, slowly turn the Linepull Control clockwise until the pulling rope or conductor starts to move.

TENSIONING (BEGINNING WITH SLACK ROPE)

This procedure describes how to set the DPT40-B when it is used as a tensioner and the rope is not under tension.



WARNING: DO NOT FOLLOW THIS PROCEDURE WHEN THERE IS TENSION ON THE CONDUCTOR.

- 1. Increase the engine speed to full throttle. An engine operated at idle speed does not sufficiently power the hydraulic system and may let the brake drag causing overheating of the brake and erratic control.
- 2. Ensure that the Brake Control is in the APPLY position.
- 3. Put the Direction Control in the TENSION position.
- 4. Turn the Linepull Control clockwise until the Hydraulic Pressure Gauge reads 500 psi. This will preset a small amount of tension in the conductor.
- 5. Turn Brake Control to the RELEASE position.
- 6. Instruct the puller operator to start pulling.
- 7. As the line begins to move, adjust the Linepull Control until the desired stringing tension is achieved.

NOTE: You may have to adjust the Linepull Control to increase or decrease the tension in the conductor to maintain the correct stringing sag as the reel empties.

- 8. To stop the pull, the puller operator must stop pulling first.
- Once the conductor stops moving, the tensioner operator can either leave the controls adjusted for resuming the pull, or if it is desired to stop for a considerable length of time, it is advisable to put the Brake Control in the APPLY position and return the Direction Control to the NEUTRAL position.

RESUMING TENSIONING AFTER A STOP

This procedure describes how a pull is to be resumed after a short stop when the Linepull Control and Direction Control are still set from the previous pull.

- 1. Move the Brake Control to the RELEASE position
- 2. Instruct the puller operator to begin pulling again.

NOTE: The tension in the conductor should revert to the previous setting before the stop.

PAYING OUT (BEGINNING WITH SLACK ROPE)

The following procedure describes how to pay out rope or conductor when it is not under tension.



CAUTION: DO NOT FOLLOW THIS PROCEDURE WHEN THE ROPE IS UNDER TENSION.

- 1. Increase the engine speed to full throttle. An engine operated at idle speed does not sufficiently power the hydraulic system and may let the brake drag causing damage or overheating of the brake.
- 2. Make sure the Brake Control is in the APPLY position.
- 3. Turn the Linepull Control fully counter clockwise to give zero linepull.
- 4. Turn the Brake Control to the RELEASE position.
- 5. Push the Direction Control slowly into the PAY OUT position. You will have to lift the Direction Lever Stop to allow the Direction Control to pass beyond the NEUTRAL position. Push Direction Control more into the PAY OUT position to increase the speed.



WARNING: NEVER PUT THE DIRECTION CONTROL LEVER IN THE PAY OUT POSITION WHEN PULLING ROPE OR WHEN THE CONDUCTOR IS UNDER TENSION!

6. To stop, pull the Direction Control to the NEUTRAL position. The Direction Lever Stop will fall back into place restricting movement into the PAY OUT direction once again.

PAYING OUT ROPE UNDER TENSION

This procedure describes how to pay out or loosen a pulling rope or conductor when it is under tension. This situation may occur, for example, when a conductor or pulling rope is to be backed into a grip. Essentially, the process is to tension out the rope or conductor at a controlled speed until the tension drops to zero, then use the Pay Out procedure above to continue to paying out the rope if desired.

- 1. Increase the engine speed to full throttle. An engine operated at idle speed does not sufficiently power the hydraulic system and may let the brake drag causing damage or overheating.
- 2. Move the Brake Control to the RELEASE position. This transfers the tension load in the rope or the conductor from the brake to the hydraulic system.
- 3. Slowly turn the Linepull Control counterclockwise. This will start to allow the reel to pay out the rope or conductor as the load pulls on it. Continue turning the Linepull Control until it is fully counterclockwise and no tension remains in the rope or conductor.
- 4. Use the payout procedure above for paying out more rope.

FREEWHEELING PAY OUT WITH OVERSPIN BRAKE

The freewheeling pay out mode disconnects the hydraulic drive system and allows the reel to rotate freely as the rope or conductor is pulled off. A drag brake prevents the reel from overspinning while in freewheel mode. This procedure is usually used when the pulling rope is being pulled from the puller end of the set-up to the tensioner end.

- 1. Make sure the reel is stationary.
- 2. Place the Direction Control in the NEUTRAL position.
- 3. Turn the Brake Control to the APPLY position.
- 4. Shut off the engine.
- 5. Remove the lock pin from the drive sprocket located behind the drive door shown in Figure 6.



WARNING: THERE MUST BE NO TENSION ON THE LINE WHEN REMOVING THE LOCKING PIN!



Figure 6: Opening Drive Door

- 6. Pull off the conductor or rope as required using the drag brake to prevent reel overspin.
- 7. When payout is complete, reinsert the lock pin in the drive sprocket. You may have to rotate the reel by hand to line up the lock pin hole.

PULLING UNDERGOUND (OPTIONAL)

This procedure describes how to use the DPT40-B as an underground puller with the optional underground pulling reel and heavy duty underground levelwind.

- 1. Load underground reel into machine (see Reel Loading procedure).
- 2. Reeve the pulling rope through the bottom guide rollers of levelwind with the rope exiting straight into the manhole.



CAUTION: DO NOT PULL WITH THE ROPE AT AN ANGLE. THIS MAY MOVE THE DPT40-B SIDEWAYS SUDDENLY.

3. Follow the pulling procedure above.

REMOVING THE REEL

1. Turn the reel until the drive arm and lifting loop are in vertical (up) position, shown in Figure 7.



Figure 7: Lifting Loop in Vertical Position

2. On the drive arm side, pull the ball lock pin straight up, and pull the reel shaft pin back enough to allow the reel shaft to be lifted up, shown in Figure 8.



Figure 8: Removing Reel Shaft Pin

On the lifting loop side, open the locking latch and swing it back out of the way, shown in Figure 9.



Figure 9: Removing Locking Latch

- 4. Attach lifting hooks to the drive arm and lifting loop. Ensure they are balanced so the reel remains level during lifting.
- 5. Lift the reel straight up.
- 6. Remove the bronze bearing from reel shaft.
- 7. Loosen the nuts on the lifting loop and remove it from reel shaft.
- 8. Remove reel shaft from reel.



!WARNING/CAUTION! NEVER ATTEMPT TO INSTALL OR REMOVE A REEL UNLESS THE DRIVE ARM LOOP IS IN THE UPRIGHT POSITION. IF THE REEL SHAFT PIN IS REMOVED WITH THE DRIVE ARM IN ANY OTHER POSITION, THE REEL MAY FALL OUT OF ITS SUPPORTED POSITION AND MAY CAUSE PERSONAL INJURY OR EQUIPMENT DAMAGE.

LOADING A REEL

- 1. Turn the reel drive until the shaft coupling drive teeth face up.
- 2. On the drive sprocket side, pull ball lock pin straight up and pull the reel shaft pin back enough to allow the reel shaft to be installed, shown in Figure 8.
- 3. On the lifting loop side, open the locking latch and swing it back out of the way, shown in Figure 9.
- 4. Put the reel shaft in the reel, making sure the conductor or rope will wind on or off from the top of the reel in the correct direction.
- 5. Make sure the reel shaft drive pins are fully engaged in reel drive holes.
- 6. Install the lifting loop tight against side of the reel to hold it firmly against the drive arm and keep it from sliding sideways. Torque nuts on locking collar to 200 ft-lbs.



ALWAYS MAKE SURE THAT THE REEL IS PUSHED TIGHT AGAINST THE DRIVE ARM AND HELD SECURELY BY LIFTING LOOP/LOCKING COLLAR.

- 7. Install the bronze bearing on end of the reel shaft.
- 8. Attach lifting hooks to the drive arm and lifting loop, making sure they are balanced so the reel remains level during lifting.
- 9. Lower the reel in place engaging the reel shaft drive with its mating part and making sure the bronze bearing locates in the bearing support.
- 10. Push the reel shaft pin back into place and insert the ball lock pin to hold the reel shaft pin in place.
- 11. Swing the locking latch back into place over the bronze bearing and insert the safety pin.



!CAUTION/WARNING! THE REEL MUST BE OVERWOUND WHEN PLACED IN THE MACHINE AS VIEWED FROM THE OPERATORS POSTION. THE REEL SHAFT DRIVE ARM MUST BE INSERTED FROM THE SIDE OF THE REEL THAT WOULD TEND TO WIND IN THE PULLING ROPE.

HIGH SPEED POLEMASTER SETUP (OPTIONAL)

This section describes the operation of the High Speed PoleMaster Pilot Rope System shown in Figure 10. The High Speed Polemaster System is a very fast and productive method of installing the pulling rope in the stringing blocks ready for the pulling of the conductor. The Polemaster System consists of three or more drums of synthetic pilot rope, each with a brake shaft all of which are mounted to the first pole in front of the tensioner. The pilot ropes are then installed in the stringing blocks for each phase plus neutral from the tensioner end to the puller end.

Figure 10: High Speed Polemaster



The end of one of the Polemaster pilot ropes is attached to the end of the pulling rope at the puller. At the tensioner, the corresponding Polemaster drum is removed from its brake on the pole and installed on the DPT40-B High Speed PoleMaster drive as detailed below.

- 1. Disconnect the chain drive from the reel as described in Freewheeling Payout section. This allows the Polemaster drum to turn without also turning the reel shaft.
- 2. Remove the drive shaft extension cover from the drive door and store it on top of the door as shown in Figure 11.



Figure 11: Extension Cover

- 3. Remove the Polemaster drive shaft from its storage pin located on the frame.
- 4. Slide the Polemaster drive shaft onto the drive shaft extension, which sticks out from the drive door, and fully install the extension lock pin as shown in Figure 12.



Figure 12: Polemaster Shaft Installed on the Drive

- 5. Slide the Polemaster drum onto the Polemaster drive shaft making sure the rope exits from the top of the drum toward the rear of the DPT40-B. You may have to rotate the Drum slightly to line up the Drive Slots in the Drum with the Shaft Drive Pins.
- 6. Insert the Drum Lock Pin as shown in Figure 13. Make sure the spring clip is installed correctly in order to keep the pin from falling out.



7. Remove some rope from the Polemaster Drum and feed it around the guide sheaves of the Polemaster Levelwind as shown in Figure 14.



Figure 14: Levelwind Reeving

The installation of the drum and rope should be as shown in Figure 15. The Polemaster System 8. is now ready to pull the pulling rope back to the conductor reel in the Tensioner.



Figure 15: Polemaster Setup

CAUTION: DAMAGE TO THE DRUM, ROPE AND/OR PERSONAL INJURY CAN RESULT FROM OVERLOADING THE POLEMASTER DRIVE SYSTEM.

HIGH SPEED POLEMASTER OPERATION (OPTIONAL)

1. Follow the procedure from the Pulling Sections using the pressure recommendations in the note below.

NOTE: The maximum 300 pounds linepull is reached at 500 PSI on the pressure gauge for an empty Polemaster reel and 1000 PSI on a full Polemaster reel.

- 2. Use the Polemaster Levelwind to evenly distribute the pilot rope across the Polemaster Drum so it does not pile in one spot and get tangled.
- 3. When the pulling rope for the first phase arrives at the Tensioner end, it is removed from the end of the pilot rope, and is attached to the end of the conductor.
- 4. In preparation for tensioning the conductor, remove the full Polemaster Drum from the DPT40-B.
- 5. Remove the Polemaster drive shaft and store.
- 6. Install the drive shaft extension cover on the hinged door.
- 7. Open the hinged door and reinstall the free wheeling lock pin as described. This reconnects the chain drive to the reel.
- 8. Proceed to tension the conductor as described in the Tensioning Sections.

SECTION III MAINTENANCE

SCOPE

This section contains schedules, recommendations, and procedures designed to ensure that the equipment is prepared for safe and efficient operation and to prolong the service life of the equipment. These maintenance instructions constitute basic requirements for an operational environment that is not extreme in temperature, humidity, airborne abrasives, or other conditions which would require preventative maintenance techniques to combat. The using organization is encouraged to determine preventative maintenance requirements that are the result of environmental extremes.

SERVCIE SAFETY PRECAUTIONS

- 1. Before performing maintenance or repair work on any equipment, consult the manufacturer's instruction manual and follow the recommended procedures.
- 2. When servicing or repairing the equipment, shut down the engine unless it is required to be running for adjustment purposes.
- 3. Always use the proper tools for the job. Repair or replace any broken or damaged tools, including lifting equipment immediately.
- 4. Keep your head, hands, feet, and loose clothing away from power-driven parts.
- 5. Pressure can be maintained in the hydraulic circuits long after the power source and pump have been shut down. Relieve all trapped pressures before performing any service work to the hydraulic components.
- 6. When troubleshooting a hydraulic system for leaks, use a piece of cardboard or other material as detector rather than your hand. Pressurized hydraulic fluid escaping from a faulty component can penetrate the skin and cause serious injury.
- 7. Do not change the pressure setting of any hydraulic valves unless authorized instruction has been obtained.
- 8. Ensure that all tire and rim parts are undamaged and correctly assembled before inflating the tires.
- 9. Use an inflation cage, safety cables or some other safety device when inflating the tires. Do not exceed the tire manufacturer's recommended maximum pressure
- 10. Use caution when draining hot fluids from the machine. Splashing hot fluid can cause serious burns.
- 11. Ensure that the equipment is blocked so that it cannot shift or move during servicing.
- 12. Install all applicable safety locks before working on a piece of equipment. Disconnect electrical power before servicing electrical components.

FIRE PREVENTION

Fires can create severe emergencies where both human life and property may be lost. Even when confined, a fire may cause very expensive damage to your equipment. Fire can strike at anytime, not only when the equipment is used, but also when lift unattended between work shifts and nobody is around to fight it.

When working in a confined environment, it is impossible to prevent combustible dust from collecting in tight corners of the machine. This dust, in itself, may not cause a fire, however, when mixed with fuel, oil or grease in a hot an confined place, it can become a fire hazard.

To reduce the chances for a fire to break out, follow the preventative instructions listed below:

- 1. Inspect the machine daily for potential fire hazards and make any necessary repairs up immediately.
- 2. Always ensure that excess grease and oil accumulation, including spillage, are cleaned up immediately.
- 3. Use only nonflammable cleaning agents for cleaning the machine or any machine component.
- 4. Store oily rags and other combustible materials in a fireproof location.
- 5. Before performing repair work such as welding, the area surrounding the repair location should be cleaned and a fire extinguisher positioned close by.
- 6. Maintain a charged fire extinguisher on or near the machine at all times and know how to use it.

INSPECTIONS

Periodic inspection of the unit according to a regular schedule will establish the normal state of the unit for personnel associated with its operation and maintenance and provide a set of consistent conditions, which will tend to highlight any occurrence of a potentially hazardous malfunction.

On a daily basis walk around the unit and look closely for any indication of the following:

- 1. Loose threaded connections.
- 2. Metal fatigue or excessive corrosion.
- 3. Abraded hose surfaces.
- 4. Hydraulic fluid leakage.
- 5. Possible obstruction of moving parts especially in the drive train.

To ensure proper operation and long life of your TSE International products, use only good quality lubricants and maintain a regular maintenance schedule as recommended by TSE International and our component suppliers.

Prior to start-up of new TSE International products, all fluid levels are to be checked to ensure correct operating levels. All lubrication and maintenance points are to be inspected and lubricated as illustrated on the Lubrication and Maintenance Instructions sheet.

While TSE International recommends specific intervals, they are intended as a minimum general guide for the maintenance of the equipment. Some job conditions and/or locations may dictate more frequent service intervals than have been recommended.

	LUBRICATION DATA									
LUBRICANT	LUBRICANT INFORMATION	GRADES	TSE PART #	APPLICATION						
AW46	TSE STANDARD HYDRAULIC FLUID (REFER TO HYDRAULIC OIL DECAL LOCATED ON HYDRAULIC RESERVOIR TO DETERMINE WHAT HYDRAULIC FLUID IS USED IN YOUR MACHINE)	ISO 46	567851	HYDRAULIC SYSTEM FLUID						
UTILITY EP #2 GREASE	MULTIPURPOSE GREASE	-	-	BEARINGS, SHAFTS, FRICTION COMPONENTS						
LUBRIPLATE CHAIN & CABLE FLUID	PENETRATING FLUID	SAE 10 ISO 32	-	CHAINS, WIRE ROPES, CABLES						
SPARTAN EP150	INDUSTRIAL GEAR OIL	ISO 150	-	GEARBOXES (REDUCERS) - SEE VENDOR LITERATURE FOR VARIATIONS AND AMOUNTS						
SUPER MPGO 80W90	PETROLEUM OIL BLEND	-	-	PUMP DRIVES						

SUGGESTED MAINTENANCE SCHEDULE

The following schedule should be carried out by qualified personnel using proper lubricants to suit environmental and operating conditions.

NOTE: THESE ARE SUGGESTED RECOMMENDATIONS ONLY. SPECIFIC SITUATIONS MAY REQUIRE A DIFFERENT LUBRICATION SCHEDULE. ALTER AS NECESSARY.

SERVICE	HOURS	DAILY	WEEKLY	100	150	500	1000
INTERVAL	MONTHS	DAILY	WEEKLY	1	2	6	12
DESCRIPTIO	ON (5)						
BEARINGS		-	-	L	-	-	ο
BUSHINGS		-	-	L	-	-	-
REELSHAFT BUS	EELSHAFT BUSHINGS		-	-	-	-	-
PIVOT POINTS		-	Х	L	-	-	-
CHAIN DRIVES		-	-	-	-	0	-
COUPLINGS		-	-	-	-	-	Х
BOLTED CONNEG	CTIONS	Х	-	-	-	-	-
HYDRAULIC PLU	HYDRAULIC PLUMBING		-	-	-	-	-
HYDRAULIC RES	DRAULIC RESERVOIR (4)		-	-	-	-	-
HYDRAULIC FILT	-	-	-	R (3)	-	-	
HYDRAULIC HOS	-	-	-	-	Х	-	
MISC. COMPONE	NTS (1)	-	L	-	-	-	-

	SYMBOL
R	REPLACE
L	LUBRICATE
Х	INSPECT & CORRECT
0	CLEAN & LUBRICATE
F	FLUSH & CHANGE


- 1. Items such as engines, pumps, pump drives, motors, reducers, brakes, etc. on your equipment should be serviced according to the manufacturer's maintenance schedule (see outside vendor literatures)
- 2. Hydraulic filter part numbers and descriptions can be found in the hydraulic schematic.
- 3. Change after the first 50 hours of use.
- 4. See the decal by the Hydraulic Reservoir.
- 5. Certain items may not be apart of your machine and DO NOT apply.


REV	DATE	CHANGE NUMBER	AMENDMENTS	BY	APPD
В	16JAN19	ECN-3407	ITEM #2 WAS 8600484 - OVERHEAD LEVELWIND ASSY	SB	JM
	DPT40- - 48 - 70,0 - 80,0 - 4,35 - 0-4 - 12,0 - FEN - FEN - OVE - FEN - OVE - REA - BOL - BRO 10 M R - STAI - REF ▲ C S	-B PULLER HP WATER ()00 in. lbs.)00 in. lbs.)00 lbs. CON brock LINES)00 LBS TAI DERS, MUDF RHEAD/UND YDRAULIC P ROM OPERA RATOR SEAT R STABILIZE T ON MANU NZE OVERS 6" DIAMETER ANUAL CON ECOMMENDE NDARD LED LECTIVE TAP USTOMER: C	TENSIONER TENSIONER COOLED JOHN DEERE DIESEL ENGINE (FINAL TIER 4) CONTINUOUS TORQUE RATING. INTERMITTENT TORQUE RATING. TINUOUS LINE PULL (6,000 FT OF 5%" ROPE) SPEED WITH INFINITE CONTROL. NDEM AXLE TRAILER MOUNTED. LAPS, BREAKAWAY CHAINS, ELECTRIC TRAILER BRAKES. ERGROUND LEVELWIND: DWERED, WITH SWING-AWAY TOP OPENING ROLLER AND CONTROLLED TOR'S CONSOLE. , DELUXE PADDED SEAT ADJUSTABLE HORIZONTALLY & VERTICALLY. RS: TWO BOLT ON MECHANICAL TYPE STABILIZERS MOUNTED ON REAR. AL FRONT JACK PIN BRAKE: BRONZE ALLOY VENTILATED DISC ROLLED CALIPER. D WHEN USING THE "FREE WHEEL" MODE. HIGHWAY LIGHTING W/ 7PT TRAILER PLUG E AS PER NHTSA USTOM TRUCK & EQUIPMENT 1-01 (TRL-17817)		
13		75			2


D600775		DECAL, TRL-17817		2
				۷
6600802		JACK ASSY – MANUAL REAR		2
564723		DOCUMENT HOLDER		1
567851		OIL, HYDRAULIC (AW-46)		30
5602413		BOX, DOCUMENT STORAGE		1
561071		276 LG – 7 CONDUCTOR CABLE		23.0FT
7601116		LIGHTING DIAGRAM, 7 PT LED		1
5600297		DECAL PACKAGE, DPT40-B		1
6600600		JACK ASSY – MANUAL		1
880256		BRAKE CALIPER INSTALLATION		1
810307		16 INCH BRONZE DISC		1
8602493		LEVELWIND, OVER/UNDER - DPT40-B		1
8602060		GENERAL ASSEMBLY, FT4 DPT40-B		1
PART NUMBER	DPER DESC	DESCRIPTION	MATERIAL	UNIT QTY
	564723 567851 5602413 561071 7601116 5600297 6600600 880256 810307 8602493 8602060 PART NUMBER	564723 I 567851 I 5602413 I 561071 I 7601116 I 5600297 I 6600600 I 880256 I 8602493 I 8602060 I PART NUMBER IPER	564723DOCUMENT HOLDER567851OIL, HYDRAULIC (AW-46)5602413BOX, DOCUMENT STORAGE561071276 LG - 7 CONDUCTOR CABLE7601116LIGHTING DIAGRAM, 7 PT LED5600297DECAL PACKAGE, DPT40-B6600600JACK ASSY - MANUAL880256BRAKE CALIPER INSTALLATION81030716 INCH BRONZE DISC8602493LEVELWIND, OVER/UNDER - DPT40-B8602060GENERAL ASSEMBLY, FT4 DPT40-BPART NUMBERDESCDESCRIPTION	564723DOCUMENT HOLDER567851OIL, HYDRAULIC (AW-46)5602413BOX, DOCUMENT STORAGE561071276 LG - 7 CONDUCTOR CABLE7601116LIGHTING DIAGRAM, 7 PT LED5600297DECAL PACKAGE, DPT40-B6600600JACK ASSY - MANUAL880256BRAKE CALIPER INSTALLATION81030716 INCH BRONZE DISC8602493LEVELWIND, OVER/UNDER - DPT40-B8602060GENERAL ASSEMBLY, FT4 DPT40-B


This prime is the property of 15c international incorporated, it is loaned with the express agreement that the drawing and the information contained therein are the property of 15c International Incorporated and will not be reproduced, copied or otherwise disposed of directly or indirectly, and will not be used in whole or in part to assist in making or to furnish any information for making drawings, prints or other reproductions thereof, or for the making of apparatus or parts thereof except upon written permission of TSE International Incorporated. The acceptance of the print will be construed as a acceptance of the foregoing agreement.


UNLESS OTHERWISE SPI DIMENSIONS ARE INC DIMENSIONS IN [] AF -TOLERANCES-	CHES RE MM		TSE INTERNATIONAL INC Shreveport, Louisiana, United States of America				
A) ANGULAR B) DECIMAL (ONE) .X	± 1/2* ± .06	MATL N/R	TITLE DPT40B,	FINAL ASSE	MBLY		
(TWD) .XX (THREE) .XXX	± .02 ± .01	MATL TEST N/R	NEXT ASSEMBLY		DERIVED FROM F60	2473	
C) FRACTIONAL 1. GENERAL	± 1/32	WELD N/R	FIRST USED 520	1	SHEET 1	of 1	
2. SAWING, FLAME CUTTING, SHEARING	± 1/16	EST LBS N/A	drawn check TKR	ed approved JM	F6024	74 REV	
& BREAKING 3. WELDING	± 1/8	ACT LBS N/A	DATE 20SEP18	SCALE 1/1	Г0024.	/4 D	


















BY APD		REF	REF	- ,				9				1 LINIT	QTY ded and will not productions thereof,	INC	2	1 REV
								GR 5					MATERIAL of TSE International Incorpo dramings, prints or other re	lance of the foregoing agr ONAL States of A	MBLY	1 <mark>™</mark> 7601128
AMENDHENTS			J6 AL					G; C/W LW, NUT	NPT-04 BRS	ORB-04	U PSI/BAR	40B FT4	DESC DESCRIPTION MATERIAL And TERIAL MATERIAL MATERIAL MATERIAL And the compare of the burden of the b	protect. The cooptimum of the prior and the construct of an acceptance of the transpire optiment. TSE INTERNATIONAL IN Scheman or the intervent of the states of American	TITLE CONTROL CONSOLE ASSEMBLY INTLE CONTROL CONSOLE ASSEMBLY NEXT DOCTOR	ASSMELY 800_2000 FROM FIRST USED 4713 SMEET PROVIDENCED ADD ACL CHECKED ADD MATE 1/2 7(
		BECKETT VALVE	VALVE- FR 3000 ORB-06	SAFETY LATCH	COLLAR- STOP	DETENT KIT	BALL JOINT	HHCS 1/4-20NC X 1 LG; C/W LW, NUT	CABLE, CONTROL - 8FT VALVE- BL 3W2P 2500	VALVE- RF 9150 4600 ORB-04	GAUGE - Z-1/Z U-2000 MORSE CONTROL, SINGLE	PANEL ENGRAVING DPT 40B FT4	. It is loaned with the express agreement that to indirectly, and will not be used in whole or in	IED	MATL N/R CERT N/R MATL N/D	TEST N/ N VELD N/R EST N/A LBS N/A
CHANGE NUMBER		-						Ē					DESC DESC and Incorporated	SPECIF INCHES ARE M		
DATE CH		563299	562109	811853	561171	561114 561114	531185		561147 560320	560331	561111	8602070	PART NUMBER tt is the property of TSE International aduced, copied or othernise disposed	ar for the making of apportun or parts thread anoid upon with UNLESS IDTHERWISE SPECIFIED DIMENSIONS ARE INCHES DIMENSIONS IN [] ARE MM	- TIDLERANCES A) ANGULAR B) DECIMAL (DNE) XX (TYPD) XX	C) FRACTIDINL 1. CENTRAL 2. SAVING, FLAME 2. SAVING, FLAME 3. VELDING 3. VELDING
REV		15	14	13	7 1	9 0	ס מ	~	പ	4 1	n v	-	ITEM This print is be reproduc		A) AN B) DE	ଝୁଁ ୷ରା ଜୀ ପି
	13 13 13 13 10 10 10 10 10 10 10 10 10 10		((1) (5)												









JT- 1-BNC ES	1/4"L0	PIN ASSY (3/4" DIA X 10 1/8"L) HARD ROLLER ASSY	CYLINDER EAR KEYSTOCK 1/2" X 1/2" X 4" LONG	LG LG	1/2" LONG f"LONG	<mark>" X 3/16"W X 32 1</mark> 2" X 1/2" X 3" 10h	3/16"W X SY	
Ē		ю 4	s s	Ē	4	- 0	v - ۱	DESC
200311	563391 561264	563390 660035	561741 120006	196280	145023 105112	158139 120006	158351 760097	Part ND.
15 15	13 14	11	9 t	8 1	5	4 M	- 10	ITEM











REV	DATE	CHANGE NUMBER			AMENDME	NTS		BY	APPD
С	12MAR02		R	EDRAV	N ON CAD			DY	RB
5	56120	65	1	PIN-					EF
4		10	FI		3NC HXHD X 4 1/2" LG. C/W	V LN			1
3	61114				- DRIVE				1
2	71385	58			ADAPTER, POLEMASTER				1
1				POLE	ASTER REEL ASSEMBLY				EF.
ITEM	PART NU	MBER	DPER DESC		DESCRIPTION		MATERIAL	Q Q	NIT TY
] DI A) A	NGULAR ECIMAL (ONE)	ARE IN IN [] 4 RANCES- .x	NCHES ARE M - ± 1 ± ,	1M 1/2* - 06	Shrevepo	INTERNA ort, Louisiana, Un , HIGH SPEED	ited States of A		
		.XX EX.XX	± , ± ,	02 F	ATL N/R NEXT ASSEMBLY	1	DERIVED ROM		
1	RACTIONAL GENERAL		± 1	- F	ELD N/R FIRST USED DN VD				1
	. SAWING, FL4 CUTTING, SH & BREAKING . WELDING			1/16		CKED APPROVED	563016	RI	C





2.9 L OEM Diesel Engines (Final Tier 4/Stage IV Platform)

OPERATOR'S MANUAL 2.9 L OEM Diesel Engines (Final Tier 4/Stage IV Platform)

OMRG39496 ISSUE 25MAR15 (ENGLISH)

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

If this product contains a gasoline engine:



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

The State of California requires the above two warnings.

Additional Proposition 65 Warnings can be found in this manual.

John Deere Power Systems PRINTED IN U.S.A.

OEM Engine and Drivetrain Warranty Registration

Why registering your OEM engine or drivetrain product is a really smart idea:¹

Get faster service. Registering your engine or drivetrain product gives us the information we need to meet your service needs promptly and completely.

Protect your investment. You'll be kept up-to-date on engine or drivetrain product updates.

Extend your warranty. You'll be given the option to extend your coverage before your standard warranty term expires.

Stay informed. Be the first to know about new products and money-saving offers from John Deere.

NOTE: A mail-in registration form is located at the back of this manual.

You're Covered

When you buy a John Deere engine or drivetrain product you aren't just buying pistons and crankshafts and gear drives. You're buying the ability to get work done. Without downtime, without worries, and without hassles. And you're buying the assurance that if you do need help, a strong support network will be there — ready to step in.

Confidence. That's what John Deere engines, John Deere drivetrains, and John Deere Warranties are all about.

Long durations. Warranties designed to give you confidence in your engine or drivetrain product.

Worldwide support. Get service when and where you need it. John Deere has 4,000+ service locations worldwide.

Genuine John Deere parts and service. Authorized service outlets will use only new or remanufactured parts or components furnished by John Deere.

Warranty Duration

¹Register your OEM engine or drivetrain product online and select an authorized John Deere service location. If available in your region, you'll receive information regarding new products and current money-saving offers from John Deere. Limit one money-saving offer per engine warranty registration. Not transferable. Not valid with any other offer. Offer ends 90 days from the date of issue. Some restrictions apply. See your John Deere service location for complete details. 

Scan this code to register your OEM engine online now and learn of current money-saving offers available to you.¹ You can also visit us directly at JohnDeere.com/warranty.

Equipment operators can't afford downtime or unexpected repairs. That's why we offer a 2-year/2,000-hour warranty, with unlimited hours in the first year, on our OEM industrial and marine engines. This warranty takes effect the date that the engine is delivered to the first retail purchaser. In addition, extended warranties are available under certain conditions. John Deere offers a variety of purchased warranties to extend the warranty period for your engine. You'll be given the option to extend your coverage before your standard warranty term expires. Be sure to register your engine or drivetrain product and take full advantage of the John Deere service and support network.

Obtaining Warranty Service

Warranty service must be requested through an authorized John Deere service outlet before the expiration of the warranty. Evidence of the engine's or drivetrain product's delivery date to the first retail purchaser must be presented when requesting warranty service. Authorized service outlets include:

- John Deere distributor
- John Deere OEM service dealer
- John Deere equipment dealer
- John Deere marine dealer

Worldwide Support Network

Visit JohnDeere.com/dealer to find the authorized engine or drivetrain service location nearest you. For complete warranty details visit JohnDeere.com/warrantystatements to view, download, or print the warranty statement for your engine or drivetrain product.

ZE59858,000025E -19-02DEC13-1/1

Foreword

READ THIS MANUAL carefully to learn how to operate and service your engine correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your engine and should remain with the engine when you sell it.

MEASUREMENTS IN THIS MANUAL are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by standing at the drive or flywheel end (rear) of the engine and facing toward the front of the engine.

WRITE ENGINE SERIAL NUMBERS and option codes in the spaces indicated in the Record Keeping Section. Accurately record all the numbers. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the engine.

SETTING FUEL DELIVERY beyond published factory specifications or otherwise overpowering will result in loss of warranty protection for this engine.

CERTAIN ENGINE ACCESSORIES such as radiator, air cleaner, and instruments are optional equipment on John Deere OEM Engines. These accessories may be provided by the equipment manufacturer instead of John Deere. This operator's manual applies only to the engine and those options available through the John Deere distribution network.

NOTE: This operator's manual covers only engines provided to OEM (Original Equipment Manufacturers). For engines in Deere machines, refer to the machine operators manual.

ZE59858,000028E -19-14NOV13-1/1


Engine Owner

John Deere Engine Owner:

It is important for you to register your new engine for factory warranty. Registering your engine will allow your Service Dealer to verify that your warranty status should a repair be needed. The easiest way to register your engine is via the internet. To register your engine for warranty via the internet, please use the following URL: http://www.johndeere.com/enginewarranty Your John Deere Engine Distributor or local John Deere Service Dealer will also be happy to provide this service. Engine service can be done by all Ag, C&FD, and JDPS branded dealers. To view the John Deere Service Dealer network or locate your nearest Dealer, use the following URL: http://www.johndeere.com/dealer

JR74534,000026F -19-21JUN12-1/1

Identification Views



3029HFC03 Right Front View

ZE59858,0000048 -19-15SEP14-1/1

Trademarks

	Trademarks
AdBlue®	AdBlue is a trademark of VDA, the German Association of the Automotive Industry.
AMP®	AMP is a trademark of Tyco Electronics
BIO-GREASE-GARD™	BIO-GREASE-GARD is a trademark of Deere & Company
Bio Hy-Gard™	Bio Hy-Gard is a trademark of Deere & Company
Bluetooth®	Bluetooth is a trademark of Bluetooth SIG
Break-In Plus™	Break-In Plus is a trademark of Deere & Company
CINCH™	CINCH is a trademark of Cinch Inc.
COOL-GARD™ PLUS	COOL-GARD is a trademark of Deere & Company
CoolScan™	CoolScan is a trademark of Deere & Company
COOLSCAN PLUS™	COOLSCAN PLUS is a trademark of Deere & Company
Custom Performance™	Custom Performance is a trademark of Deere & Company
Deere™	Deere is a trademark of Deere & Company
DENSO®	DENSO is a trademark of DENSO Corporation
DEUTSCH®	DEUTSCH is a trademark of Deutsch Co.
DieselScan™	DieselScan is a trademark of Deere & Company
DuPont®	DuPont is a trademark of E.I. DuPont de Nemours and Company
EXTREME-GARD™	EXTREME-GARD is a trademark of Deere & Company
FleetGard™	FleetGard is a trademark of Deere & Company
Fleetguard®	Fleetguard is a trademark of Cummins Filtration
FlexBox™	FlexBox is a trademark of Deere & Company
Funk™	Funk is a trademark of Deere & Company
GREASE-GARD™	GREASE-GARD is a trademark of Deere & Company
	Hy-Gard is a trademark of Deere & Company
Hy-Gard™ JDLink™	
JDParts™	JDLink is a trademark of Deere & Company
John Deere™	JDParts is a trademark of Deere & Company
	John Deere is a trademark of Deere & Company
Loctite®	Loctite is a trademark of Henkel Corporation
Metri-Pack®	Metri-Pack is a trademark of Delphi Connection Systems
OILSCAN PLUS™	OILSCAN PLUS is a trademark of Deere & Company
Oilscan™	Oilscan is a trademark of Deere & Company
Permatex®	Permatex is a trademark of Illinois Tool Works Inc.
Phoenix™	Phoenix is a trademark of Deere & Company
Plastigage®	Plastigage is a trademark of Perfect Circle Corporation
Plus-50™ II	Plus-50 is a trademark of Deere & Company
PowerSight™	PowerSight is a trademark of Deere & Company
PowerTech™	PowerTech is a trademark of Deere & Company
PowerTech™ E	PowerTech is a trademark of Deere & Company
PowerTech™ M	PowerTech is a trademark of Deere & Company
PowerTech™ Plus	PowerTech is a trademark of Deere & Company
PRECISION JOINT™	PRECISION JOINT is a trademark of Deere & Company
RemanSelect™	RemanSelect is a trademark of Deere & Company
Restore®	Restore is a trademark of "Restore, Inc."
Scotch-Brite®	Scotch-Brite is a trademark of 3M Co.
Scotch-Grip®	Scotch-Grip is a trademark of 3M Co.
Service ADVISOR™	Service ADVISOR is a trademark of Deere & Company
SERVICEGARD™	SERVICEGARD is a trademark of Deere & Company
ГАСН-N-TIME™	TACH-N-TIME is a trademark of SPX Corp.
TeamMate™	TeamMate is a trademark of Deere & Company
TEFLON®	TEFLON is a trademark of Du Pont Co.
TMIII™	TMIII is a trademark of Deere & Company
	Continued on next page ZE59858,0000006 -19-13FEB

Vari-Cool™	Vari-Cool is a trademark of Deere & Company			
WEATHER PACK®	WEATHER PACK is a trademark of Packard Electric			
WINDOWS®	WINDOWS is a trademark of Microsoft Corporation			
ZE59858.0000006 -19-13FEB14-2/2				

Page

Record Keeping	
Record Engine Serial Number	01-1
Engine Option Codes	01-2
Record Aftertreatment Serial Numbers	
Record High-Pressure Fuel Pump	
Model Number	01-3
Record Engine Control Unit (ECU)	
Serial Number	01-4

Safetv

Understand Signal Words	05-1
Recognize Safety Information	
Replace Safety Signs	05-1
Follow Safety Instructions	05-2
California Proposition 65 Warning	
Exhaust Filter Cleaning	
Work In Ventilated Area	
Dispose of Waste Properly	05-3
Prevent Machine Runaway	
Practice Safe Maintenance	
Work in Clean Area	
Wear Protective Clothing	05-5
Service Machines Safely	
Use Proper Tools	05-5
Support Machine Properly	05-6
Use Proper Lifting Equipment	05-6
Protect Against Noise	05-6
Illuminate Work Area Safely	05-7
Install All Guards	05-7
Stay Clear of Rotating Drivelines	
Protect Against High Pressure Spray	05-8
Service Cooling System Safely	
Remove Paint Before Welding or Heating	
Do Not Open High-Pressure Fuel System	05-9
Avoid High-Pressure Fluids	05-9
Avoid Heating Near Pressurized Fluid Lines	
Avoid Static Electricity Risk When Refueling	
Handle Fuel Safely—Avoid Fires	
Prepare for Emergencies	
Handle Starting Fluid Safely	05-11
Handling Batteries Safely	05-12
Prevent Acid Burns	05-13
Prevent Battery Explosions	
Live With Safety	05-14

Fuels, Lubricants, and Coolants

Diesel Fuel10-	-	•	1	
----------------	---	---	---	--

Supplemental Diesel Fuel Additives	10-1
Lubricity of Diesel Fuel	10-2
Handling and Storing Diesel Fuel	
BioDiesel Fuel	
Testing Diesel Fuel	10-4
Fuel Filters	
Minimizing the Effect of Cold Weather	
on Diesel Engines	10-5
John Deere Break-In Plus™ Engine Oil	
 Interim Tier 4, Final Tier 4, Stage 	
IIIB, and Stage IV	10-6
Diesel Engine Oil — Interim Tier 4,	
Final Tier 4, Stage IIIB, and Stage IV	10-6
Engine Oil and Filter Service Intervals	
 Interim Tier 4, Final Tier 4, Stage 	
IIIB, and Stage IV — OEM Applications	
Diesel Engine Oil and Filter Service Intervals .	
Mixing of Lubricants	
Alternative and Synthetic Lubricants	10-8
Lubricant Storage	
Oil Filters	10-9
Diesel Engine Coolant (engine with	
wet sleeve cylinder liners)	10-10
Water Quality for Mixing with Coolant	
Concentrate	
Operating in Warm Temperature Climates	
Testing Coolant Freeze Point	10-12
Disposing of Coolant	10-12

Instrument Panels

Instrument Panels	
Using Diagnostic Gauge to Access	
Engine Information	
Main Menu Navigation	
Engine Configuration Data	
Accessing Stored Trouble Codes	
Accessing Active Trouble Codes	
Engine Shutdown Codes	15-11
Adjusting Backlighting	15-12
Adjusting Contrast	15-14
Selecting Units Of Measurement	15-15
Setup 1-Up Display	15-17
Setup 4-Up Display	15-23
John Deere PowerSight	15-27

Continued on next page

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

i

COPYRIGHT © 2015 DEERE & COMPANY Moline, Illinois All rights reserved. A John Deere ILLUSTRUCTION ™ Manual Previous Editions Copyright © 2014

Page

Page

Engine Operation

Break-In Service	20-1
Generator Set (Standby) Applications	20-2
Starting the Engine	20-2
Normal Engine Operation	20-3
Warming Engine	20-4
Idling Engine	20-4
Changing Engine Speed	20-5
Cold Weather Operation	20-6
Stopping the Engine	20-7
Auxiliary Gear Drive Limitations	20-8
Using a Booster Battery or Charger	20-8

Aftertreatment System

Exhaust Filter Cleaning and Maintenance	25-1
Exhaust Filter — Cleaning	25-1
Diesel Particulate Filter Maintenance	
and Service	25-2
Exhaust Filter — Diesel Particulate	
Filter Ash Handling and Disposal	25-2
Exhaust Filter — Disposal	25-2
Exhaust Filter System Overview	
Diagnostic Gauge Keys and Indicators	
Överview	25-4
Passive Regeneration/Natural Cleaning	25-5
Automatic (AUTO) Exhaust Filter Cleaning	25-5
Manual/Parked Exhaust Filter Cleaning	25-6
Disable Exhaust Filter Cleaning	25-7
Exhaust Filter Service Required	25-7

Lubrication and Maintenance

Observe Service Intervals	. 30-1
Use Correct Fuels, Lubricants, and Coolant	.30-1
Lubrication and Maintenance Service	
Interval Chart	.30-2

Lubrication & Maintenance — Daily

Daily Prestarting	Checks			35-1
--------------------------	--------	--	--	------

Lubrication & Maintenance — 250 Hours/12 Months

Lubrication & Maintenance — 500 Hours/12 Months

Servicing Fire Extinguisher	40-1
Servicing Battery	
Changing Engine Oil and Replacing Filter	40-3
Visually Inspecting Coolant Pump	40-5
Checking Open Crankcase Vent (OCV)	40-5
Checking Engine Mounts	40-6
Checking Fan and Alternator V-Belt Tension	40-6
Checking Air Intake System	40-8
Checking Engine Ground Connection	40-8
Checking Cooling System	40-9

	Page
Pressure Testing Cooling System Checking and Adjusting Engine Speeds	
Lubrication & Maintenance — 1200 Ho Checking and Adjusting Valve Clearance	

Lubrication & Maintenance — 1500 Hours/24 Months

Changing Open Crankcase Ventilation

(OCV) Filter	50-1
--------------	------

Lubrication & Maintenance — 6000 Hours/72 Months

Flushing and Refilling Cooling System	.55-1
Testing Thermostat Opening Temperature	.55-3

Service As Required

Additional Service Information	60-1
Do Not Modify Fuel System	60-1
Drain Water From Fuel Filter	60-2
Bleeding Fuel System	60-2
Adding Coolant	60-4
Pre-Start Cleaning Guide	
Replacing Single Stage Air Cleaner	60-6
Replacing Axial Seal Air Cleaner Filter	
Element	60-7
Replacing Radial Seal Air Cleaner	
Filter Element	60-9
Cleaning the Exhaust Filter	60-10
Replacing Fan Belt	60-10
Checking Fuses	60-11
Checking Electrical Wiring And Connections	60-11
Checking Air Compressors	60-11

Troubleshooting

General Troubleshooting Information	65-1
Diagnostic Trouble Codes (DTCs) - Listing.	
Diagnostic Trouble Codes (DTCs) —	
Operation	65-3
Intermittent Fault Diagnostics	65-4
Engine Troubleshooting	65-5
Precautions for Electrical System	
When Steam Cleaning Engine	65-16
Engine Wiring Harness Layout	65-17
Precautions for Welding	65-22
2.9 L Wiring Diagram 1	65-23
2.9 L Wiring Diagram 2	65-25
2.9 L Wiring Diagram 3	65-26
2.9 L Wiring Diagram 4	65-27
2.9 L Wiring Diagram 5	65-30
2.9 L Wiring Diagram 6	
2.9 L Wiring Diagram 7	65-34
2.9 L Wiring Diagram 8	65-35
2.9 L Wiring Diagram 9	65-37

Continued on next page

Page

Storage

Engine Storage Guidelines	.70-1
Preparing Engine for Long-Term Storage	.70-1
Removing Engine from Long-Term Storage	.70-2

Specifications

General OEM Engine Specifications	75-1
Engine Power Ratings And Fuel	
System Specifications	75-2
Engine Crankcase Oil Fill Quantities	75-2
Unified Inch Bolt and Screw Torque Values	
Metric Bolt and Screw Torque Values	75-4

Lubrication and Maintenance Records

Using Lubrication and Maintenance Records	80-1
Daily (Prestarting) Service	80-1
250 Hours or 12 Months Service	80-1
500 Hours or 12 Months Service	80-2
1200 Hours	80-2
1500 Hours or 24 Months Service	80-3
6000 Hours or 72 Months Service	80-3
Service As Required	80-4

Warranty

John Deere Warranty in OEM Applications85-1 Emissions Control System Certification Label....85-4 EPA Non-road Emissions Control

Warranty Statement—Compression Ignition .. 85-5 CARB Non-road Emissions Control

Warranty Statement—Compression Ignition .. 85-7

Record Engine Serial Number

Each engine has a 13-digit John Deere engine serial number. The first two digits identify the factory that produced the engine:

• "CD" = Saran, France

The engine serial number plate (C) is located on the right-hand side of cylinder block.

Record all of the numbers and letters found on your engine serial number plate in the spaces provided below.

This information is very important for repair parts or warranty information. Use all 13 digits when providing engine serial number.

Engine Serial Number (A)

Engine Model Number (B)


NOTE: On engine serial number (A) the seventh digit shows the emission level as follows:

• "U" for Final Tier 4/Stage IV

A—Engine Serial Number B—Engine Model Number C—Serial Number Plate



Engine Serial Number Plate




Engine Serial Number Plate Location

ZE59858,0000049 -19-17JUL14-1/1

Record Keeping

Engine Option Codes



Engine Option Codes

A—Engine Base Code

In addition to the serial number plate, OEM engines have an engine option code label affixed to the rocker arm cover. These codes indicate which of the engine options were installed on your engine at the factory. When in need of parts or service, furnish your authorized servicing dealer or engine distributor with these numbers.

The engine option code label includes an engine base code (A). This base code must also be recorded along with the option codes.

The first two digits of each code identify a specific group, such as alternators. The last two digits of each code identify one specific option provided on your engine, such as a 12-volt, 55-amp alternator.

NOTE: These option codes are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice. If an engine is ordered without a particular component, the last two digits of that functional group option code will be 99, 00, or XX. The list on the next page shows only the first two digits of the code numbers. For future reference such as ordering repair parts, it is important to have these code numbers available. To ensure this availability, enter the third and fourth digits shown on your engine option code label in the spaces provided on the following page.

NOTE: Your engine option code label may not contain all option codes if an option has been added after the engine left the producing factory.

> If option code label is lost or destroyed, consult your servicing dealer or engine distributor selling the engine for a replacement.

Option Codes	Description	Option Codes	Description
11	Rocker Arm Cover	49	Rocker Arm Assembly
12	Oil Fill Inlet	50	Oil Pump
13	Crankshaft Pulley/Damper	51	Cylinder Head With Valves
14	Flywheel Housing	52	Auxiliary Gear Drive
15	Flywheel	53	Fuel Heater
16	High-Pressure Fuel Pump	54	Turbocharger Air Inlet
17	Air Inlet	55	Shipping Stand
19	Oil Pan	56	Paint
20	Coolant Pump	57	Coolant Pump Inlet
21	Thermostat Cover	59	Oil Cooler and Filter
22	Thermostat	60	Add-on Auxiliary Drive Pulley
23	Fan Drive	61	Aftertreatment
24	Fan Belt	62	Alternator Mounting Bracket
26	Engine Coolant Heater	63	Low Pressure Fuel Line
28	Exhaust Manifold	64	Exhaust Elbow
29	Crankcase Ventilation System	65	Turbocharger
30	Starter Motor	67	 Electronic Sensors (Base Engine)
31	Alternator	69	Engine Serial Number Plate
33	Aftertreatment Temperature Sensors	7A	ECU Electronic Software Option
35	Fuel Filters	74	Air Conditioning Refrigerant Compressor

Continued on next page

ZE59858,000004A -19-15SEP14-1/2

Option Codes	Description	Option Codes	Description
36	Front Plate	76	Switches and Sensors
37	Fuel Transfer Pump	78	Air Compressor
39	Thermostat Housing	83	Electronic Software (Vehicle Option)
40	Oil Dipstick	84	Electrical Wiring Harness
41	Belt-Driven Front Auxiliary Drive	86	Fan Pulley
43	Starting Aid	87	Belt Tensioner
44	Timing Gear Cover	89	Exhaust Gas Recirculating (EGR) System
45	Balancer Shafts	90	Software
46	Cylinder Block With Liners and Camshaft	91	— Wiring Harness Kit/Engine Installation Kit
47	Crankshaft and Bearings	93	Emission Label
48	Connecting Rods and Pistons	98	Shipping (Engine Hanger Straps)
Engine Base Cod	e		

ZE59858,000004A -19-15SEP14-2/2


Record Aftertreatment Serial Numbers

Record the numbers from your aftertreatment device as shown on DPF (A) (B) and DOC (C) (D) serial number plates. Having these numbers recorded and kept in a safe location can aid in part ordering and assist in locating stolen items in case of theft.

DPF Part Number._____
DPF Serial Number._____
DOC Part Number._____
DOC Serial Number._____

A—Diesel Particulate Filter Part Number B—Diesel Particulate Filter

- Serial Number
- C—Diesel Oxidation Catalyst Part Number D—Diesel Oxidation Catalyst Serial Number



Serial Number Plates for Aftertreatment

ZE59858,0000293 -19-14NOV13-1/1

Record High-Pressure Fuel Pump Model Number


Record the high-pressure fuel pump model and serial number information found on the serial number plate (A).

Model No._

Manufacturer's No.____

Serial No.

A—Serial Number Plate



ZE59858,0000294 -19-04SEP14-1/1


Record Engine Control Unit (ECU) Serial Number

Record the part number and serial number information found on the serial number label (A) on the Engine Control Unit (ECU) mounted on or near the engine.

Part No.___

Serial No.___

A—Serial Number Label



Understand Signal Words

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

A DANGER

A WARNING




DX,SIGNAL -19-03MAR93-1/1

Recognize Safety Information

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.




DX,ALERT -19-29SEP98-1/1

Replace Safety Signs

Replace missing or damaged safety signs. Use this operator's manual for correct safety sign placement.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.




Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.



If you do not understand any part of this manual and need assistance, contact your John Deere dealer.

DX,READ -19-16JUN09-1/1

California Proposition 65 Warning

Diesel engine exhaust, some of its constituents, along with certain machine components contain or emit chemicals known to the State of California to cause cancer and birth


defects or other reproductive harm. In addition, certain fluids contained in the machine and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

RG41061,000001F -19-12JAN10-1/1

Exhaust Filter Cleaning

Servicing machine or attachments during exhaust filter cleaning can result in serious personal injury. Avoid exposure and skin contact with hot exhaust gases and components.

During auto or manual/stationary exhaust filter cleaning operations, the engine will run at elevated idle and hot temperatures for an extended period of time. Exhaust gases and exhaust filter components reach temperatures hot enough to burn people, or ignite, or melt common materials.




DX,FILTER -19-20JAN10-1/1

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



Dispose of Waste Properly

Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.


Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.

Prevent Machine Runaway

Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

NEVER start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park.





Practice Safe Maintenance

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.

Work in Clean Area


Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.

032715

PN=20








```
DX,SERV -19-17FEB99-1/1
```

Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




DX,WEAR2 -19-03MAR93-1/1

Service Machines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



DX,LOOSE -19-04JUN90-1/1


Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.




Support Machine Properly

Always lower the attachment or implement to the ground before you work on the machine. If the work requires that the machine or attachment be lifted, provide secure support for them. If left in a raised position, hydraulically supported devices can settle or leak down.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

When implements or attachments are used with a machine, always follow safety precautions listed in the implement or attachment operator's manual.




DX,LOWER -19-24FEB00-1/1

Use Proper Lifting Equipment

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.




DX,LIFT -19-04JUN90-1/1

Protect Against Noise

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



Illuminate Work Area Safely

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




DX,LIGHT -19-04JUN90-1/1

Install All Guards

Rotating cooling system fans, belts, pulleys, and drives can cause serious injury.

Keep all guards in place at all times during engine operation.

Wear close-fitting clothes. Stop the engine and be sure fans, belts, pulleys, and drives are stopped before making adjustments, connections, or cleaning near fans and their drive components.



DX,GUARDS -19-18AUG09-1/1

Stay Clear of Rotating Drivelines

Entanglement in rotating driveline can cause serious injury or death.

Keep all shields in place at all times. Make sure rotating shields turn freely.

Wear close-fitting clothing. Stop the engine and be sure that all rotating parts and drivelines are stopped before making adjustments, connections, or performing any type of service on engine or machine driven equipment.



Protect Against High Pressure Spray


Spray from high pressure nozzles can penetrate the skin and cause serious injury. Keep spray from contacting hands or body.

If an accident occurs, see a doctor immediately. Any high pressure spray injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.


Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



DX,SPRAY -19-16APR92-1/1



DX,RCAP -19-04JUN90-1/1

S281

Remove Paint Before Welding or Heating


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 100 mm (4 in.) from area to be affected by heating. If paint cannot be removed, wear an approved respirator before heating or welding.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.




Dispose of paint and solvent properly.

DX,PAINT -19-24JUL02-1/1

Do Not Open High-Pressure Fuel System

High-pressure fluid remaining in fuel lines can cause serious injury. Do not disconnect or attempt repair of fuel lines, sensors, or any other components between the high-pressure fuel pump and nozzles on engines with High Pressure Common Rail (HPCR) fuel system.

Only technicians familiar with this type of system can perform repairs. (See your John Deere dealer.)



DX,WW,HPCR1 -19-07JAN03-1/1

Avoid High-Pressure Fluids

Inspect hydraulic hoses periodically – at least once per year – for leakage, kinking, cuts, cracks, abrasion, blisters, corrosion, exposed wire braid or any other signs of wear or damage.

Replace worn or damaged hose assemblies immediately with John Deere approved replacement parts.

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.


If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar

Avoid Heating Near Pressurized Fluid Lines

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can accidentally burst when heat goes beyond the immediate flame area.



with this type of injury should reference a knowledgeable medical source. Such information is available in English from Deere & Company Medical Department in Moline, Illinois, U.S.A., by calling 1-800-822-8262 or +1 309-748-5636.





DX,TORCH -19-10DEC04-1/1


Avoid Static Electricity Risk When Refueling

The removal of sulfur and other compounds in Ultra-Low Sulfur Diesel (ULSD) fuel decreases its conductivity and increases its ability to store a static charge.

Refineries may have treated the fuel with a static dissipating additive. However, there are many factors that can reduce the effectiveness of the additive over time.

Static charges can build up in ULSD fuel while it is flowing through fuel delivery systems. Static electricity discharge when combustible vapors are present could result in a fire or explosion.

Therefore, it is important to ensure that the entire system used to refuel your machine (fuel supply tank, transfer pump, transfer hose, nozzle, and others) is properly grounded and bonded. Consult with your fuel or fuel system supplier to ensure that the delivery system is in compliance with fueling standards for proper grounding and bonding practices.



DX,FUEL,STATIC,ELEC -19-12JUL13-1/1

Handle Fuel Safely—Avoid Fires


Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.

Use only an approved fuel container for transporting flammable liquids.

Never fill fuel container in pickup truck with plastic bed liner. Always place fuel container on ground before refueling. Touch fuel container with fuel dispenser nozzle before removing can lid. Keep fuel dispenser nozzle in contact with fuel container inlet when filling.




Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93-1/1

Handle Starting Fluid Safely

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.

Do not use starting fluid on an engine equipped with glow plugs or an air intake heater.



DX,FIRE3 -19-14MAR14-1/1

Handling Batteries Safely

Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded (-) battery clamp first and replace grounded clamp last.

Sulfuric acid in battery electrolyte is poisonous and strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid hazards by:

- Filling batteries in a well-ventilated area
- Wearing eye protection and rubber gloves
- Avoiding use of air pressure to clean batteries
- Avoiding breathing fumes when electrolyte is added
- Avoiding spilling or dripping electrolyte
- Using correct battery booster or charger procedure.


If acid is spilled on skin or in eyes:

- 1. Flush skin with water.
- 2. Apply baking soda or lime to help neutralize the acid.
- 3. Flush eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

- 1. Do not induce vomiting.
- 2. Drink large amounts of water or milk, but do not exceed 2 L (2 qt.).
- 3. Get medical attention immediately.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**



DX,WW,BATTERIES -19-02DEC10-1/1

Prevent Acid Burns

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


- 1. Filling batteries in a well-ventilated area.
- 2. Wearing eye protection and rubber gloves.
- 3. Avoiding breathing fumes when electrolyte is added.
- 4. Avoiding spilling or dripping electrolyte.
- 5. Use proper jump start procedure.

If you spill acid on yourself:

- 1. Flush your skin with water.
- 2. Apply baking soda or lime to help neutralize the acid.
- 3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

- 1. Do not induce vomiting.
- 2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
- 3. Get medical attention immediately.




Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to $16^{\circ}C$ ($60^{\circ}F$).





Diesel Fuel

Consult your local fuel distributor for properties of the diesel fuel available in your area.

In general, diesel fuels are blended to satisfy the low temperature requirements of the geographical area in which they are marketed.

Diesel fuels specified to EN 590 or ASTM D975 are recommended. Renewable diesel fuel produced by hydrotreating animal fats and vegetable oils is basically identical to petroleum diesel fuel. Renewable diesel that meets EN 590 or ASTM D975 is acceptable for use at all percentage mixture levels.

Required Fuel Properties

In all cases, the fuel shall meet the following properties:

Cetane number of 40 minimum. Cetane number greater than 47 is preferred, especially for temperatures below -20 °C (-4 °F) or elevations above 1675 m (5500 ft.).

Cold Filter Plugging Point (CFPP) should be at least 5 °C (9 °F) below the expected lowest temperature or **Cloud Point** below the expected lowest ambient temperature.

Fuel lubricity should pass a maximum scar diameter of 0.52 mm as measured by ASTM D6079 or ISO 12156-1. A maximum scar diameter of 0.45 mm is preferred.

Diesel fuel quality and sulfur content must comply with all existing emissions regulations for the area in which the engine operates. DO NOT use diesel fuel with sulfur content greater than 10 000 mg/kg (10 000 ppm).

Sulfur content for Interim Tier 4, Final Tier 4, Stage III B, and Stage IV Engines

• Use ONLY ultra low sulfur diesel (ULSD) fuel with a maximum of 15 mg/kg (15 ppm) sulfur content.

Sulfur Content for Tier 3 and Stage III A Engines

- Use of diesel fuel with sulfur content less than 1000 mg/kg (1000 ppm) is RECOMMENDED.
- Use of diesel fuel with sulfur content 1000—2000 mg/kg (1000—2000 ppm) REDUCES the oil and filter change interval.
- BEFORE using diesel fuel with sulfur content greater than 2000 mg/kg (2000 ppm), contact your John Deere dealer.

Sulfur Content for Tier 2 and Stage II Engines

- Use of diesel fuel with sulfur content less than 2000 mg/kg (2000 ppm) is RECOMMENDED.
- Use of diesel fuel with sulfur content 2000—5000 mg/kg (2000—5000 ppm) REDUCES the oil and filter change interval.
- BEFORE using diesel fuel with sulfur content greater than 5000 mg/kg (5000 ppm), contact your John Deere dealer.

Sulfur Content for Other Engines

- Use of diesel fuel with sulfur content less than 5000 mg/kg (5000 ppm) is RECOMMENDED.
- Use of diesel fuel with sulfur content greater than 5000 mg/kg (5000 ppm) REDUCES the oil and filter change interval.

IMPORTANT: Do not mix used diesel engine oil or any other type of lubricating oil with diesel fuel.

Improper fuel additive usage may cause damage on fuel injection equipment of diesel engines.

DX,FUEL1 -19-24OCT14-1/1

Supplemental Diesel Fuel Additives

Diesel fuel can be the source of performance or other operational problems for many reasons. Some causes include poor lubricity, contaminants, low cetane number, and a variety of properties that cause fuel system deposits. These and others are referenced in other sections of this Operator's Manual.

To optimize engine performance and reliability, closely follow recommendations on fuel quality, storage, and handling, which are found elsewhere in this Operator's Manual. To further aid in maintaining performance and reliability of the engine's fuel system, John Deere has developed a family of fuel additive products for most global markets. The primary products include Fuel-Protect Diesel Fuel Conditioner (full feature conditioner in winter and summer formulas) and Fuel-Protect Keep Clean (fuel injector deposit removal and prevention). Availability of these and other products varies by market. See your local John Deere dealer for availability and additional information about fuel additives that might be right for your needs.

DX,FUEL13 -19-07FEB14-1/1

Lubricity of Diesel Fuel

Most diesel fuels manufactured in the United States, Canada, and the European Union have adequate lubricity to ensure proper operation and durability of fuel injection system components. However, diesel fuels manufactured in some areas of the world may lack the necessary lubricity.

IMPORTANT: Make sure the diesel fuel used in your machine demonstrates good lubricity characteristics.

Fuel lubricity should pass a maximum scar diameter of 0.52 mm as measured by ASTM D6079 or ISO 12156-1. A maximum scar diameter of 0.45 mm is preferred.

If fuel of low or unknown lubricity is used, add John Deere Fuel-Protect Diesel Fuel Conditioner (or equivalent) at the specified concentration.

Lubricity of BioDiesel Fuel

Fuel lubricity can improve significantly with BioDiesel blends up to B20 (20% BioDiesel). Further increase in lubricity is limited for BioDiesel blends greater than B20.

DX,FUEL5 -19-07FEB14-1/1

Handling and Storing Diesel Fuel

CAUTION: Reduce the risk of fire. Handle fuel carefully. DO NOT fill the fuel tank when engine is running. DO NOT smoke while you fill the fuel tank or service the fuel system.

Fill the fuel tank at the end of each day's operation to prevent water condensation and freezing during cold weather.

Keep all storage tanks as full as practicable to minimize condensation.

Ensure that all fuel tank caps and covers are installed properly to prevent moisture from entering. Monitor water content of the fuel regularly. When using BioDiesel fuel, the fuel filter may require more frequent replacement due to premature plugging.

Check engine oil level daily prior to starting engine. A rising oil level may indicate fuel dilution of the engine oil.

IMPORTANT: The fuel tank is vented through the filler cap. If a new filler cap is required, always replace it with an original vented cap.

When fuel is stored for an extended period or if there is a slow turnover of fuel, add a fuel conditioner to stabilize the fuel and prevent water condensation. Contact your fuel supplier or John Deere dealer for recommendations.

DX,FUEL4 -19-15FEB13-1/1

BioDiesel Fuel

BioDiesel fuel is comprised of mono-alkyl esters of long chain fatty acids derived from vegetable oils or animal fats. BioDiesel blends are BioDiesel mixed with petroleum diesel fuel on a volume basis.

Before using fuel containing BioDiesel, review the BioDiesel Use Requirements and Recommendations in this Operator's Manual.

Environmental laws and regulations can encourage or prohibit the use of biofuels. Operators should consult with appropriate governmental authorities prior to using biofuels.

All John Deere Engines with Exhaust Filter (Released 2011 and After)

While 5% blends (B5) are preferred, BioDiesel concentrations up to a 20% blend (B20) in petroleum diesel fuel can be used. BioDiesel blends up to B20 can be used ONLY if the BioDiesel (100% BioDiesel or B100) meets ASTM D6751, EN 14214, or equivalent specification. Expect a 2% reduction in power and a 3% reduction in fuel economy when using B20.

BioDiesel concentrations above B20 can harm the engine's emission control systems and should not be used. Risks include, but are not limited to, more frequent stationary regeneration, soot accumulation, and increased intervals for ash removal.

John Deere approved fuel conditioners, which contain detergent and dispersant additives, are required when using BioDiesel blends from B10—B20, and are recommended when using lower BioDiesel blends.

All John Deere Engines Excluding Exhaust Filter (Primarily Released Prior to 2012)

While 5% blends (B5) are preferred, BioDiesel concentrations up to a 20% blend (B20) in petroleum diesel fuel can be used. BioDiesel blends up to B20 can be used ONLY if the BioDiesel (100% BioDiesel or B100) meets ASTM D6751, EN 14214, or equivalent specification. Expect a 2% reduction in power and a 3% reduction in fuel economy when using B20.

These John Deere engines can operate on BioDiesel blends above B20 (up to 100% BioDiesel). Operate at levels above B20 ONLY if the BioDiesel is permitted by law and meets the EN 14214 specification (primarily available in Europe). Engines operating on BioDiesel blends above B20 might not fully comply with or be permitted by all applicable emissions regulations. Expect up to a 12% reduction in power and an 18% reduction in fuel economy when using 100% BioDiesel.

John Deere approved fuel conditioners, which contain detergent and dispersant additives, are required when using BioDiesel blends from B10—B20, and are recommended when using lower BioDiesel blends.

BioDiesel Use Requirements and Recommendations

The petroleum diesel portion of all BioDiesel blends must meet the requirements of ASTM D975 (US) or EN 590 (EU) commercial standard.

BioDiesel users in the U.S. are strongly encouraged to purchase BioDiesel blends from a BQ-9000 Certified Marketer and sourced from a BQ-9000 Accredited Producer (as certified by the National BioDiesel Board). Certified Marketers and Accredited Producers can be found at the following website: <u>http://www.bq9000.org</u>.

BioDiesel contains residual ash. Ash levels exceeding the maximums allowed in either ASTM D6751 or EN14214 can result in more rapid ash loading and require more frequent cleaning of the Exhaust Filter (if present).

The fuel filter can require more frequent replacement, when using BioDiesel fuel, particularly if switching from diesel. Check engine oil level daily prior to starting engine. A rising oil level can indicate fuel dilution of the engine oil. BioDiesel blends up to B20 must be used within 90 days of the date of BioDiesel manufacture. BioDiesel blends above B20 must be used within 45 days from the date of BioDiesel manufacture.

When using BioDiesel blends up to B20, the following must be considered:

- Cold-weather flow degradation
- Stability and storage issues (moisture absorption, microbial growth)
- Possible filter restriction and plugging (usually a problem when first switching to BioDiesel on used engines)
- Possible fuel leakage through seals and hoses (primarily an issue with older engines)
- Possible reduction of service life of engine components

Request a certificate of analysis from your fuel distributor to ensure that the fuel is compliant with the specifications provided in this Operator's Manual.

Consult your John Deere dealer for approved fuel conditioners to improve storage and performance with BioDiesel fuels.

The following must also be considered if using BioDiesel blends above B20:

- Possible coking or blocked injector nozzles, resulting in power loss and engine misfire if John Deere approved fuel conditioners are not used
- Possible crankcase oil dilution (requiring more frequent oil changes)
- Possible lacquering or seizure of internal components
- Possible formation of sludge and sediments
- Possible thermal oxidation of fuel at elevated temperatures
- Possible compatibility issues with other materials (including copper, lead, zinc, tin, brass, and bronze) used in fuel handling equipment

Continued on next page

DX,FUEL7 -19-15MAY13-1/2

- Possible reduction in water separator efficiency
- Possible damage to paint if exposed to BioDiesel
- Possible corrosion of fuel injection equipment
- Possible elastomeric seal and gasket material degradation (primarily an issue with older engines)
- Possible high acid levels within fuel system
- Because BioDiesel blends above B20 contain more ash, using blends above B20 can result in more rapid

ash loading and require more frequent cleaning of the Exhaust Filter (if present)

IMPORTANT: Raw pressed vegetable oils are NOT acceptable for use as fuel in any concentration in John Deere engines. Their use could cause engine failure.

DX,FUEL7 -19-15MAY13-2/2

Testing Diesel Fuel

A fuel analysis program can help to monitor the quality of diesel fuel. The fuel analysis can provide critical data such as cetane number, fuel type, sulfur content, water content, appearance, suitability for cold weather operations, bacteria, cloud point, acid number, particulate contamination, and whether the fuel meets specification.

Contact your John Deere dealer for more information on diesel fuel analysis.

DX,FUEL6 -19-14APR11-1/1

Fuel Filters

The importance of fuel filtration cannot be overemphasized with modern fuel systems. The combination of increasingly restrictive emission regulations and more efficient engines requires fuel system to operate at much higher pressures. Higher pressures can only be achieved using fuel injection components with very close tolerances. These close manufacturing tolerances have significantly reduced capacities for debris and water.

John Deere brand fuel filters have been designed and produced specifically for John Deere engines.

To protect the engine from debris and water, always change engine fuel filters as specified in this manual.

DX,FILT2 -19-14APR11-1/1

Minimizing the Effect of Cold Weather on Diesel Engines

John Deere diesel engines are designed to operate effectively in cold weather.

However, for effective starting and cold-weather operation, a little extra care is necessary. The following information outlines steps that can minimize the effect that cold weather may have on starting and operation of your engine. See your John Deere dealer for additional information and local availability of cold-weather aids.

Use Winter Grade Fuel

When temperatures fall below 0 °C (32 °F), winter grade fuel (No. 1-D in North America) is best suited for cold-weather operation. Winter grade fuel has a lower cloud point and a lower pour point.

Cloud point is the temperature at which wax begins to form in the fuel. This wax causes fuel filters to plug. **Pour point** is the lowest temperature at which movement of the fuel is observed.

NOTE: On average, winter grade diesel fuel has a lower Btu (heat content) rating. Using winter grade fuel may reduce power and fuel efficiency, but should not cause any other engine performance effects. Check the grade of fuel being used before troubleshooting for low-power complaints in cold-weather operation.

Air Intake Heater

An air intake heater is an available option for some engines to aid cold weather starting.

Ether

An ether port on the intake is available to aid cold weather starting.

CAUTION: Ether is highly flammable. Do not use ether when starting an engine equipped with glow plugs or an air intake heater.

Coolant Heater

An engine block heater (coolant heater) is an available option to aid cold weather starting.

Seasonal Viscosity Oil and Proper Coolant Concentration

Use seasonal grade viscosity engine oil based on the expected air temperature range between oil changes and a proper concentration of low silicate antifreeze as recommended. (See DIESEL ENGINE OIL and ENGINE COOLANT requirements in this section.)

Diesel Fuel Flow Additive

Use John Deere Fuel-Protect Diesel Fuel Conditioner (winter formula), which contains anti-gel chemistry, or equivalent fuel conditioner to treat non-winter grade fuel (No. 2-D in North America) during the cold-weather season. This generally extends operability to about 10 °C (18 °F) below the fuel cloud point. For operability at even lower temperatures, use winter grade fuel.

IMPORTANT: Treat fuel when outside temperature drops below 0 °C (32 °F). For best results, use with untreated fuel. Follow all recommended instructions on label.

BioDiesel

When operating with BioDiesel blends, wax formation can occur at warmer temperatures. Begin using John Deere Fuel-Protect Diesel Fuel Conditioner (winter formula) at 5 °C (41 °F) to treat BioDiesel fuels during the cold-weather season. Use B5 or lower blends at temperatures below 0 °C (32 °F). Use only winter grade petroleum diesel fuel at temperatures below -10 °C (14 °F).

Winterfronts

Use of fabric, cardboard, or solid winterfronts is not recommended with any John Deere engine. Their use can result in excessive engine coolant, oil, and charge air temperatures. This can lead to reduced engine life, loss of power and poor fuel economy. Winterfronts may also put abnormal stress on fan and fan drive components potentially causing premature failures.

If winterfronts are used, they should never totally close off the grill frontal area. Approximately 25% area in the center of the grill should remain open at all times. At no time should the air blockage device be applied directly to the radiator core.

Radiator Shutters

If equipped with a thermostatically controlled radiator shutter system, this system should be regulated in such a way that the shutters are completely open by the time the coolant reaches 93 $^{\circ}$ C (200 $^{\circ}$ F) to prevent excessive intake manifold temperatures. Manually controlled systems are not recommended.

If air-to-air aftercooling is used, the shutters must be completely open by the time the intake manifold air temperature reaches the maximum allowable temperature out of the charge air cooler.

For more information, see your John Deere dealer.

DX,FUEL10 -19-15MAY13-1/1

John Deere Break-In Plus™ Engine Oil — Interim Tier 4, Final Tier 4, Stage IIIB, and Stage IV

New engines are filled at the factory with John Deere Break-In Plus™ Engine Oil. During the break-in period, add John Deere Break-In Plus™ Engine Oil, as needed to maintain the specified oil level.

Operate the engine under various conditions, particularly heavy loads with minimal idling, to help seat engine components properly.

During the initial operation of a new or rebuilt engine, change the oil and filter between a minimum of 100 hours and maximum equal to the interval specified for John Deere Plus-50[™] II oil.

After engine overhaul, fill the engine with John Deere Break-In Plus™ Engine Oil.

If John Deere Break-In Plus[™] Engine Oil is not available, use an SAE 10W-30 viscosity grade diesel engine oil meeting one of the following:

Break-In Plus is a trademark of Deere & Company Plus-50 is a trademark of Deere & Company.

- API Service Category CJ-4
- ACEA Oil Sequence E9
- ACEA Oil Sequence E6

If one of these oils is used during the initial operation of a new or rebuilt engine, change the oil and filter between a minimum of 100 hours and a maximum of 250 hours.

IMPORTANT: Do not use any other engine oils during the initial break-in of a new or rebuilt engine.

John Deere Break-In Plus[™] Engine Oil can be used for all John Deere diesel engines at all emission certification levels.

After the break-in period, use John Deere Plus-50[™] II or other diesel engine oil as recommended in this manual.

DX,ENOIL16 -19-15JUN10-1/1

Diesel Engine Oil — Interim Tier 4, Final Tier 4, Stage IIIB, and Stage IV

Use oil viscosity based on the expected air temperature range during the period between oil changes.

John Deere Plus-50^m II is the recommended engine oil.

Extended service intervals may apply when John Deere Plus-50[™] II engine oil is used. Refer to the engine oil drain interval table and consult your John Deere dealer for more information.

If John Deere Plus-50[™] II engine oil is not available, engine oil meeting one or more of the following may be used:

- API Service Category CJ-4
- ACEA Oil Sequence E9
- ACEA Oil Sequence E6


DO NOT use engine oil containing more than 1.0% sulfated ash, 0.12% phosphorus, or 0.4% sulfur.

Multi-viscosity diesel engine oils are preferred.

Diesel fuel quality and fuel sulfur content must comply with all existing emissions regulations for the area in which the engine operates.

IMPORTANT: Use only ultra low sulfur diesel (ULSD) fuel with a maximum sulfur content of 15 mg/kg (15 ppm).

Plus-50 is a trademark of Deere & Company



DX,ENOIL14 -19-15JUN10-1/1

Engine Oil and Filter Service Intervals — Interim Tier 4, Final Tier 4, Stage IIIB, and Stage IV — OEM Applications

Recommended oil and filter service intervals are based on a combination of oil pan capacity, type of engine oil and filter used, and sulfur content of the diesel fuel. Actual service intervals also depend on operation and maintenance practices.

Use oil analysis to evaluate the condition of the oil and to aid in selection of the proper oil and filter service interval. Contact your John Deere dealer for more information on engine oil analysis.

Change the oil and oil filter at least once every 12 months even if the hours of operation are fewer than the otherwise recommended service interval.

Diesel fuel sulfur content affects engine oil and filter service intervals. Higher fuel sulfur levels reduce oil and filter service intervals.

Use of diesel fuel with sulfur content less than 15 mg/kg (15 ppm) is REQUIRED.

IMPORTANT: To avoid engine damage:

- Reduce oil and filter service intervals by 50% when using BioDiesel blends greater than B20. Oil analysis may allow longer service interval.
 Use only approved oil types.
- Use only approved on types.

Plus-50 is a trademark of Deere & Company

Approved Oil Types

- John Deere Plus-50™ II
- "Other Oils" include API CJ-4, ACEA E9, and ACEA E6.

NOTE: The 500 hour extended oil and filter change interval is only allowed if all of the following conditions are met:

- Engine equipped with an extended drain interval oil pan
- Use of diesel fuel with sulfur content less than 15 mg/kg (15 ppm)
- Use of John Deere Plus-50™ II oil
- Use of an approved John Deere oil filter

	Oil Pan Size (L/kW)		
	Greater than or equal to 0.10	Greater than or equal to 0.12	
John Deere Plus-50™ II	375 hours	500 hours	
Other Oils	250 hours	250 hours	
Other Oils250 hours250 hoursOil analysis may extend the service interval of "Other Oils" to a maximum not to exceed the interval of Plus-50™ II oils.			

DX,ENOIL15,IT4,OEM -19-07FEB14-1/1

Diesel Engine Oil and Filter Service Intervals

The oil and filter service intervals in the following table should be used as guidelines. Actual service intervals also depend on operation and maintenance practices. It is suggested to use oil analysis to determine the actual useful life of the oil and to aid in selection of the proper oil and filter service interval. Change the oil and filter at least once every 12 months even if the hours of operation are fewer than the otherwise recommended service interval. Oil and filter service intervals are based on a combination of oil pan capacity and the type of engine oil and filter used.

Diesel fuel sulfur level will affect engine oil and filter service intervals.

Use of diesel fuel with sulfur content less than 0.0015% (or 15 ppm) (or 15 mg/kg) maximum limit is required.

IMPORTANT: To avoid engine damage:

• Reduce oil and filter service intervals by 50% when using biodiesel blends greater than B20. Oil analysis may allow longer service intervals.

• Use only approved oil types.

Approved Oil Types

- John Deere Plus-50™ II
- "Other Oils" include oils meeting API CJ-4, ACEA E9, or ACEA E6.

Use of other specification oils in Final Tier 4/Stage IV engines can result in premature failure.

NOTE: The 500 hour extended oil and filter change interval is only allowed if all the following conditions are met:

- Engine equipped with an extended drain interval oil pan
- Use of diesel fuel with sulfur content less than 0.0015% (15 ppm) (15 mg/kg) maximum limit
- Use of John Deere Plus-50™ II oil
- Use of an approved John Deere oil filter

		Oil Pan Option Codes	
Power Rating	Fuel Sulfur Content	19GN 8.5 L	
kW (hp)		Other Oils	John Deere Plus-50 II
36 (48)	≤15 ppm	250 hours	500 hours
48 (64)	≤15 ppm	250 hours	500 hours
55 (74)	≤15 ppm	250 hours	500 hours

Plus-50 is a trademark of Deere & Company

ZE59858,000004B -19-28JUL14-1/1

Mixing of Lubricants

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements.

Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance. Consult your John Deere dealer to obtain specific information and recommendations.

DX,LUBMIX -19-18MAR96-1/1

Alternative and Synthetic Lubricants

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual.

Some John Deere brand coolants and lubricants may not be available in your location.

Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to both conventional and synthetic lubricants.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-11APR11-1/1

Lubricant	Storage
-----------	---------

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation. Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-11APR11-1/1

Oil Filters

Filtration of oils is critically important for proper operation and lubrication. John Deere brand oil filters have been designed and produced specifically for John Deere applications.

John Deere filters adhere to engineering specifications for quality of the filter media, filter efficiency rating, strength

of the bond between the filter media and the element end cap, fatigue life of the canister (if applicable), and pressure capability of the filter seal. Non-John Deere branded oil filters might not meet these key John Deere specifications.

Always change oil filters regularly as specified in this manual.

DX, FILT1 -19-11APR11-1/1

Diesel Engine Coolant (engine with wet sleeve cylinder liners)

Preferred Coolants

The following pre-mix engine coolants are preferred:

- John Deere COOL-GARD™II
- John Deere COOL-GARD II PG

COOL-GARD II pre-mix coolant is available in several concentrations with different freeze protection limits as shown in the following table.

COOL-GARD II pre-mix	Freeze Protection Limit
COOL-GARD II 20/80	-9 °C (16 °F)
COOL-GARD II 30/70	-16 °C (3 °F)
COOL-GARD II 50/50	-37 °C (-34 °F)
COOL-GARD II 55/45	-45 °C (-49 °F)
COOL-GARD II PG 60/40	-49 °C (-56 °F)
COOL-GARD II 60/40	-52 °C (-62 °F)

Not all COOL-GARD II pre-mix products are available in all countries.

Use COOL-GARD II PG when a non-toxic coolant formulation is required.

Additional Recommended Coolants

The following engine coolant is also recommended:

- John Deere COOL-GARD II Concentrate in a 40—60% mixture of concentrate with quality water.
- IMPORTANT: When mixing coolant concentrate with water, do not use less than 40% or greater than 60% concentration of coolant. Less than 40% gives inadequate additives for corrosion protection. Greater than 60% can result in coolant gelation and cooling system problems.

Other Coolants

Other ethylene glycol or propylene glycol base coolants may be used if they meet the following specification:

• Pre-mix coolant meeting ASTM D6210 requirements

COOL-GARD is a trademark of Deere & Company

• Coolant concentrate meeting ASTM D6210 requirements in a 40—60% mixture of concentrate with quality water

If coolant meeting one of these specifications is unavailable, use a coolant concentrate or pre-mix coolant that has a minimum of the following chemical and physical properties:

- Provides cylinder liner cavitation protection according to either the John Deere Cavitation Test Method or a fleet study run at or above 60% load capacity
- Is formulated with a nitrite-free additive package
- Protects the cooling system metals (cast iron, aluminum alloys, and copper alloys such as brass) from corrosion

Water Quality

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol and propylene glycol base engine coolant concentrate.

Coolant Drain Intervals

Drain and flush the cooling system and refill with fresh coolant at the indicated interval, which varies with the coolant used.

When COOL-GARD II or COOL-GARD II PG is used, the drain interval is 6 years or 6000 hours of operation.

If a coolant other than COOL-GARD II or COOL-GARD II PG is used, reduce the drain interval to 2 years or 2000 hours of operation.

IMPORTANT: Do not use cooling system sealing additives or antifreeze that contains sealing additives.

Do not mix ethylene glycol and propylene glycol base coolants.

Do not use coolants that contain nitrites.

DX,COOL3 -19-15MAY13-1/1

Water Quality for Mixing with Coolant Concentrate

Engine coolants are a combination of three chemical components: ethylene glycol (EG) or propylene glycol (PG) antifreeze, inhibiting coolant additives, and quality water.

Water quality is important to the performance of the cooling system. Distilled, deionized, or demineralized water is recommended for mixing with ethylene glycol and propylene glycol base engine coolant concentrate.

All water used in the cooling system should meet the following minimum specifications for quality:

Chlorides	<40 mg/L
Sulfates	<100 mg/L
Total solids	<340 mg/L
Total dissolved I hardness	<170 mg/L
рН	5.5—9.0

IMPORTANT: Do not use bottled drinking water because it often contains higher concentrations of total dissolved solids.

Operating in Warm Temperature Climates

John Deere engines are designed to operate using recommended engine coolants.

Always use a recommended engine coolant, even when operating in geographical areas where freeze protection is not required.

IMPORTANT: Water may be used as coolant *in emergency situations only.*

Freeze Protection

The relative concentrations of glycol and water in the engine coolant determine its freeze protection limit.

Ethylene Glycol	Freeze Protection Limit
40%	-24 °C (-12 °F)
50%	-37 °C (-34 °F)
60%	-52 °C (-62 °F)
Propylene Glycol	Freeze Protection Limit
40%	-21 °C (-6 °F)
50%	-33 °C (-27 °F)
60%	-49 °C (-56 °F)

DO NOT use a coolant-water mixture greater than 60% ethylene glycol or 60% propylene glycol.

DX,COOL19 -19-15MAY13-1/1

Foaming, hot surface aluminum and iron corrosion, scaling, and cavitation occur when water is used as the coolant, even when coolant conditioners are added.

Drain cooling system and refill with recommended engine coolant as soon as possible.

DX,COOL6 -19-15MAY13-1/1

Testing Coolant Freeze Point

The use of a handheld coolant refractometer is the quickest, easiest, and most accurate method to determine coolant freeze point. This method is more accurate than a test strip or a float-type hydrometer which can produce poor results.

A coolant refractometer is available through your John Deere dealer under the SERVICEGARD[™] tool program. Part number 75240 provides an economical solution to accurate freeze point determination in the field.

To use this tool:

- 1. Allow cooling system to cool to ambient temperatures.
- 2. Open radiator cap to expose coolant.
- 3. With the included dropper, collect a small coolant sample.
- 4. Open the lid of the refractometer, place one drop of coolant on the window and close the lid.
- 5. Look through the eyepiece and focus as necessary.
- Record the listed freeze point for the type of coolant (ethylene glycol coolant or propylene glycol) being tested.

SERVICEGARD™ Part Number 75240




Image with a Drop of 50/50 Coolant Placed on the Refractometer Window

SERVICEGARD is a trademark of Deere & Company

DX,COOL,TEST -19-13JUN13-1/1


Disposing of Coolant

Improperly disposing of engine coolant can threaten the environment and ecology.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere engine distributor or servicing dealer.



Instrument Panels

Final Tier 4/Stage IV John Deere PowerTech™ OEM Engines have an electronic control system, which has the following controls and gauges as shown. The following information applies only to those controls and gauges supplied by John Deere. Refer to your engine application manual for specific guidelines if John Deere-sourced controls and instrumentation are not used.

NOTE: This manual only covers operation of engine with a John Deere control system.

Following is a brief description of the available optional electronic controls and gauges found on John Deere provided instrument panels. Refer to manufacturer's literature for information on controls not provided by Deere.

Instrument Panel

A—Diagnostic Gauge/Hour Meter

The diagnostic gauge (A) displays diagnostic trouble codes (DTCs) as they are accessed. Other information on the engine can be accessed using the touch keys (N, O and P). The hour meter feature shows the operating hours of the engine and should be used as a guide for scheduling periodic maintenance. If the diagnostic gauge receives a trouble code from an engine control unit, the current display will switch to a warning or shutdown (depending on the severity of the code) screen that will display the trouble code number, the description of the code and the corrective action needed.

B—Tachometer

The tachometer (B) indicates engine speed in hundreds of revolutions per minute (rpm).

C—Voltmeter (Optional)

The voltmeter (C) indicates system battery voltage. The amber "Warning" light (Q) will illuminate when battery voltage is too low for proper operation of the fuel injection system.

D—Audible Alarm (Optional)


The audible alarm (D) will sound whenever low oil pressure, high coolant temperature, or water-in-fuel conditions exist. This includes all signals that light up the amber "warning" indicator (intermittent alarm) or the red "stop engine" indicator (steady alarm).

E—Audible Alarm Override Button

The optional audible alarm has an override button (E) that silences the audible alarm for approximately two minutes when pressed.

F—Key Start Switch

The three-position key start switch (F) controls the engine electrical system. When the key switch is turned clockwise to "START", the engine will crank. When the engine starts, the key is released and returns to the "ON" (RUN) position.



Full-Featured Instrument Panel

- A—Diagnostic Gauge/Hour
- Meter
- -Tachometer Bc–
- -Voltmeter (Optional) D—Audible Alarm (Optional)
- E—Audible Alarm Override
- Button
- F-Key Switch
- Switch
- -Bump Enable Rocker Switch
- I- Speed Select Rocker Switch

- J-High-Low Speed Select **Rocker Switch**
- K—Analog Throttle Control
- (Optional)
- Oil Pressure Gauge
- **M**—Coolant Temperature Gauge
- N-Menu Key -Override Shutdown Rocker O-Arrow Keys
- P—Enter Key Q—Amber "WARNING" Indicator Light
- **R—Red "STOP ENGINE"** Indicator Light

G—Override Shutdown Rocker Switch

Switch will be present, but may not be active, depending on engine control unit (ECU) options originally selected. If switch is active, pressing the upper half of the override shutdown switch (G) will override an engine shutdown signal. The switch must be pressed within 30 seconds to prevent undesired shutdown of engine. Pressing this switch will override the engine shutdown for 30 seconds at a time to move vehicle to a safe location.

Continued on next page

H—Bump Speed Enable Rocker Switch

This is a three-position switch (H) with the center position as "OFF" (locked). With this switch in the "OFF" position, the speed select switch (I) is also locked, to prevent accidental changes in operating speed. Pressing upper or lower half of switch (H) will unlock or enable the bump speed switch to take effect using speed select switch (I).

I—Speed Select Rocker Switch

The speed select switch (I) is used to bump engine speed up (+) or down (-) in small increments during operation. This switch must be used with the bump speed enable switch (H) in the unlocked position (top or bottom half of button depressed).

J—High-Low Speed Select Rocker Switch

The high-low speed select switch (J) is used to set the engine operating speeds at slow (turtle) or fast (rabbit). Factory preset idle speeds can also be adjusted using bump speed enable switch (H) with speed select switch (I).

The basic instrument panel will have the high-low speed select switch only. Press and hold up (+) or down (-) to adjust engine speed as desired. The engine speed selected will not be held in the memory. To adjust engine speeds, See Changing Engine Speeds in Section 20.

How To Select Preset Operating Speeds (Bump Speeds)

First select Turtle (Slow) or Adj by pressing speed select switch (J) to "Turtle" (slow) or "Adj"(center). Then you can press either the upper or lower portion of the bump speed enable switch (H) to unlock the setting. The bump speed enable must be held down as the speed select switch (J) is used to change the setting by pressing (+) to increase speed or (-) to decrease speed.

Once the slow idle speed has been set, the bump speed enable **switch must be pressed and released three times within two seconds to commit the new operating speed to memory.** If not done, the engine's new speed will only be effective until the key switch is shut off. Then the speed will revert back to the previous setting.

The fast idle speed is not adjustable. It will always go back to the factory preset fast idle speed.

K—Analog Throttle Control (Optional)

PowerTech is a trademark of Deere & Company

The throttle control (K) is used to control engine speed. This control is available only on engines with analog throttle.

L—Engine Oil Pressure Gauge

The oil pressure gauge (L) indicates engine oil pressure. An audible alarm (D) warns the operator if engine oil pressure falls below a safe operating pressure.

M—Engine Coolant Temperature Gauge

The engine coolant temperature gauge (M) indicates engine coolant temperature. An audible alarm (D) warns the operator if coolant temperature rises above the preset safe operating temperature.

N-Menu Key

The menu key is pressed to either enter or exit the menu screens on the diagnostic gauge.

O—Arrow Keys

Use the arrow keys (O) to change the display on the window of the diagnostic gauge and to access engine performance data.

Pressing the left arrow to scroll to the left or upward or the right arrow to scroll to the right or downward. This will allow you to view various engine parameters and any diagnostic trouble codes that occur.

Refer to the following story for accessing engine information on the diagnostic gauge using the touch keys.

P—Enter Key

The enter key is pressed to select the parameter that is highlighted on the screen.

Q—Amber "WARNING" Indicator Light

When light comes on, an abnormal condition exists. It is not necessary to shut down the engine immediately, but the problem should be corrected as soon as possible.

R—Red "STOP ENGINE" Indicator Light

When light comes on, stop engine immediately or as soon as safely possible to prevent engine damage. Correct problem before restarting.

ZE59858,00002D2 -19-15SEP14-2/2

F

Using Diagnostic Gauge to Access Engine Information

The diagnostic gauge (A) allows the operator to view many readouts of engine functions and trouble codes (DTCs). The gauge is linked to the electronic control system and its sensors. This allows the operator to monitor engine functions and to troubleshoot the engine systems when needed.


Press the menu key (B) to access the various engine functions in sequence. The displays can be selected as either customary English or metric units.

The following menu of engine parameters can be displayed on the diagnostic gauge window:

- Intake Temperature
- Air Filter Diff. Pressure
- Battery Potential Voltage
- Fan Drive
- Engine Desired Op Speed
- Machine Hours
- Exhaust System High Temp Lamp
- Exhaust Filter Clean Status
- % Soot
- Last Exhaust Filter Clean
- Compressor Inlet Temperature
- CAC Outlet Temperature
- Exhaust Filter Outlet Temp
- Fan Drive State
- Fuel Level
- Fuel Temperature
- Fuel Delivery Pressure
- Engine Oil Pressure
- Coolant Pressure
- Coolant Level
- Fuel Rate
- Barometric Pressure
- Boost Pressure
- Intake Temperature
- Accelerator Pedal Position
- Percent Load at Current RPM
- Actual Engine Torque
- Engine Speed
- Total Engine Hours
- Trip Fuel

Main Menu Navigation

- NOTE: The engine does not need to be running to navigate the diagnostic gauge screens. If engine start up is desired, See Starting The Engine. All of the engine values illustrated on the diagnostic gauge indicate the engine is running.
- Turn the key switch to the ON position. Starting at the single or four engine parameter display, press the "Menu" key.




Indicator Light

• Total Fuel Used


- Engine Coolant Temperature
- Fuel Temperature
- % Ash
- NOTE: Engine parameters which can be accessed will vary with the engine application. Diagnostic gauge can be set to display readouts in one of the following languages; English, French, German, Italian, and Spanish. Contact your engine distributor or dealer.

The diagnostic gauge includes a graphical backlit Liquid Crystal Display (LCD) screen. The display can show either a single parameter or a quadrant display showing four parameters simultaneously. The diagnostic gauge uses two arrow keys (C) for scrolling through the engine parameter list and viewing the menu list and an enter key (D) for selecting highlighted items. The red (E) and amber (F) lights are used to signal active trouble code received by the diagnostic gauge.

JR74534,00002C8 -19-23AUG10-1/1



2. The first seven items of the "Main Menu" will be displayed.




3. Pressing the "Arrow" keys will scroll through the menu **GO TO 1-UP DISPLAY** selections. STORED CODES ENGINE CONFIG SETUP 1-UP DISPLAY SETUP 4-UP DISPLAY SELECT UNITS ADJUST BACKLIGHT Main Menu Items OURGP11,00000A9 -19-11OCT06-3/5 4. Pressing the right arrow key will scroll down to reveal ADJUST CONTRAST the last items of "Main Menu" screen, highlighting the UTILITIES next item down.

Last Items On Main Menu

OURGP11,00000A9 -19-110CT06-4/5

Continued on next page


5. Use the arrow keys to scroll to the desired menu item or press the "Menu Button" to exit the main menu and return to the engine parameter display.




OURGP11,00000A9 -19-11OCT06-5/5


Engine Configuration Data

- NOTE: The engine configuration data is a read only function.
- NOTE: The engine does not need to be running to navigate the diagnostic gauge screens. If engine start up is desired, See Starting The Engine. All of the engine values illustrated on the diagnostic gauge indicate the engine is running.
- Turn the key switch to the ON position. Starting at the single or four engine parameter display, press the "Menu" key.
- 2. The main menu will be displayed. Use the "Arrow" keys to scroll through the menu until "Engine Config" is highlighted.




OURGP11,00000AB -19-11OCT06-1/6





6. Press the "Menu" key to exit the main menu and return to the engine parameter display.



Exit Main Menu

Menu Key

1800 RPM

ENG RPM COOL TEMP

◀) (▶

98%

14.2

OURGP11,00000AB -19-11OCT06-6/6

1000 RPM

57 PSI


►


Accessing Stored Trouble Codes

NOTE: The engine does not need to be running to navigate the diagnostic gauge screens. If engine start up is desired, See Starting The Engine. All of the engine values illustrated on the diagnostic gauge indicate the engine is running.

For description of trouble codes, see chart in Troubleshooting Section.

- Turn the key switch to the ON position. Starting at the single or four engine parameter display, press the "Menu" key.
- 2. The main menu will be displayed. Use the "Arrow" keys to scroll through the menu until "Stored Codes" is highlighted.






HECK FUEL FILTER AND LINES

< NEXT >


Use Arrow Keys To Scroll

HIDE

OURGP11,00000AC -19-11OCT06-4/6



6. Press the "Menu" key to exit the main menu and return to the engine parameter display.




OURGP11,00000AC -19-11OCT06-6/6

Accessing Active Trouble Codes

NOTE: The engine does not need to be running to navigate the diagnostic gauge screens. If engine start up is desired, See Starting The Engine. All of the engine values illustrated on the diagnostic gauge indicate the engine is running.

For description of trouble codes, see chart in Troubleshooting Section.

1. During normal operation the single or four parameter screen will be displayed.





- When the diagnostic gauge receives a trouble code from an engine control unit, the single or four parameter screen will be replaced with the "Warning" message. The SPN and FMI number will be displayed along with a description of the problem and the corrective action needed.
- IMPORTANT: Ignoring active trouble codes can result in severe engine damage.





OURGP11,00000AD -19-110CT06-2/7


3. If the word "Next" appears above the arrow keys, there are more trouble codes that can be viewed by using the arrow keys to scroll to the next trouble code.













Select Adjust Backlight

3. Once the "Adjust Backlight" menu item has been highlighted, press the "Enter" key to activate the "Adjust Backlight" function.



Return to Main Menu




Continued on next page


OURGP11,0000237 -19-23AUG10-5/6

6. Press the "Menu" key to exit the main menu and return 98% 1000 RPM to the engine parameter display. 1800 RPM 14.2 **57 PSI** ENG RPM COOL TEMP Exit Main Menu OURGP11,0000237 -19-23AUG10-6/6 **Adjusting Contrast** 98% 1000 RPM 1. Turn the key switch to the ON position. Starting at 1800 RPM the single or four engine parameter display press the 14.2 **57 PSI** ENG RPM COOL TEMP "Menu" key. Menu Key OURGP11,00000AF -19-11OCT06-1/6 2. The main menu will be displayed. Use the "Arrow" GO TO 1-UP DISPLAY keys to scroll through the menu until "Adjust Contrast" STORED CODES is highlighted. **ENGINE CONFIG** SETUP 1-UP DISPLAY SETUP 4-UP DISPLAY SELECT UNITS ADJUST BACKLIGHT Select Adjust Contrast OURGP11,00000AF -19-11OCT06-2/6 3. Once the "Adjust Contrast" menu item has been STORED CODES highlighted, press the "Enter" key to activate the **ENGINE CONFIG** "Adjust Contrast" function. **SETUP 1-UP DISPLAY** SETUP 4-UP DISPLAY SELECT UNITS ADJUST BACKLIGHT ADJUST CONTRAST Press Enter Key OURGP11,00000AF -19-11OCT06-3/6 Continued on next page

15-14

4. Use the "Arrow" keys to select the desired contrast intensity.






2. The main menu will be displayed. Use the "Arrow" GO TO 1-UP DISPLAY keys to scroll through the menu until "Select Units" is STORED CODES highlighted. ENGINE CONFIG **SETUP 1-UP DISPLAY** SETUP 4-UP DISPLAY SELECT UNITS ADJUST BACKLIGHT Select Units OURGP11,00000B0 -19-11OCT06-2/7 3. Once the "Select Units" menu item has been GO TO 1-UP DISPLAY highlighted press the "Enter" key to access the "Select

STORED CODES


Units" function. ENGINE CONFIG SETUP 1-UP DISPLAY SETUP 4-UP DISPLAY SELECT UNITS ADJUST BACKLIGHT Press Enter Key OURGP11,00000B0 -19-11OCT06-3/7 4. There are three choices for units of measurement, ENGLISH English, Metric kPa or Metric Bar. METRIC KPA METRIC BAR English is for Imperial units, with pressures displayed in PSI and temperatures in °F. Metric kPa and Metric bar are for IS units, with pressures displayed in kPa and bar respectively, and temperatures in °C. Use the "Arrow" keys to highlight the desired units of measurement. Select Desired Units

Continued on next page

OURGP11,00000B0 -19-110CT06-4/7




7. Press the "Menu" key to return to the engine parameter display.




Return To Main Menu


OURGP11,00000B0 -19-11OCT06-7/7



2. Use the "Arrow" keys to scroll through the menu until "Setup 1-Up Display" is highlighted.




- 3. Once "Setup 1-Up Display" menu item has been GO TO 1-UP DISPLAY highlighted press the "Enter" key to access the "Setup STORED CODES 1-Up Display" function. ENGINE CONFIG SETUP 1-UP DISPLAY SETUP 4-UP DISPLAY SELECT UNITSD ADJUST BACKLIGHT Press Enter Key OURGP11,00000B1 -19-11OCT06-3/18
- 4. Three options are available for modification of the 1-Up Display.
 - a. Use Defaults This option contains the following engine parameters for display: Engine Hours, Engine Speed, Battery Voltage, % Load, Coolant Temperature and Oil Pressure.
 - b. Custom Setup This option contains a list of engine parameters. Engine parameters from this list can be selected to replace any or all of the default parameters. This option can be used to add parameters available for scrolling in the 1-Up Display.
 - c. Automatic Scan Selecting the scan function will allow the 1-Up Display to scroll through the selected set of parameters one at a time, momentarily pausing at each.





Continued on next page

OURGP11,00000B1 -19-11OCT06-4/18

5. Use Defaults - To select "Use Defaults" use the Arrow **USE DEFAULTS** keys to scroll to and highlight "Use Defaults" in the CUSTOM SETUP menu display. AUTOMATIC SCAN OFF Select Defaults OURGP11,00000B1 -19-11OCT06-5/18 6. Press the "Enter" key to activate the "Use Defaults" **USE DEFAULTS** function. CUSTOM SETUP AUTOMATIC SCAN OFF Defaults Selected OURGP11,00000B1 -19-11OCT06-6/18 The display parameters are reset to the factory 7. defaults, then the display will return to the "Setup 1-Up **RESTORED TO** Display" menu. DEFAULTS Restored To Defaults Continued on next page OURGP11,00000B1 -19-11OCT06-7/18 8. **Custom Setup** - To perform a custom setup of the 1-Up Display, use the arrow buttons to scroll to and highlight "Custom Setup" on the display.








11. Press the "Enter" key to deselect the selected ENGINE SPEED parameter, removing it from the list of parameters PERCENT LOAD AT CURRENT RPM 3 being displayed on the 1-Up Display. **ENGINE OIL PRESSURE** ENGINE COOLANT TEMPERATURE **Deselect** Parameters OURGP11,00000B1 -19-11OCT06-11/18 12. Use the "Arrow" keys to scroll and highlight the desired ENGINE SPEED parameter that has not been selected for display PERCENT LOAD AT CURRENT RPM 2 (parameter without a number to right of it). Note that the numbers ENGINE OIL PRESSURE 1 now indicate the new **ENGINE COOLANT TEMP** order of display for the parameters. Select Desired Parameters OURGP11,00000B1 -19-11OCT06-12/18 13. Press the "Enter" key to select the parameter for ENGINE SPEED inclusion in the Single Engine Parameter Display. PERCENT LOAD AT CURRENT RPM 2 14. Continue to scroll through and select additional **ENGINE OIL PRESSURE** 1 parameters for the custom 1-Up Display. Press the **ENGINE COOLANT TEMP** 3 "Menu" key at any time to return to the "Custom Setup" menu. Select Parameters For Display OURGP11,00000B1 -19-11OCT06-13/18 Continued on next page

- 15. Automatic Scan Selecting the scan function will USE DEFAULTS allow the 1- Up Display to scroll through the selected CUSTOM SETUP set of parameters one at a time. Use the "Arrow" keys to scroll to the "Automatic Scan" function. AUTOMATIC SCAN OFF Automatic Scan Off OURGP11,00000B1 -19-11OCT06-14/18 16. Press the "Enter" key to toggle the "Automatic Scan" **USE DEFAULTS** function on. CUSTOM SETUP AUTOMATIC SCAN ON Automatic Scan On OURGP11,00000B1 -19-11OCT06-15/18




Exit Main Menu

OURGP11,00000B1 -19-11OCT06-18/18

Setup 4-Up Display

1. Turn the key switch to the ON position. From the single or four engine parameter display, press the "Menu" key.



2. The main menu will be displayed. Use the "Arrow" keys to scroll through the menu until "Setup 4-Up Display" is highlighted.

 GO TO 1-UP DISPLAY STORED CODES

 SETUP 1-UP DISPLAY

 SETUP 1-UP DISPLAY

 SETUP 4-UP DISPLAY

 SELECT UNITS

 ADJUST BACKLIGHT

 Velocity

 Select Setup 4-Up Display

 OURCP11,000082-19-110CT06-214

3. Once the "Setup 4-Up Display" menu item has been highlighted, press the "Enter" key to activate the "Setup 4-Up Display" menu.

 GO TO 1-UP DISPLAY

 STORED CODES

 ENGINE CONFIG

 SETUP 1-UP DISPLAY

 SETUP 4-Up DISPLAY

 SETUP 4-Up DISPLAY

 SETUP 4-Up DISPLAY

 SETUP 4-UP DISPLAY


 SELECT UNITS

 ADJUST BACKLIGHT

 Image: Construction of the set of th

OURGP11,00000B2 -19-11OCT06-3/14


- 4. Two options are available for the 4-Up Display.
 - a. **Use Defaults** This option contains the following engine parameters for display: Engine Speed, Battery Voltage, Coolant Temperature and Oil Pressure.
 - b. Custom Setup This option contains a list of engine parameters. Engine parameters from this list can be selected to replace any or all of the default parameters.




OURGP11,00000B2 -19-11OCT06-4/14

5. To reset the display parameters to the factory defaults, scroll to and highlight "Use Defaults". Press the "Enter" key to activate the "Use Defaults" function. A message indicating the display parameters are reset to the factory defaults will be displayed, then the display will return to the "Setup 4-Up Display" menu. **RESTORED TO DEFAULTS Were the factory defaults will be displayed, then the display will return to the "Setup 4-Up Display" menu. Restore To Defaults Restore To Defaults Restore To Defaults**


 Custom Setup - To perform a custom setup of the 4-Up Display, use the arrow buttons to scroll to and highlight "Custom Setup" on the display.




The quadrant with the highlighted parameter value 7. is the current selected parameter. Use the "Arrow" 125°F 1000 RPM keys to highlight the value in the quadrant you wish to COOL TEMP ENG RPM change to a new parameter. 57 PSI 14.2 **BAT VOLT OIL PRES** Select Parameters OURGP11,00000B2 -19-11OCT06-7/14 8. Press the "Enter" key and a list of engine parameters will be displayed. 125°F 1000 RPM COOL TEMP ENG RPM 14.2 57 PSI BAT VOLT **OIL PRES** List Of Engine Parameters OURGP11,00000B2 -19-11OCT06-8/14 Continued on next page



- 13. Repeat the parameter selection process until all spaces are as desired.
- 14. Press the "Menu" key to return to the main menu.





John Deere PowerSight

John Deere PowerSight is a web based service that allows remote access to machine data. John Deere PowerSight is accessible from a laptop, desktop or mobile device.

John Deere PowerSight works by combining a controller that includes cellular communication and GPS antennas. Machine data is collected by the controller and wirelessly transferred to a data server, where it is made available on a website.

John Deere PowerSight allows you to:

- Stay informed on machine location and hours
- Protect assets with Geofence and Curfew alerts
- Keep assets running with maintenance tracking and preventive maintenance plans
- Track and analyze machine and fuel usage
- Conduct remote machine diagnostics and programming

For more information and availability, contact an authorized John Deere dealer or servicing dealer.

BL90236,0000031 -19-13FEB14-1/1


Engine Operation

Break-In Service

- 1. This engine is factory-filled with John Deere Break-In Plus oil. Operate the engine at heavy loads with minimal idling during the break-in period.
- If the engine has significant operating time at idle, constant speeds, and light load usage, or make-up oil is required in the first 100 hour period, a longer break-in period may be required. In these situations, there are two acceptable options. 1. Drain the oil and replace with fresh Break-In Plus oil and a new John Deere oil filter (recommended). 2. Continue running the engine with the same oil and filter for up to a maximum of 500 hours.
- Check engine oil by pulling out the oil dipstick located the right side of engine. Check oil more frequently during engine break-in period. If oil must be added during this period, John Deere Break-In Plus Oil is preferred. See <u>John Deere Break-In™ Plus Engine</u> <u>Oil</u> in the Fuels, Lubricants, and Coolants Section for other oils allowed.
- IMPORTANT: DO NOT fill above the top of the crosshatch pattern or the FULL mark, whichever is present. Oil levels anywhere within crosshatch are considered in the acceptable operating range.
- 4. During the first 20 hours, avoid prolonged periods of engine idling or sustained maximum load operation.
- 5. If engine idles longer than 5 minutes, stop engine.
- During the initial operation of a new or rebuilt engine with Break-In Plus, change the oil and filter between a minimum of 100 hours and a maximum of up to 500 hours. See <u>Changing Engine Oil and Replacing Filter</u> in the Lubrication & Maintenance — 500 Hours/12 Months Section. Fill crankcase with seasonal viscosity grade oil. See <u>Diesel Engine Oil</u> in the Fuels, Lubricants, and Coolants Section.
- NOTE: Some increase in oil consumption may be expected when low viscosity oils are used. Check oil levels more frequently.

If air temperature is less than 0°C (32°F), use cold weather starting aids. See <u>Cold Weather</u> <u>Operation</u> in the Engine Operation Section.

If air temperature is less than 0°C (32°F), use an engine block heater.



7. Watch coolant temperature and oil pressure gauges closely during engine operation. If gauge does not indicate more than minimum oil pressure specification, stop the engine and determine the cause. If coolant temperature rises above 113°C (235°F), the engine reduces power automatically. Unless temperature drops quickly, stop the engine and determine the cause before resuming operation.

Monitor oil pressure and coolant temperature specifications.

Specification

Engine —Oil Pressure at	
Rated Speed	357 kPa (3.57 bar) (52 psi)
Minimum Oil Pressure at	
Low Idle	254 kPa (2.54 bar) (37 psi)
Coolant Temperature	
Range	83—95°C (181-–203°F)

8. Check belt for proper alignment and seating in pulley grooves.

ZE59858,000004C -19-16SEP14-1/1

Generator Set (Standby) Applications

To assure that your engine will deliver efficient standby generator operation when needed, start engine and run at rated speed (with 50%—70% load) for 30 minutes every 2 weeks. DO NOT allow engine to run for an extended period of time with no load.

Biodiesel fuel is not recommended for standby equipment that can have minimal fuel consumption (such as standby generators, fire protection, etc.). For standby applications, use only petroleum based diesel fuel with John Deere approved fuel conditioners and additives. For fuel conditioners and additives, check with your local John Deere dealer.

Petroleum diesel fuel should not be stored in service tanks longer than two years even when using fuel additives. See your fuel distributor or John Deere dealer for more information.

Starting the Engine

NOTE: The controls and instruments for your engine may be different from those shown here; always follow manufacturer's instructions.

The following instructions apply to the optional controls and instruments available through the John Deere Parts Distribution Network.

CAUTION: Before starting engine in a confined building, install proper outlet exhaust ventilation equipment. Always use safety approved fuel storage and piping.

- NOTE: If temperature is below 0 °C (32 °F), it may be necessary to use cold weather starting aids. See <u>Cold Weather Operation</u> in the Engine Operation Section.
- Perform all prestarting checks. See <u>Daily Prestarting</u> <u>Checks</u> in the Lubrication & Maintenance - Daily Section.

Use Proper Ventilation

- 2. Open the fuel supply shutoff valve, if equipped.
- 3. Disengage power (or clutch if equipped) to any engine drive lines.

ZE59858,0000297 -19-15SEP14-1/3


4. Set slow idle as follows:

Panels with high-low speed select rocker switch (B) only: Set slow speed by pressing lower half of switch.

Panels with optional analog throttle(s) (A) : Set high-low speed select rocker switch to slow (turtle), then push in on analog throttle handle or turn full counterclockwise to set analog throttle(s) to slow speed.

IMPORTANT: Do not operate the starter for more than 30 seconds at a time. To do so may overheat the starter. If the engine does not start the first time, wait at least 2 minutes before trying again. If engine does not start after four attempts, see Troubleshooting Section.

A—Analog Throttle Control (Optional) B—Speed Select Rocker Switch



Analog Throttle Control and Speed Select Switch

ZE59858,0000297 -19-15SEP14-2/3

Continued on next page

RK80614,0000009 -19-16OCT12-1/1

- 5. Turn the key start switch (A) clockwise to the "ON" position. Wait until the Engine Preheater Indicator light turns off, then turn the key start switch clockwise "START" position to crank the engine. (In cold weather, preheater indicator light remains on longer while engine is warmed. See Cold Weather Operation in the Engine Operation Section.) When the engine starts, release the key switch so that it returns to the "ON" position.
- IMPORTANT: If the key switch is released before the engine starts, wait until the starter and the engine stop turning before trying again. This will prevent possible damage to the starter and/or flywheel.
- 6. After engine starts, idle engine at not more than 1200 rpm until warm. See Warming Engine in the Engine **Operation Section**.

Panels with high-low speed select rocker switch **(B) only:** Set rpm using bump speed enable switch (C) with speed select rocker switch (D).

Panels with optional analog throttle (E): Set either high-low speed select switch (B) or analog throttle (E) to slow speed, and set desired speed with remaining control. See Changing Engine Speed in the Engine Operation Section.

- NOTE: Engine Control Unit (ECU) reads the higher of the high-low speed select rocker switch or the analog throttle speed settings.
- 7. Check all gauges for normal engine operation. If operation is not normal, stop the engine and


Normal Engine Operation

Observe engine coolant temperature and engine oil pressure. Temperatures and pressures vary between engines and with changing operating conditions, temperatures, and loads.

Normal engine coolant operating temperature range is 83°—95°C (181°—203°F). If coolant temperature rises above 113°C (235°F), reduce load on engine. Unless temperature drops quickly, stop engine and determine cause before resuming operation.

Normal engine oil pressure at slow idle should be at least 254 kPa (2.54 bar) (37 psi) and should rise to at least 357 kPa (3.57 bar) (52 psi) at rated RPM.

Operate the engine under a lighter load and at slower than normal speed for first 15 minutes after start-up. DO NOT run engine at slow idle.



Stop engine immediately if there are any signs of part failure. Some early signs of engine problems are:

- Sudden drop in oil pressure
- Abnormal coolant temperatures
- Unusual noise or vibration
- Sudden loss of power
- Excessive fuel consumption
- Excessive oil consumption
- Fluid leaks

D-Speed Select Rocker **B—High-Low Speed Select** Switch E—Analog Throttle Control C—Bump Speed Enable Rocker (Optional)

 \cap

determine the cause. For normal gauge pressures and temperatures, see Break-In Service in the Engine Operation Section.

Start And Idle Engine Controls On Instrument Panel

0

(E)

A—Key Start Switch

Rocker Switch

Switch

ZE59858,0000297 -19-15SEP14-3/3

RG13723 —UN—11NOV04

Warming Engine

IMPORTANT: To assure proper lubrication, operate engine at or below 1200 rpm with no load for 1–2 minutes. Extend this period 2–4 minutes when operating at temperatures below freezing.


Engines used in generator set applications where the governor is locked at a specified speed may not have a slow idle function. Operate these engines at fast idle for 1—2 minutes before applying the load. This procedure does not apply to standby generator sets where the engine is loaded immediately upon reaching rated speed.

 Check oil pressure gauge (A) as soon as engine starts. If oil pressure gauge does not increase to more than minimum oil pressure specification, 254 kPa (2.54 bar) (37 psi) within 5 seconds, stop the engine and determine the cause. Normal engine oil pressure is measured at slow idle (850 rpm) and rated full load speed (1800–2500 rpm).

Specification

Oil Pressure—Pressure.....254—357 kPa (2.54—3.57 bar) (37—52 psi)

 Watch coolant temperature gauge (B). Do not place engine under full load until it is properly warmed up. The normal engine coolant temperature range is 83°–95°C (181°–203°F).



Idling Engine

Avoid excessive engine idling. Prolonged idling may cause the engine coolant temperature to fall below its normal range. This in turn, causes crankcase oil dilution, due to incomplete fuel combustion and permits formation of gummy deposits on valves, pistons and piston rings. It also promotes rapid accumulation of engine sludge and unburned fuel in the exhaust system.

Once an engine is warmed to normal operating temperatures, engine should be idled at slow idle speed. If an engine will be idling for more than five minutes, stop and restart later.

NOTE: Generator set application engines will idle at no load governed speed (high idle).

ZE59858,0000304 -19-07JAN14-1/1

Changing Engine Speed

NOTE: On engines with **2-position** throttles, speeds are not adjustable. These throttles allows operation only at the preset rated speed or at idle using the single switch (A).

Changing from slow to fast speed using Standard High-Low Speed Select Rocker Switch (A) (If Equipped):

- For slow speed, press lower half of switch (indicated by turtle symbol).
- For fast speed, press upper half of switch (indicated by rabbit symbol).


NOTE: To adjust preset fast or slow speeds for High-Low Speed Select Rocker Switch:

- 1. Select fast (rabbit) or slow (turtle) position on High-Low Speed Select Rocker Switch (A).
- 2. Press and hold top or bottom half of Bump Speed Enable Rocker Switch (B) while using Speed Select Rocker Switch (C).
- 3. Use Speed Select Rocker Switch (C) to bump engine speed up (+) or down (-).
- NOTE: Once the speed has been set, the Bump Speed Enable Switch (B) must be pressed and released three times within two seconds to commit the new slow or fast speed to memory. If not done, the engine's new slow or fast speed will only be effective until the key switch is shut off. Then the speed will revert to its previous setting.

Changing from slow to fast speed using Adjustable High-Low Speed Select Rocker Switch (A) (If Equipped):

Panels have an adjustable **three-position** rocker switch (A) that can be used to select slow idle, fast idle, or an adjustable ("ADJ") intermediate speed.

- For slow speed, press lower half of rocker switch (indicated by turtle symbol).
- For fast speed, press upper half of rocker switch (indicated by rabbit symbol).
- NOTE: To adjust preset fast or slow speeds with adjustable High-Low Speed Select Rocker Switch:
 - 1. Select middle position (ADJ) or slow (turtle) position on the optional Adjustable Three-State Speed Select Rocker Switch (A).
 - 2. Press and hold top or bottom half of Bump Speed Enable Rocker Switch (B) while using Speed Select Rocker Switch (C).
 - 3. Use Speed Select Rocker Switch (C) to bump engine speed up (+) or down (-).



Changing Engine Speed On Panel

A— High-Low Speed Select Rocker Switch B— Bump Speed Enable

Rocker Switch

- C— Speed Select Rocker Switch D— Analog Throttle Control (Optional)
- NOTE: Slow (turtle) position is factory preset at low engine idle, while middle (ADJ) position is factory set at high engine idle.
- NOTE: Once the speed has been set, the Bump Speed Enable Switch (B) must be pressed and released three times within two seconds to commit the new slow or fast speed to memory. If not done, the engine's new slow or fast speed will only be effective until the key is shut off. Then the speed will revert to its previous setting.

Changing engine speed using optional analog throttle (D)

NOTE: Pushing in on analog throttle will immediately take engine to slow idle speed.

1. Set High-Low Speed Select Rocker Switch (A) to low speed "turtle" position.

2. Turn analog throttle (D) clockwise to increase speed or counterclockwise to decrease speed.

NOTE: Engine Control Unit (ECU) reads the higher of the High-Low Speed Select Rocker Switch or the Analog Throttle(s) Speed Settings. With High-Low switch at low speed, Analog Throttle(s) will control speed higher than slow idle setting.

ZE59858,000029A -19-14NOV13-1/1

E— Ether

Heat

Cold Weather Operation



Starting Fluid is Flammable

140 41°F (5°C) 2 Heat 130 32°F (0°C) Heat Air RPM Heat ectric Block Block 115 14°F (-10°C) Cranking + Heat 108 0°F (-18°C) Heat Block 105 -4°F (-20°C) Electric Air Ether inimum + Ether 103 -13°F (-25°C) Ξ 100 -22°F (-30°C) A 100 -31°F (-35°C) 100 -40°F (-40°C) Cold Weather Starting Guidelines

Ć D E F G

B

A— Minimum Cranking RPM B- No Aids

C— Electric Air Heat D— Block Heat

CAUTION: Ether is highly flammable. DO NOT use ether when starting an engine equipped with glow plugs or an air intake heater.

DO NOT use starting fluid near fire, sparks, or flames. DO NOT incinerate or puncture a starting fluid container.

IMPORTANT: Engines with Rear PTO -Turn off or unload all pumps, auxiliary drives, and compressors before cold weather starting to reduce drag on engine.

Engines may be equipped with a block heater, coolant heater, or fuel heater as cold weather starting aids.

Starting aids are required below 0 °C (32 °F). They will enhance starting performance above these temperatures and may be needed to start applications that have high parasitic loads during cranking and/or start acceleration to idle.

Using correct grade oil (per engine and machine operators manual) is critical to achieving adequate cold-weather cranking speed. Synthetic oils have improved flow at low temperatures

G— Ether and Block Heat F- Electric Air Heat and Block

Other cold weather starting aids are required at temperatures below -25 °C (-13 °F) or at altitudes above 1500 m (5000 ft).

1. Follow steps 1—4 as listed under Starting the Engine in the Engine Operation Section, then proceed as follows according to the instrument (control) panel on your engine.

2. Use cold weather starting aids as needed. Follow supplier instructions for starting aid provided on your engine. A booster battery can be connected if needed (see Using a Booster Battery or Charger in the Engine Operation Section).

3. Engines with air intake heaters or glow plugs: Turn key ON but do not crank engine until Engine Preheat Indicator goes off.

4. Follow remaining steps 5-7 as listed under Starting the Engine in the Engine Operation Section.

Additional information on cold-weather operation is available from your authorized servicing dealer.

RK80614.000000C -19-25MAR14-1/1

Stopping the Engine

- 1. Pull PTO clutch lever rearward (away from engine) to disengage clutch, if equipped.
- IMPORTANT: Before stopping an engine that has been operating at working load, idle engine at least 2 minutes at 1000—1200 rpm to cool hot engine parts. If an Exhaust Filter Cleaning has just been performed, increase engine idle time to 4 minutes. If service work is going to be performed on the Exhaust Filter, increase engine idle time to 10 minutes.


Engines in generator set applications, run engine for at least 2 minutes at fast idle and no load. If an Exhaust Filter Cleaning has just been performed, increase engine idle time to 4 minutes. If service work is going to be performed on the Exhaust Filter, increase engine idle time to 10 minutes

2. Run engine at 1000—1200 rpm for at least 2 minutes to cool. If an Exhaust Filter Cleaning has just been performed, increase engine idle time to 4 minutes. If service work is going to be performed on the Exhaust Filter, increase engine idle time to 10 minutes


Panels with high-low speed select rocker switch (B) only: Set rpm using bump speed enable switch (C) with speed select rocker switch (D).

Panels with optional analog throttle (E): Set either high-low speed select switch (B) or analog throttle control (E) to slow idle, and set desired speed with remaining control.

- NOTE: Engine control unit (ECU) reads the higher of the high-low speed select rocker switch or the analog throttle speed settings.
- 3. Push in on analog throttle control handle (if equipped) so that engine goes to slow idle, or set slow speed with high-low speed select rocker switch.
- 4. Turn key start switch (A) to "OFF" position to stop the engine. Remove ignition key.
- IMPORTANT: Make sure that exhaust stack rain cap (F) is installed when engine is not running. This will prevent water and dirt from entering engine.



Stopping the Engine Using Panel Controls (Full-Featured Panel Shown)



ZE59858,0000305 -19-07JAN14-1/1

Auxiliary Gear Drive Limitations

- IMPORTANT: See OEM engine distributor for more information to prevent overloading the auxiliary drive. Severe engine damage could result.
- IMPORTANT: When attaching an air compressor, hydraulic pump, or other accessory to be driven by the auxiliary gear drive (engine timing gear train at front of engine), power requirements of the accessory must be limited to values listed:
- 11 kW (15 hp) Continuous Operation at 2400 rpm
- 18 kW (24 hp) Intermittent Operation at 2400 rpm
- 10 kW (13 hp) Continuous Operation at 2200 rpm
- 16.5 kW (22 hp) Intermittent Operation at 2200 rpm


Using a Booster Battery or Charger

A 12 volt booster battery or charger can be connected in parallel with battery(ies) on the unit to aid in cold weather starting. ALWAYS use heavy-duty jumper cables.


CAUTION: Gas given off by battery is explosive. Keep sparks and flames away from battery. Before connecting or disconnecting a battery charger, turn off charger. Make last connection and first disconnection at a point away from battery. Always connect NEGATIVE (-) cable last and disconnect this cable first.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

- IMPORTANT: Be sure that polarity is correct before making connections. Reversed polarity damages electrical system. Always connect positive to positive and negative to ground. Always use 12 volt booster battery for 12 volt electrical systems and 24 volt booster battery(ies) for 24 volt electrical systems.
- 1. Connect booster battery or batteries to produce the required system voltage for your engine application.
- NOTE: To avoid sparks, DO NOT allow the free ends of jumper cables to touch the engine.



ZE59858,000004F -19-23SEP14-1/1




- 2. Connect one end of jumper cable to the POSITIVE (+) post of the booster battery.
- 3. Connect the other end of the jumper cable to the POSITIVE (+) post of battery connected to starter.
- 4. Connect one end of the other jumper cable to the NEGATIVE (–) post of the booster battery.
- 5. ALWAYS complete the hookup by making the last connection of the NEGATIVE (–) cable to a good ground on the engine frame and away from the battery(ies).
- Start the engine. Disconnect jumper cables immediately after engine starts. Always disconnect NEGATIVE (–) cable first.

ZE59858,0000011 -19-18AUG14-1/1

Aftertreatment System

Exhaust Filter Cleaning and Maintenance



Exhaust Filter — Cleaning

The Exhaust Filter, which includes the Diesel Oxidation Catalyst (DOC) and Diesel Particulate Filter (DPF), is a critical component in the engine's emissions control system, which is required to meet governmental emissions regulations. The Exhaust Filter captures diesel particulate matter or "soot" to prevent its release into

the atmosphere. This soot must be eliminated from the DPF to keep it functioning properly. The process of eliminating collected soot is carefully controlled by the Engine Control Unit (ECU) and is called "exhaust filter cleaning" or "regeneration". During this process, a rise in exhaust temperature occurs and allows the soot to be oxidized within the DPF.

RK80614,0000014 -19-04JUN13-1/1

Diesel Particulate Filter Maintenance and Service

The Exhaust Filter includes the Diesel Oxidation Catalyst (DOC) and Diesel Particulate Filter (DPF). The DPF is designed to retain residual ash, which is a noncombustible result of additives used in crankcase lubrication oils and the fuel. The DPF provides many hours of maintenance free operation. At some point the DPF will require professional service to remove the accumulated ash. The exact number of hours of operation before service is required will vary depending upon the engine power category, duty cycle and operating conditions, engine oil ash content, and fuel quality. Adhering to John Deere's recommended oil and fuel specifications will maximize the hours of operation before professional DPF service is required.

As the engine owner, you are responsible for performing the required maintenance described in your Operator's manual. Generally, the ash removal service interval will far exceed the EPA required minimums of 3,000 hours for engines below 175hp/130kW and 4,500 hours for engines at or above 175hp/130kW. The use of recommended John Deere fluids will extend the life of the aftertreatment system and extend the maintenance intervals of the DPF. When the exhaust filter requires service, the Engine Control Unit (ECU) will alert the operator with a Diagnostic Trouble Code (DTC)

The removal of DPF ash must be done by removing the DPF from the machine and placing it into specialized equipment. Do not remove ash by using water or other chemicals. Removing ash by these methods may damage the material securing the DPF in its canister, resulting in the loosening of the DPF element in the canister and subjecting it to damage from vibration.

Failure to follow the approved ash removal methods may violate your Governing Bodies Regulations along with damage the DPF, resulting in potential denial of the Diesel Exhaust Filter emissions warranty. It is recommended that you take the DPF to an authorized John Deere service location or other gualified service provider for servicing.

RK80614,0000015 -19-16DEC13-1/1

Exhaust Filter — Diesel Particulate Filter Ash Handling and Disposal

CAUTION: Your Governing Bodies Regulations may classify diesel particulate filter ash as a hazardous waste. Hazardous wastes therefore must be disposed of in accordance with all applicable Governing Bodies Regulations governing hazardous waste disposal. Only a qualified service provider should remove ash from the DPF. Personal protective equipment and clothing, maintained in a sanitary and reliable condition, should be used when handling and cleaning a DPF. See your John Deere dealer or qualified service provider for assistance.

RK80614,0000016 -19-05JUN13-1/1


Exhaust Filter — Disposal

CAUTION: Proper management of an Exhaust Filter that has reached the end of its useful life is required, since the ash or catalyst material in the device may be classified as hazardous waste under federal, state, and/or local laws or regulations. See your John Deere dealer or qualified service provider for assistance.

RK80614,0000017 -19-210CT13-1/1

Exhaust Filter System Overview

NOTE: Operator display icons and procedures can vary in other applications. The information contained in this section specifically applies to only OEM engines using the diagnostic gauge. If you are operating a John Deere vehicle, please see the vehicle operator manual for all exhaust filter cleaning operation information and procedures.



Diesel Exhaust Filter

A—Diesel Exhaust Filter

B—Diesel Particulate Filter (DPF) C—Diesel Oxidation Catalyst (DOC)

John Deere has developed an exhaust filter consisting of a diesel oxidation catalyst (DOC) and a diesel particulate filter (DPF) specifically to meet the demands of off-highway applications. The DOC reduces carbon monoxide, hydrocarbons, and some particulate matter. The downstream DPF traps and holds particulates remaining in the exhaust stream. Trapped particles are eventually oxidized within the DPF through a process known as regeneration or exhaust filter cleaning.

Under normal machine operation and with the system in AUTO mode, the exhaust filter system requires minimal operator interaction.

To avoid unnecessary buildup of diesel particulates or soot in the exhaust filter system;

 Utilize the Automatic (AUTO) Exhaust Filter Cleaning mode.

- **2** Avoid unnecessary idling.
- **3** Use proper engine oil (See Fuels, Lubricants, and Coolants Section for recommendations).
- 4 Use only ultra low sulfur fuel (See Fuels, Lubricants, and Coolants Section for recommendations).

In addition to soot, ash deposits will also slowly build up in the DPF and cannot be removed through the engine exhaust filter cleaning process. To clean the ash deposits from the DPF see <u>Diesel Particulate Filter Maintenance</u> <u>and Service</u> in the Aftertreatment Section.

Λ	CAUTION: Do not power wash the filter assembly
	when external skin temperature of assembly
	exceeds 50 °C (120 °F).

RK80614,0000018 -19-28JAN13-1/1

Diagnostic Gauge Keys and Indicators Overview The image below shows all the keys and indicators you will see and use through the operator initiated or auto exhaust filter cleaning and disable processes. 5104 EXH FLT CL G (H)F Diagnostic Gauge Indicators and Keys A-Exhaust Filter Cleaning C—Exhaust Filter Indicator E—Warning Indicator H-Menu Key Indicator **D**—Caution Indicator F-Enter Key G—Arrow Keys

-Auto Cleaning Disabled Indicator

NOTE: You will never see the diagnostic gauge with all indicators illuminated at the same time (as

shown). This image is only to illustrate the indicators you may see during operation.

The exhaust filter cleaning indicator (A) will illuminate when exhaust gas temperature is at optimal regeneration temperature, elevated idle is active, or exhaust filter cleaning is in process.

When this indicator (A) is illuminated, the machine can be operated as normal unless the operator determines the machine is not in a safe location for high exhaust temperatures and disables auto cleaning.

The auto cleaning disabled indicator (B) will illuminate when the operator has engaged the request to disable the auto exhaust filter cleaning function from the diagnostic gauge. This icon will remain illuminated until the operator reengages automatic exhaust filter cleaning from the diagnostic gauge. Disabling auto mode is not recommended for any situation unless it is safety related or if the fuel tank lacks the required fuel to complete the cleaning process.

The exhaust filter indicator (C) will illuminate when the exhaust filter is in need of cleaning and the operator has disabled auto exhaust filter cleaning. DTC 3719.15 will be present on the diagnostic gauge (see Listing of Diagnostic

Trouble Codes in the Troubleshooting section for more information). If conditions are safe, the operator should enable the auto exhaust filter clean setting or perform manual service regeneration or follow DTC procedure.

If the exhaust filter indicator (C) is combined with the caution indicator (D), the engine performance will be reduced by the ECU because the soot level of the exhaust filter is moderately high. DTC 3719.16 will be present on the diagnostic gauge (see Listing of Diagnostic Trouble Codes in the Troubleshooting section for more information) and the amber indicator light on the diagnostic gauge will turn on. If conditions are safe, the operator should enable the auto exhaust filter clean function. If conditions are not safe, the operator should move the machine to a safe location and engage the auto exhaust filter cleaning mode. Perform manual service regeneration or follow DTC procedure

If the exhaust filter indicator (C) is combined with the stop engine warning indicator (E), the engine performance will be further reduced by the ECU because the soot level of the exhaust filter is extremely high. DTC 3719.00 will be present on the diagnostic gauge (see Listing of Diagnostic Trouble Codes in the Troubleshooting section for more information) and the red indicator light on the diagnostic gauge will turn on. If this combination is present, see your authorized servicing dealer.

Continued on next page

The instructions in this section refer to the keys on the diagnostic gauge. The Enter key (F) is used when selecting an option on the diagnostic gauge. The Arrow keys (G) are used to scroll up or down between options on the diagnostic gauge screen. The Menu key (H) is used to access the main menu of options from which the operator can choose.

JR74534,00001E5 -19-04JAN11-2/2

Passive Regeneration/Natural Cleaning

Periodically, the exhaust filter will experience higher heat levels simply through the engine operating at higher loads. During these times, the higher exhaust heat will naturally clean a small amount of soot build up in the exhaust filter. Conversely, unnecessary idling can cause additional exhaust filter soot to accumulate. For the best possible engine operation which requires the least amount of operator interaction, the engine should be worked at higher load conditions whenever possible and idling should be kept to a minimum.

Automatic (AUTO) Exhaust Filter Cleaning

- NOTE: Operator display icons and procedures can vary in other applications. The information contained in this section specifically applies to only OEM engines. If you are operating a John Deere vehicle, please see the vehicle operator manual for all exhaust filter cleaning and handling information and procedures.
- NOTE: When Auto or Parked exhaust filter cleaning is enabled, the exhaust temperature may be high under no load or light load conditions at certain times during the exhaust filter cleaning cycle.


Operating the engine in AUTO Mode allows the ECU to perform intelligent exhaust filter cleaning as required. The Exhaust Filter Cleaning Indicator will illuminate when the system is actively performing an exhaust filter cleaning. During this process, the injector will inject small amounts of fuel into the exhaust stream to assist in cleaning the exhaust filter. When the exhaust filter cleaning process has completed its cycle, the cleaning indicator will automatically turn off.

CAUTION:

Servicing machine or attachments during exhaust filter cleaning can result in serious personal injury. Avoid exposure and skin contact with hot exhaust gases and components.

During auto or manual/stationary exhaust filter cleaning operations, the engine will run at elevated idle and hot temperatures for approximately 20—50 minutes. Exhaust gases and exhaust filter components reach temperatures hot enough to burn people, ignite, or melt common materials.

CAUTION: If the machine is not in a safe location for elevated exhaust temperatures, move the



machine to a safe location and check for adequate fuel level before beginning the exhaust filter cleaning process. Any PTO driven devices (if equipped) should be powered off or disconnected.

If the machine is not able to be moved into a safe location, the operator should temporarily disable auto exhaust filter cleaning (see <u>Disable Exhaust Filter Cleaning</u> in the Aftertreatment System Section). If the machine is located in a safe location, the auto mode should always be engaged.

To engage the auto exhaust filter cleaning mode:

- **1** Press the Menu key on the diagnostic gauge.
- Press the Arrow keys to scroll up or down to EXHAUST FILTER.
- 3 Press the Select key.
- Press the Arrow keys to scroll up or down to AUTO EXH FLT CLEAN.
- Press the Select key to enable auto exhaust filter cleaning.

RK80614,000001B -19-24JUL13-1/1

RK80614,000001A -19-16OCT12-1/1

Manual/Parked Exhaust Filter Cleaning

NOTE: Operator display icons and procedures can vary in other applications. The information contained in this section specifically applies to only OEM engines. If you are operating a John Deere vehicle, please see the vehicle operator manual for all exhaust filter cleaning and handling information and procedures.

Manual/Parked Exhaust Filter Cleaning is an automated process initiated at the request of the operator. This process allows the system to clean the exhaust filter when the operator previously needed to engage the disable exhaust filter cleaning because of specific conditions. During the process the engine speed will be controlled by the ECU and the machine must remain parked to complete the procedure. Time required for the manual/Parked Exhaust Filter Cleaning process is dependent upon the level of exhaust filter restriction, ambient temperatures, and current exhaust gas temperature.

Complete cleaning times will very on several criteria including fuel type, oil type, duty cycle, and the number of previously aborted exhaust filter cleaning requests. Average time for a standard cleaning can range from 20-50 minutes.

Servicing machine or attachments during exhaust filter cleaning can result in serious personal injury. Avoid exposure and skin contact with hot exhaust gases and components.

During auto or manual/parked exhaust filter cleaning operations, the engine will run at elevated idle and hot temperatures for approximately 20-50 minutes. Exhaust gases and exhaust filter components reach temperatures hot enough to burn people, ignite, or melt common materials.

CAUTION: Always park the machine in a safe location and check for adequate fuel level before beginning the exhaust filter cleaning process. Any PTO driven devices (if equipped) should be powered off or disconnected.

To request a manual/parked exhaust filter cleaning:





- 1 Reduce engine speed to slow idle.
- 2 Press the Menu key.
- Press the Arrow keys to scroll up or down to EXHAUST FILTER.
- 4 Press the Select key.
- 5 Press the Arrow keys to scroll up or down to REQUEST EXH FLT CLEAN.
- 6 Press the Select key to request a manual/parked exhaust filter cleaning.
- 7 Follow the directions on the display and ensure all conditions are met.
- 8 Press the Select key to CONFIRM all conditions are met.

NOTE: Engine speed will be controlled by the ECU during filter cleaning.

The Exhaust filter indicator will remain off when Filter Cleaning is complete. If you are not returning the machine to service immediately after the procedure, allow the engine and the exhaust filter time to return to normal operating temperature before stopping engine. At any time during the parked procedure, the process can be canceled.

Avoid disabling the cleaning procedure unless absolutely necessary. Repeated disabling or ignoring prompts to perform a manual/parked cleaning procedure will cause additional engine power limitations and can eventually lead to dealer required service.

Utilize Exhaust Filter Cleaning AUTO mode to avoid additional service.

RK80614,000001C -19-24JUL13-1/1

Disable Exhaust Filter Cleaning

- NOTE: Operator display icons and procedures can vary in other applications. The information contained in this section specifically applies to only OEM engines. If you are operating a John Deere vehicle, please see the vehicle operator manual for all exhaust filter cleaning and handling information and procedures.
- NOTE: Disabling the exhaust filter cleaning request is not preferred. Disable the automatic exhaust filter cleaning only when necessary. Whenever possible, cleaning should be allowed and the diagnostic gauge should be left in the auto mode. When left in auto mode, soot buildup in the exhaust filter system will be at a minimum.
- NOTE: When AUTO or PARKED/MANUAL cleaning is enabled, the exhaust temperature may be high under no load or light load conditions at certain times during the exhaust filter cleaning cycle. Disable exhaust filter cleaning in conditions where it may be unsafe for elevated exhaust temperatures.

To disable the auto exhaust filter cleaning mode:

- **1** Press the Menu key on the diagnostic gauge.
- 2 Press the Arrow keys to scroll up or down to select EXHAUST FILTER.
- 3 Press the Enter key.
- Press the Arrow keys to scroll up or down and select DISABLE EXH FLT CLEAN to disable auto exhaust filter cleaning.
- 5 Press the Enter key.

JR74534,00001E9 -19-04JAN11-1/1

Exhaust Filter Service Required

The exhaust filter cleaning procedures listed earlier in this section clean the soot from your exhaust filter. The exhaust filter also traps ash deposits over time which are not removed during an exhaust filter cleaning. When the exhaust filter has run several thousand hours, these ash deposits can restrict engine performance due to increased back pressure. To correct this situation, replace the exhaust filter or have the exhaust filter cleaned in specialized equipment. See <u>Diesel Particulate Filter</u> <u>Maintenance and Service</u> in the Aftertreatment Section.

RK80614,000001E -19-11JUL13-1/1

Observe Service Intervals

A repair shop or person of the owner's choosing may maintain, replace, or repair emission control devices and systems. However, warranty service must be performed by an authorized John Deere service facility except in the case of emergency.

In an emergency, where an authorized John Deere service location is not available, repairs may be performed at any available service establishment, or by the owner, using any replacement part, provided such parts are warranted by their manufacturer to be the equivalent of John Deere parts in performance and durability and the failure does not arise from the owner's failure to perform required maintenance.

Using hour meter (A) as a guide, perform all services at the hourly intervals indicated on following pages. At each scheduled maintenance interval, perform all previous maintenance operations in addition to the ones specified. Keep a record of hourly intervals and services performed, using charts provided in Lubrication and Maintenance Records section.


IMPORTANT: Recommended service intervals are for normal operating conditions. Perform maintenance at interval which occurs first, for example, either at 500 hours of operation or every 12 months. Service more often if engine operated under adverse conditions. Neglecting maintenance can result in failures or permanent damage to the engine.

Use Correct Fuels, Lubricants, and Coolant

IMPORTANT: Use only fuels, lubricants, and coolants meeting specifications outlined in Fuels, Lubricants, and Coolant Section when servicing your John Deere Engine.

Consult your John Deere Servicing Distributor or your nearest John Deere Parts Network for recommended fuels, lubricants, and coolant. Also available are necessary additives for use when operating engines in tropical, arctic, or any other adverse conditions.





Hour Meter On Instrument Panel

A—Hour Meter

Perform all services at the hourly intervals. Record the services performed in the Lubrication and Maintenance Records Section. When scheduled service at any hourly level is performed, also perform all subordinate hourly level services.

JR74534,000027F -19-18MAY09-1/1

ZE59858,0000050 -19-23SEP14-1/1

Lubrication and Maintenance Service Interval Chart

	Lubrication and Maintenance Service Intervals						
Item	Daily	250 Hours of Operation or Every 12 Months	500 Hours of Operation or Every 12 Months	1200 Hours of Operation	1500 Hours of Operation or Every 24 Months	6000 Hours of Operation or Every 72 Months	Service as Required
Check Engine Oil Level	•						
Check Engine Coolant Level	•						
Check Fan, Alternator, and Accessory Drive Belts	•						
Drain Water From Fuel Filter	•						
Check Air Cleaner Dust Unloader Valve and Restriction Indicator Gauge	•						
Visual Walk Around Inspection	•						
Replace Fuel Filter Elements		•					
Service Fire Extinguisher			•				
Service Battery			•				
Change Engine Oil And Replace Oil Filter ^{a ,b}			•				
Visually Inspect Coolant Pump			•				
Check Open Crankcase Ventilation (OCV) System			•				
Check Engine Mounts			•				
Check Belt and Belt Wear			•				
Check Air Intake Hoses, Connections, & System			•				
Check Engine Ground Connection			•				
Check Cooling System			•				
Pressure Test Cooling System			•				
Check Engine Speeds			•				
Check and Adjust Engine Valve Clearance				•			
Changing Open Crankcase Ventilation (OCV) Filter					•		
Flush and Refill Cooling System						•	
Test Thermostats						•	
Drain Water From Fuel Filters							•
Bleed Fuel System							•
Add Coolant							•
Pre-Start Cleaning Guide							٠
Replace Air Cleaner Elements							٠
Clean Diesel Particulate Filter ^c							•
Replace Fan Belt							٠
Check Fuses							٠
Check Electrical Wiring and Connections							•
Check Air Compressor (If Equipped)							•

^aDuring the initial operation of a new or rebuilt engine with Break-In Plus, change the oil and filter between a mini-

mum of 100 hours and a maximum of up to 500 hours. ^bService intervals depend on sulfur content of the diesel fuel, oil pan capacity, and the oil and filter used. (See Diesel Engine

Oil and Filter Service Intervals in the Fuels, Lubricants, and Coolants Section.) ^cActual service should take place when the dash indicator light comes on or as indicated by the diagnostic gauge.

RK80614,0000534 -19-12DEC14-1/1

Daily Prestarting Checks

Check the following items BEFORE STARTING THE ENGINE for the first time each day:

 Check engine oil level on dipstick. Fill cap/dipstick may be located on left or right side, depending on application. Add as required, using seasonal viscosity grade oil. (See <u>Diesel Engine Oil</u> — Interim Tier 4, Final <u>Tier 4, Stage IIIB, and Stage IV</u> in the Fuels, Lubricants, and Coolants Section for oil specifications.)

NOTE: Wipe all fittings, caps, and plugs before performing any maintenance to reduce the chance of system contamination.

- Check the coolant level when engine is cold. Fill radiator or surge tank with proper coolant if level is low. (See <u>Adding Coolant</u> in the Service As Required Section.) Check overall cooling system for leaks.
- Check radiator for leaks and trash buildup.
 - NOTE: It is normal for a small amount of coolant to weep from the coolant pump weep hole, especially as the engine cools down and parts contract. If enough coolant weeps from the engine where coolant drips from the engine, this

may indicate the need to replace the coolant pump seal. Contact your engine distributor or servicing dealer for repairs.

- Check fan, alternator, and accessory drive belts for cracks, breaks or other damage.
- Loosen water drain valve on each fuel filter all the way so that the valve opens to drain water and debris as needed. Retighten valves securely.

NOTE: Any water in fuel is drained into the bottom of the fuel filters. The operator is signaled by an amber indicator on the instrument panel. To service, see <u>Drain Water From Fuel Filters</u> in the Service As Required Section.

- Squeeze the automatic dust unloader valve (if equipped) on air cleaner assembly to clear away any dust buildup.
- Check air intake restriction indicator gauge and service air cleaner as required (if equipped).
- Check air intake system hoses and connections for cracks and loose clamps.
- Inspect the engine compartment. Look for fluid leaks, worn fan and accessory drive belts, loose connections, and trash buildup. Remove trash buildup and have repairs made as needed.

RK80614,0000023 -19-05FEB14-1/1

Removing and Installing Fuel Filter

CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If any fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.


IMPORTANT: Replace fuel filter elements anytime audible alarm sounds and trouble codes indicate

Remove and Install Primary Fuel Filter Element

- 1. Thoroughly clean filter header and surrounding area to prevent dirt and debris from entering fuel system.
- 2. Connect a hose to filter drain valve (A) on bottom of filter and drain all fuel from filter canister.
- 3. Disconnect water-in-fuel sensor connector if equipped.
- 4. Remove fuel filter canister (C).
- 5. Place new O-ring on filter canister.
- 6. Apply a thin film of fuel on O-ring.


IMPORTANT: Do not fill the new filter with fuel before installing. This could contaminate the fuel system with unfiltered fuel.

- 7. Install new filter and tighten until the top portion of the filter contacts the filter header assembly.
- 8. Reconnect water-in-fuel sensor connector if equipped.
- 9. Prime the fuel system. See <u>Bleeding Fuel System</u> in the Service As Required Section.



plugged fuel filters (low fuel pressure). If no alarm sounds during the 12 month service interval, replace elements at that time, or after 250 hours operation, whichever comes first.

RK80614,0000535 -19-12DEC14-1/2



A—Drain Valve B—Water Separator C—Primary Fuel Filter Element D—Primary Fuel Filter Header

RK80614,0000535 -19-12DEC14-2/2

Servicing Fire Extinguisher

A fire extinguisher (A) is available from your authorized servicing dealer or engine distributor.

Read and follow the instructions which are packaged with it. The extinguisher should be inspected at least every 500 hours of engine operation or every 12 months. Once extinguisher is operated, no matter how long, it must be recharged. Keep record of inspections on the tag which comes with the extinguisher instruction booklet.

A—Fire Extinguisher



Servicing Battery

CAUTION: Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded NEGATIVE (—) battery clamp first and replace it last.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

IMPORTANT: Wear personal Protective Equipment while doing any type of Battery check or replacement.

- 1. On regular batteries, check electrolyte level. Fill each cell to bottom of filler neck with distilled water.
- NOTE: Low-maintenance or maintenance-free batteries should require little additional service. However, electrolyte level can be checked by cutting the center section of decal on dash-line, and removing cell plugs. Fill each cell to bottom of filler neck with distilled water.
- 2. Keep batteries clean by wiping them with a damp cloth. Keep all connections clean and tight. Remove



Exploding Battery

any corrosion, and wash terminals with a solution of 1 part baking soda and 4 parts water. Tighten all connections securely.

- NOTE: Coat battery terminals and connectors with a mixture of petroleum jelly and baking soda to retard corrosion.
- Keep battery fully charged, especially during cold weather. If a battery charger is used, turn off charger before connecting charger to battery(ies). Attach POSITIVE (+) battery charger lead to POSITIVE (+) battery post. Then attach NEGATIVE (—) battery charger lead to a good ground.

Continued on next page

ZE59858,0000052 -19-16APR14-1/2

CAUTION: Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:

- 1. Filling batteries in a well-ventilated area.
- 2. Wearing eye protection and rubber gloves.
- 3. Avoiding breathing fumes when electrolyte is added.
- 4. Avoiding spilling or dripping electrolyte.
- 5. Using proper jump start procedure.

If you spill acid on yourself:

- 1. Flush your skin with water.
- 2. Apply baking soda or lime to help neutralize the acid.
- 3. Flush your eyes with water for 10—15 minutes. Get medical attention immediately.

If acid is swallowed:

- 1. Drink large amounts of water or milk.
- 2. Then drink milk of magnesia, beaten eggs, or vegetable oil.
- 3. Get medical attention immediately.

In freezing weather, run engine at least 30 minutes to ensure thorough mixing after adding water to battery.


Replacement battery(ies) must meet or exceed the following recommended capacities¹ at -18 $^{\circ}C$ (0 $^{\circ}F$):

Specification

12-Volt System—Min-	
imum Battery Capac-	
ity—Cold Cranking	
Amps	640 Minimum
Reserve Capacity	
(Minutes)	

¹ Total recommended capacity based on batteries connected in series or parallel.





- 5. Remove filter element (A) using a suitable filter wrench. Remove inner seal (B). Discard oil filter element and seal.
- NOTE: Depending on engine application, oil filter is mounted in the vertical or horizontal position.
- IMPORTANT: Filtration of oils is critical to proper lubrication. Always change filter regularly. Use filter meeting John Deere performance specifications.
- 6. Clean oil filter sealing surface.

Oil Filter-Turn After

- 7. Apply clean engine oil to the new filter inner seal (B) and to filter threads.
- 8. Thread new oil filter onto oil filter header until the oil filter seal contacts the oil filter header.
- 9. Hand tighten oil filter to specification. DO NOT overtighten oil filter.

Specification


 Fill engine crankcase with correct John Deere engine oil through oil filler cap. See <u>Diesel Engine Oil</u> — <u>Interim Tier 4, Final Tier 4, Stage IIIB, and Stage</u> <u>IV</u> in the Fuels, Lubricants, and Coolant Section for determining correct engine oil.

To determine the correct oil fill quantity for your engine, see <u>Engine Crankcase Oil Fill Quantities</u> in the Specifications Section.

- IMPORTANT: Immediately after completing any oil change, crank engine for 30 seconds without permitting engine to start. This helps insure adequate lubrication to engine components before engine starts.
- NOTE: Crankcase oil capacity may vary slightly. ALWAYS fill crankcase within crosshatch marks on dipstick. DO NOT overfill.
- 11. Start engine and run to check for possible leaks.
- 12. Stop engine and check oil level after 10 minutes. Oil level reading should be within crosshatch marks on dipstick.


A—Oil Filter Element

B—Inner Seal



Visually Inspecting Coolant Pump

- NOTE: Cooling pump drive pulley is transparent for clarity purposes.
- 1. Inspect coolant weep hole (B). Clean weep hole if blocked.
- 2. Coolant leakage indicates a damaged seal.
- 3. A slight weeping of coolant is normal. If enough coolant leaks from the weep hole that it drips from the engine, the coolant pump assembly should be replaced or repaired.
- 4. Wiggle coolant pump pulley (A). There should only be slight radial movement in the bearing. If bearing is loose, repair or replace coolant pump.



B—Weep Hole

A—Pullev

ZE59858,0000054 -19-07MAY14-1/1

Checking Open Crankcase Vent (OCV)


- Check all hoses (A), (B), (C), and (D) of open crankcase ventilation system for cracks, damage, and blockage.
- 2. Check all constant tension clamps (E), (F), (G), and (H) for its appropriate tension on the hoses.
- 3. Check filter housing for cracks and damage.
- 4. Inspect duckbill valve for leakage or blockage (I).

A-OCV Filter Inlet Hose

B—Oil Drain Hose C—OCV Filter Outlet Hose

Inlet Hose

- F—Constant Tension Clamp Oil Drain Hose
- G—Constant Tension Clamp Outlet Hose
- D—OCV Air Vent Hose E—Constant Tension Clamp —
- H—Constant Tension Clamp Air Vent Hose
- I— Duckbill Valve




Checking Engine Mounts

Engine mounting is the responsibility of the Original Equipment Manufacturer. Follow manufacturer's guidelines for mounting specifications.

IMPORTANT: Use only Grade SAE 8 or higher grade of hardware for engine mounting.

- 1. Check the engine mounting brackets (A), vibration isolators, and mounting bolts on support frame and engine block for tightness. Tighten as necessary.
- 2. Inspect overall condition of vibration isolators, if equipped. Replace isolators, as necessary, if rubber has deteriorated or mounts have collapsed.



A—Mounting Bracket

ZE59858,00002A2 -19-14NOV13-1/1

Checking Fan And Alternator V-Belt Tension

Low belt tension causes slippage resulting in excessive cover wear, burn spots, overheating, or "slip and grab", causing belt breakage.


High belt tension causes belt heating and excessive stretch, as well as damage to drive components such as pulleys and shafts. V-belts should ride on the sides of standard pulleys not on the bottom of the groove.

Standard V-belt tension can be checked with JDG529 Tension Gauge (bold arrow) or equivalent gauge. (Gauge is available from a John Deere Dealer or Distributor)

NOTE: On engines with dual belts, check tension of front belt only.

- 1. Inspect belts for cracks, fraying, or stretched out areas. Replace if necessary.
- Using JDG529 Belt Tension Gauge, or belt tension tester (A) and straightedge (B), check tension of warm belts:
 - a. When using JDG529 Belt Tension Gauge, measure belt tension and compare with specifications on next page.
 - b. Belt deflection when using belt tension tester (A) with straightedge (B), with force applied halfway between pulleys.

Specification



Continued on next page

ZE59858,0000059 -19-18SEP14-1/2

- 3. If adjustment is necessary, loosen alternator bracket cap screw (C) and nut (D) on mounting bolt. Pull alternator frame outward until belts are correctly tensioned.
- 4. Tighten alternator bracket cap screw and nut to specification.

Specification

Alternator Lower Bracket	
—Torque	30 N·m (22 lbft.)
Alternator Upper Bracket	
—Torque	


IMPORTANT: Do not pry against the alternator rear frame. Do not tighten or loosen belts while they are hot.

5. After a new or used belt has run for 10 minutes, recheck belt tension.

STANDARD V-BELTS

	New Belt Tension	Used Belt Tension ^a
Single Belt	578—623 N (130—140 lb force)	378—423 N (85—95 lb force)
Dual Belts	423—463 N (95—104 lb force)	378—423 N (85—95 lb force)


^aBelts are considered used after 10 minutes of operation.



ZE59858,0000059 -19-18SEP14-2/2

Checking Air Intake System

- IMPORTANT: The air intake system must not leak. Any leak, no matter how small, may result in internal engine damage due to abrasive dirt and dust entering the intake system.
- 1. Inspect all intake hoses (piping) for cracks. Replace as necessary.
- 2. Check clamps (A) on piping which connect the air cleaner, engine and, if present, turbocharger. Tighten clamps as necessary. This will help prevent dirt from entering the air intake system through loose connections causing internal engine damage.
- If engine has a rubber dust unloader valve (B), inspect the valve on bottom of air cleaner for cracks or plugging. Replace as necessary.
- IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.
- 4. Test air restriction indicator (C) for proper operation. Replace indicator as necessary.
- IMPORTANT: If not equipped with air restriction indicator, replace air cleaner elements at 500 Hours or at 12 Months, whichever occurs first.



JR74534,000025D -19-26APR10-1/1

Checking Engine Ground Connection

Check engine ground connection to be sure that it is secure and clean. This will prevent electrical arcing which can damage engine.

Verify engine to frame ground.

Verify battery ground to frame.

Verify Engine Control Unit to ground (Remote Mount).


RK80614,0000033 -19-11JUL13-1/1


Checking Cooling System

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

- IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head or plug in thermostat housing to allow air to escape when filling system. Retighten fitting or plug when all the air has been expelled. Cooling system must be free of air by time engine coolant temperature reaches 80 °C (176 °F).
- 1. Check entire cooling system for leaks. Tighten all clamps securely.





Radiator Cap-Maximum

Pressure...... 125 kPa (1.25 bar) (18 psi)


If gauge does not hold pressure, replace radiator cap.

3. Remove the cap from gauge, turn it 180°, and retest cap. This verifies that the first measurement was accurate.

Test Cooling System for Leaks

NOTE: Engine should be warmed up to test overall cooling system for leaks.

¹Test pressures recommended are for all Deere OEM cooling systems. On specific vehicle applications, test cooling system and pressure cap according to the recommended pressure for that vehicle.



- 1. Allow engine to cool, then carefully remove radiator
- 2. Fill radiator with coolant to the normal operating level.
- or expansion tank. Pressurize cooling system to the

4. With pressure applied, check all cooling system hose

If leakage is detected, correct as necessary and pressure test system again.


If no leakage is detected, but the gauge indicated a drop in pressure, coolant may be leaking internally within the system or at the block-to-head gasket. Have your servicing dealer or distributor correct this problem immediately.

DN28805,0001EF6 -19-23SEP14-1/1

Checking and Adjusting Engine Speeds

Use tachometer on the diagnostic gauge (A) to verify engine speeds. (See Engine Power and Speed Rating <u>Specifications</u> in the Specifications Section for engine speed specifications.) If engine speed adjustment is required, see your authorized servicing dealer or engine distributor.

A—Tachometer



Checking and Adjusting	Valve	Clearance
-------------------------------	-------	-----------


CAUTION: To prevent accidental starting of engine while performing valve adjustments, always disconnect NEGATIVE (—) battery terminal.

IMPORTANT: Valve clearance MUST BE checked and adjusted with engine COLD.

- 1. Remove fuel injector heat shield, crankcase ventilator tube, and rocker arm cover.
- 2. Remove plastic plug (A) from flywheel housing bores and install appropriate flywheel turning tool JDG820, or JDE83. Install JDG1571 or JDE81-4 flywheel timing pin.
- IMPORTANT: Visually inspect contact surfaces of valve tips and rocker arm wear pads. Check all parts for excessive wear, breakage, or cracks. Replace parts that show visible damage.

Rocker arms that exhibit excessive valve clearance should be inspected more thoroughly to identify damaged parts.

3. Rotate engine in operating direction, with the flywheel turning tool until locking pin engages timing hole in flywheel.




Bores to Insert Flywheel Turning Tool and Timing Pin

A—Plastic Plug C—Timing Pin Bore B—Flywheel Turning Tool Bore

- NOTE: If the rocker arms for No. 1 (front) cylinder are loose, the engine is at No. 1 top dead center compression.
- NOTE: If the rocker arms for No. 1 (front) cylinder are **NOT** loose, the engine is at No. 1 top dead center exhaust. Rotate the engine one full revolution (360°) to No. 1 top dead center compression.

Continued on next page


ZE59858,000005A -19-23SEP14-1/5



Valve Clearance Adjustment - No. 1 TDC

4. With engine locked at TDC of No. 1 piston compression stroke, use a bent feeler gauge to check valve clearance on No. 1 and 2 exhaust and No. 1 and 3 intake valves. Loosen lock nut (A) on rocker arm adjusting screw. Turn adjusting screw with a 4 mm hex key wrench until feeler gauge slips with a slight drag. Hold the adjusting screw from turning and tighten lock nut to specifications.


	Specification	
Intake Valve Clearance		
(Rocker Arm-to-Valve		
Tip With Engine Cold)		
-Clearance	0.35 mm	
	(0.014 in.)	
Exhaust Valve Clearance		
(Rocker Arm-to-Valve		A—Lock Nut
Tip With Engine		
Cold)—Clearance		<u> </u>
-	(0.018 in.)	Recheck
Valve Adjusting Screw	· · · · ·	Readjust
Lock Nut—Torque		
	C	ontinued on next page



A—Lock Nut

Recheck clearance again after tightening lock nut. Readjust clearance as necessary.

ZE59858,000005A -19-23SEP14-2/5



Valve Clearance Adjustment - No. 1 TDC Exhaust

- Using the flywheel turning tool, rotate engine in operating direction 360°, until locking pin engages timing hole in flywheel. No. 1 piston is at TDC of its exhaust stroke. Rocker arms for No. 1 piston should **NOT** be loose.
- Check and adjust valve clearance to the same specifications on for No. 3 exhaust and No. 2 intake valves.
- 7. Remove timing pin and flywheel turning tool. Replace plug in flywheel housing.
- 8. Lubricate valve components with a generous amount of engine oil.

ZE59858,000005A -19-23SEP14-3/5

9. Install a new gasket (C) onto the cylinder head (D). Do not use sealant on gasket.


IMPORTANT: Replace gasket (C) every time the rocker arm cover is removed.

- 10. Install rocker arm cover (B) onto the cylinder head
- 11. Finger start cap screws (A) through the rocker arm cover and gasket into the cylinder head. Tighten cap screws to specification starting form the center and moving towards both the front and rear ends of the cover.

Specification

12. Install Fuel Injector Heat Shield.

A—Cap Screws (8 used) B—Rocker Arm Cover C—Gasket D—Cylinder Head



Continued on next page

ZE59858,000005A -19-23SEP14-4/5

- 13. Engage the fuel injector heat shield (B) into the external groove (C) in the rocker arm cover.
- 14. Install cap screws (A) and tighten to specification.

Specification

Cap Screw —Torque......11 N·m (97 lb.-in.)


15. Install OCV inlet pipe. Lubricate new O-ring with engine oil and install OCV filter inlet tube into the rocker arm cover. Tighten M6 cap screw to specification.

Specification

M6 Cap Screw — Torque...... 15 N·m (133 lb.-in.)

16. Reconnect battery terminal.

A—Cap Screw (2 used) B—Fuel Injector Heat Shield C—External Groove



Changing Open Crankcase Ventilation (OCV) Filter

Service checks of the OCV include checking and/or replacement of worn, cracked, leaking, or bulging hoses and for good clamp tension on all hose ends.

Expectation for minimal service interval will be at least 1500 hours.

NOTE: OCV Filter must be replaced as an assembly. the filter inside is not serviceable.

Remove OCV Filter Assembly

- 1. Squeeze constant tension clamps (C) on both ends of the OCV filter outlet hose (E) with suitable tool and position clamps onto the OCV filter outlet tube (F). Remove the OCV filter outlet hose (E) from the OCV filter outlet hose barb and OCV filter outlet tube (F).
- 2. Squeeze constant tension clamps (C) on the OCV filter oil drain hose (K) with suitable tool and position clamp 50 mm (2.0 in.) from the end of the hose.


Remove the OCV filter oil drain hose (K) from the OCV filter assembly (J), inspect for damage.

3. Squeeze constant tension clamps (C) on both ends of OCV filter inlet hose (D) with suitable tool and position clamps onto the OCV filter inlet tube (A).

Remove the OCV filter inlet hose (D) from the hose barb of the OCV filter assembly (J) and the OCV filter inlet tube (A), inspect for damage.

4. Remove two cap screws (I) from the OCV filter assembly (J). Remove OCV filter assembly (J).

Continued on next page




Install OCV Filter Assembly

 Install two cap screws (I) through the OCV filter assembly (J) into the threaded holes in the intake manifold. Tighten cap screws to specification.

Specification

OCV Filter Assembly Mounting Cap Screws

- 2. Install two constant tension clamps (C) onto the OCV filter inlet tube (A).
- 3. Lubricate ID of both ends of OCV filter inlet hose (D).
- 4. Insert one end of OCV filter inlet hose (D) onto the hose barb of the OCV filter inlet tube (A). Install the other end onto the inlet hose barb of the OCV filter assembly (J).
- 5. Squeeze constant tension clamps (C) with suitable tool and position clamps 2—5 mm (0.08—0.20 in.) from the end of the hose.
- 6. Lubricate ID of the OCV filter oil drain hose (K). Install the oil drain hose (K) onto the OCV filter assembly (J).
- Squeeze constant tension clamp (C) with suitable tool and position clamps 2—5 mm (0.08—0.20 in.) from the end of the hose.
- 8. Lubricate ID of both ends of OCV filter outlet hose (E).
- 9. Insert one end of OCV filter outlet hose (E) onto the OCV filter outlet hose barb.
- 10. Install two constant tension clamps (C) onto the OCV filter outlet tube (F).
- 11. Install the OCV filter outlet hose (E) onto the OCV filter outlet tube(F).
- 12. Squeeze constant tension clamps (C) with suitable tool and position clamps 2—5 mm (0.08—0.20 in.) from the end of the hose.
- If necessary, orient OCV filter outlet tube (F). Install P-Clamp (N) around tube onto the intake manifold mounting stud. Install flanged head nut (G) and tighten to specification.



DN28805,0001EF7 -19-23SEP14-2/2

Flushing and Refilling Cooling System


CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.


NOTE: If COOL-GARD II is not used, the drain interval is reduced to 2000 hours or 24 months of operation.

Drain old coolant, flush the entire cooling system, test thermostats, and fill with recommended clean coolant per the following procedure.

- Pressure test entire cooling system and pressure cap if not previously done. See <u>Pressure Testing Cooling</u> <u>System</u> in the Lubrication & Maintenance — 500 Hours/12 Months Section.
- 2. Slowly open the engine cooling system filler cap or radiator cap (A) to relieve pressure and allow coolant to drain faster.



- 3. Remove engine block drain plug (B). Drain all coolant from engine block.
- 4. Open radiator drain valve. Drain all coolant from radiator.
- 5. Close all drain valves and reinstall plug after coolant has drained.
 - B—Cylinder Block Coolant Drain Plug



Continued on next page

ZE59858,000005B -19-24SEP14-2/3

- 6. Remove the coolant pump bypass tube from the thermostat housing (H). Remove cap screws (G), thermostat housing (H) and thermostat (I).
- Reinstall thermostat housing (H) and gasket (J) without the thermostat. Tighten cap screws (G) to specification. Reinstall the coolant pump bypass tube.

Specification

- 8. Test thermostat opening temperature. See <u>Testing</u> <u>Thermostat Opening Temperature</u> in the Lubrication & Maintenance — 6000 Hours/72 Months Section.
- 9. Fill the cooling system with clean water. Run the engine 10 minutes to stir up possible rust or sediment.

CAUTION: Do not run engine longer than 10 minutes. Doing so may cause engine to overheat which may cause burns when radiator water is draining.

- 10. Stop engine. Remove lower radiator hose and radiator cap. Immediately drain the water from system before rust and sediment settles.
- After draining water, reinstall radiator cap and radiator hose and clamp. Fill the cooling system with clean water and a heavy-duty cooling system cleaner such as Fleetguard® RESTORE[™] and RESTORE PLUS[™]. Follow manufacturer's directions on label.
- 12. Remove radiator cap and engine coolant drain plugs as stated in steps (3 and 4).
- 13. Install drain plug on engine block. Close drain valve on radiator. Tighten plugs to specification.


Specification

 Install thermostat and thermostat housing with new gasket. Tighten cap screws (G) to specification. Reinstall the coolant pump bypass tube.

Specification

Fleetguard is a trademark of Cummins Engine Company, Inc.

RESTORE is a trademark of Fleetguard. RESTORE PLUS is a trademark of Fleetguard.



Thermostat and Housing

F—Bypass Tube Seal G—M10 x 25 mm Cap Screw (2	l— Thermostat J— Gasket
used)	K—Cylinder Head
H—Thermostat Housing	-

- 15. Add coolant to surge tank. Coolant level should be at bottom of surge tank filler neck or radiator filler neck. If equipped with a translucent surge tank, coolant level should be at cool fill line indicator on surge tank. Install radiator cap. Coolant capacities can vary significantly, see your application operator's manual for coolant capacity.
- 16. Run engine until it reaches operating temperature. This mixes the solution uniformly and circulates it through the entire system. The normal engine coolant temperature range is 82°—95°C (180°—203°F).
- 17. After running engine, check coolant level and entire cooling system for leaks.

ZE59858,000005B -19-24SEP14-3/3

Testing Thermostat Opening Temperature

Removing Thermostat

1. Visually inspect area around thermostat housing for leaks.

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns. DO NOT drain coolant until it has cooled below operating temperature. Always loosen radiator pressure cap or drain valve slowly to relieve pressure.


2. Remove radiator pressure cap and partially drain cooling system.

Figh-Pressure Fluids

ZE59858,000005C -19-24SEP14-1/4

- 3. Remove coolant pump bypass tube from the thermostat housing (H). Remove cap screws (G) and thermostat housing (H). Clean and check housing for cracks or damage.
- 4. Remove thermostat (I) from the housing.

F— Bypass Tube Seal G—M10 x 25 mm Cap Screw (2 used) H—Thermostat Housing I— Thermostat J— Gasket K—Cylinder Head



Continued on next page

ZE59858,000005C -19-24SEP14-2/4

Testing Thermostat Opening Temperature

1. Visually inspect thermostat for corrosion or damage.


CAUTION: DO NOT allow thermostat or thermometer to rest against the side or bottom of container when heating water. Either may become damaged if overheated.

- 2. Suspend thermostat and a thermometer in a container of water.
- 3. Stir the water as it heats. Observe opening action of thermostat and compare with specifications.

Specification

Thermostat — Start to	
Open—Temperature	83°C (181°F)
Thermostat — Fully	
Open—Temperature	95°C (203°F)

- NOTE: Due to varying tolerances of different suppliers, initial opening and full open temperatures may vary slightly from specified temperatures.
- 4. Remove thermostat and observe its closing action as it cools. In ambient air the thermostat should close completely. Closing action should be smooth and slow.



Testing Thermostat Opening Temperature

5. Replace thermostat if defective.

ZE59858,000005C -19-24SEP14-3/4


Installing Thermostat

- 1. If necessary, install seal (F) into the thermostat housing.
- 2. Remove gasket material from cylinder head (K) and thermostat housing (H) surfaces.
- 3. Place thermostat (I) into recess in thermostat housing with jiggle pin on top for proper deaeration.
- 4. Apply Loctite ® fast drying black weather strip adhesive to the thermostat housing side of gasket (J).
- 5. Place gasket (J) onto thermostat housing (H). Allow adhesive to set.
- NOTE: Gasket holds thermostat in place during installation of thermostat housing onto the cylinder head.
- 6. Install cap screws (G) and tighten to specifications.

Specification


Thermostat Housing Cap

- 7. Reinstall coolant pump bypass tube.
- 8. Fill cooling system and check for leaks.
- IMPORTANT: Air must be expelled from cooling system when system is refilled. Loosen temperature sending unit fitting at rear of cylinder head to allow air to escape when



Additional Service Information

This is not a detailed service manual. If you want more detailed service information, contact your John Deere dealer or engine distributor.



OURGP11,0000048 -19-23AUG10-1/1

Do Not Modify Fuel System

CAUTION: Do not open high-pressure fuel system.

High-pressure fluid remaining in fuel lines can cause serious injury. Do not disconnect or attempt repair of fuel lines, sensors, or any other components between the high-pressure fuel pump and nozzles on engines with High Pressure Common Rail (HPCR) fuel system.


Only technicians familiar with this type of system can perform repairs. (See your John Deere dealer.)

IMPORTANT: Never steam clean or pour cold water on a high-pressure fuel pump while it is still warm. To do so may cause seizure of pump parts.

Modification or alteration of the high-pressure fuel pump (A), the injection timing, or the fuel injectors in ways not recommended by the manufacturer will terminate the warranty obligation to the purchaser.

In addition, tampering with fuel system which alters emission-related equipment on engines may result in fines or other penalties, per EPA regulations or other local emission laws.


Do not attempt to service fuel pump, fuel rail, or fuel injectors yourself. Special training and special tools are required. (See your authorized servicing dealer or engine distributor.)



Drain Water From Fuel Filter

- 1. Loosen drain valve (A) to drain water and debris as needed. If necessary, open air bleed screw to allow water to drain from separator.
- 2. Retighten drain valve securely.
- 3. Bleed air from the fuel system as required. See <u>Bleeding Fuel System</u> in Service As Required section.

A—Drain Valve B—Water Separator C—Primary Fuel Filter D—Air Bleed Screw



ZE59858,000005D -19-23SEP14-1/1

Bleeding Fuel System

CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting fuel or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

IMPORTANT: Do not operate the engine at high speeds or full loads just before bleeding the fuel system as this may cause fuel injection pump failure.

Bleed the fuel system anytime the fuel system has been opened up. This includes:



Keep Skin Away from High-Pressure Fluids

- After fuel filter changes.
- After pump or nozzle replacement.
- Anytime fuel lines have been disconnected.
- After engine has run out of fuel.

Bleed the fuel system using the following procedure:


Continued on next page

ZE59858,000005E -19-24SEP14-1/3

- 1. Loosen the air bleed vent screw (B) two full turns.
- 2. On mechanical supply pumps, operate supply pump primer lever (A) until fuel flow is free from air bubbles.
- 3. On electric supply pumps, turn key switch to "ON" position until fuel flow is free from air bubbles.
- 4. Tighten bleed screw securely by hand. Continue operating hand primer until pumping action is not felt. When finished, pull hand primer upward as far as it will go.
- 5. Start engine and check for leaks.


If engine does not start, it may be necessary to bleed air from fuel system at the high-pressure fuel pump.

A—Fuel Supply Pump Primer B—Air Bleed Screw Lever



Air Bleed Screw and Fuel Supply Pump Primer Lever

- 6. Disconnect high-pressure pump fuel inlet line (A).
- 7. Attach a fuel line to the fuel inlet line (A), and place other end in a 3.8 L (1.0 gal.) or larger container.
- 8. Manually prime the mechanical transfer pump until discharge stream of fuel into bucket is present without air bubbles.
- 9. Reinstall fuel inlet line and prime the high-pressure fuel pump.
- 10. With the ignition ON and the engine OFF, manually prime the mechanical transfer pump.
- 11. Crank the engine for 15 seconds. If engine does not start, perform step 6—10 as necessary. If engine does not start, see your John Deere dealer.



ZE59858,000005E -19-24SEP14-3/3

ZE59858,000005E -19-24SEP14-2/3

Adding Coolant

CAUTION: Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

IMPORTANT: Never pour cold liquid into a hot engine, as it may crack cylinder head or block. DO NOT operate engine without coolant for even a few minutes.

> John Deere Cooling System Sealer may be added to the radiator to stop leaks. DO NOT use any other stop-leak additives in the cooling system.

> Air must be expelled from cooling system when system is refilled and before running the engine is run at normal operating temperatures. Air will escape from the coolant system through an engine coolant vent line (if equipped) when the engine is idled. Allow approximately 30 minutes to ensure all air has escaped the system before returning the engine to normal service. If there is no engine coolant vent line installed on the engine (connected to the coolant surge tank) loosen the temperature sending unit fitting (rear of cylinder head) or a plug in thermostat housing to allow air to escape when filling the system. Retighten fitting or plug when all the air has been expelled.


Coolant level should be maintained to the bottom of the surge tank filler neck or radiator filler neck (A). If needed, add coolant as follows.

- 1. Loosen temperature sending unit fitting at rear of cylinder head to allow air to escape when filling system.
- IMPORTANT: When adding coolant to the system, use the appropriate coolant solution. (See ENGINE COOLANT SPECIFICATIONS in Fuels, Lubricants, and Coolant Section for mixing of coolant ingredients before adding to cooling system.)

Do not overfill cooling system. A pressurized system needs space for heat expansion without overflowing at top of radiator.



High-Pressure Fluids



A—Radiator Filler Neck

B—Radiator

- 2. Add coolant until level is at bottom of surge tank filler neck or radiator filler neck (A). If equipped with a translucent surge tank, coolant level should be at cool fill line indicator on surge tank.
- 3. Tighten plugs and fittings when air has been expelled from system.
- 4. Run engine until it reaches operating temperature.

JR74534,0000276 -19-07OCT10-1/1

Pre-Start Cleaning Guide

IMPORTANT: Before cleaning machine, allow ample time for hot surfaces to cool.

IMPORTANT: Do not direct high-pressure spray from hose output directly at or close to electrical connections and sensors.

Rigorous cleaning as needed is recommended. Clean more frequently during heavy machine use, and when weather conditions are dry.


- Check enclosed areas daily. Clean the engine and other enclosed areas of equipment to remove debris and any buildup of oil and grease. Keep the engine and engine compartment free of combustible material.
- Check for debris buildup daily on and around intake systems, exhaust systems, and intercooler piping systems. Verify that there are no holes or leaks in intake or exhaust systems. Do not allow debris to build up near hot exhaust components. Verify that hot exhaust components are cleaned as often as environmental conditions require.
- Inspect cooling system daily to determine whether cooling system needs cleaning. Visible buildup of residue that blocks airflow may degrade machine performance and requires more frequent cleaning depending on environmental conditions.

- Inspect difficult to observe areas daily as conditions may require additional cleaning care to remove debris.
- Check for oil and fuel leaks daily. Replace or repair any sources of leaks, including gaskets, seals, breather tubes, fittings, and fluid lines.

Maintenance and Service Reminders

- Keep surfaces free of grease and oil.
- Clean up after hydraulic and other fluid leaks.
- Fuel Lines Check for leaks, cracks, and kinks that require service before use.
- Fuel Pumps Check fittings, especially compression ring couplings, for cracks and leaks.
- Fuel Injectors Check pressure and return lines for signs of leaks.
- When servicing fuel filter or draining water separator, avoid fuel spills. Immediately clean up any fuel spill.
- Handle transmission and power steering fluids with care. Immediately clean up any spills, especially around fill points.
- Check for transmission case venting system seepage, transmission case leakage, power steering cylinder leakage, or power steering line leakage.
- Check for loose electrical connectors, damaged wiring, corrosion, and poor connections.


ZE59858,0000009 -19-20MAY13-1/1



RG,RG34710,5594 -19-18DEC13-2/2

Replacing Axial Seal Air Cleaner Filter Element

- IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator (A) shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.
- NOTE: This procedure applies to John Deere 2-stage axial seal air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.



Continued on next page


OURGP11,000013A -19-24SEP14-1/2

- 1. Remove wing nut and remove canister cover shown in small illustration inset.
- 2. Remove wing nut (A) and remove primary element (B) from canister.
- 3. Thoroughly clean all dirt from inside canister.
- NOTE: Some engines may have a dust unloader valve (C) on the air cleaner. If equipped, squeeze valve tip to release any trapped dirt particles.
- IMPORTANT: Remove secondary (safety) element (E) ONLY for replacement. DO NOT attempt to clean, wash, or reuse secondary element. Replacement of secondary element is usually necessary ONLY when primary element has a hole in it.
- To replace secondary element, remove retaining nut (D) and secondary element (E). Immediately replace secondary element with new element to prevent dust from entering air intake system.

Specification

Retaining Nut-Torque...... 20 N·m (177 lb.-in.)

- 5. Install new primary element and tighten wing nut securely. Install cover assembly and tighten retaining wing nut securely.
- IMPORTANT: Whenever the air cleaner has been serviced or had cover removed, ALWAYS fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.
- 6. If equipped, fully depress air restriction indicator reset button and release to reset indicator.
 - A—Wing Nut B—Primary Element C—Dust Unloader Valve
- D—Retaining Nut E—Secondary Element




Retaining Nut and Secondary Element

OURGP11,000013A -19-24SEP14-2/2

Replacing Radial Seal Air Cleaner Filter Element

- IMPORTANT: ALWAYS REPLACE primary air cleaner element when air restriction indicator shows a vacuum of 625 mm (25 in.) H₂O, is torn, or visibly dirty.
- NOTE: This procedure applies to John Deere 2-stage radial seal air cleaner kits. Refer to manufacturers' instructions for servicing air cleaners not supplied by John Deere.
- 1. Unlatch and remove dust cap/cover (A) of air cleaner.
- 2. Move end of filter (B) back and forth gently to break seal.
- 3. Pull filter (B) off outlet tube and out of housing.
- 4. Thoroughly clean all dirt from inside housing and from outlet bore.
- IMPORTANT: Remove secondary (safety) element (C) ONLY for replacement. DO NOT attempt to clean, wash, or reuse secondary element. Replacement of secondary element is usually necessary ONLY when primary element has a hole in it.
- 5. To replace secondary element (C), pull filter element out gently. Immediately replace secondary element with new element to prevent dust from entering air intake system.
- 6. Install new primary filter element. Apply pressure by hand at outer rim of filter.
- IMPORTANT: Do NOT use latches on cover to force filter into air cleaner. Using cover to force filter will damage cleaner housing.
- 7. Close housing with dust unloader valve aimed down and latch latches.
- IMPORTANT: Whenever the air cleaner has been serviced or cover has been removed, ALWAYS fully depress the air restriction indicator reset button (if equipped) to assure accurate readings.
- 8. If equipped, fully depress air restriction indicator reset button and release to reset indicator.




Cleaning the Exhaust Filter

The exhaust filter will require maintenance periodically. Some of the maintenance will be transparent to the operator. During continuous heavy loads and other conditions, the engine may create enough heat to naturally remove accumulated soot in the exhaust filter. When the exhaust filter has accumulated higher levels of soot, the display panel may request (depending on predefined user settings) an exhaust filter cleaning. During this request, the equipment is required to be located or moved to a suitable location with adequate ventilation.

To the right are symbols which may be seen on the operator interface.

- IMPORTANT: The area above and surrounding the engine during a manual exhaust filter cleaning should be free of any flammable objects as temperatures can reach as high as 550 °C (1022 °F).
- NOTE: For more information on the operator interface icons or exhaust filter cleaning procedures, please see the Aftertreatment System Section of this Manual, or the corresponding Component Technical Manual (CTM).



Replacing Fan Belt

- 1. Inspect belts for cracks, fraying, or stretched out areas. Replace if necessary.
- 2. Install new belt, making sure that belt is correctly seated in all pulley grooves. Text on belt (such as John Deere or part number) should be readable when standing at the front of the engine looking back toward the rear.
- NOTE: While belt is removed, inspect pulleys and bearings. Rotate and feel for hard turning or

any unusual sounds. If pulleys or bearings need replacement, see your John Deere dealer.

- Adjust belt tension. See <u>Checking Fan And Alternator</u> <u>V-Belt Tension</u> in Lubrication & Maintenance - 500 Hours -12 Months section.
- 4. Install fan guard if removed.
- 5. Start engine and check belt alignment.

ZE59858,000005F -19-27JUN14-1/1

Checking Fuses

Check the following fuses located in the control panel wiring harness. Replace defective fuses.

- Control Panel fuse 30 Amp
- **Checking Electrical Wiring And Connections**

Check for loose or corroded wiring and connectors. Tighten connections or replace wiring as needed. See your authorized servicing dealer for repairs.

Checking Air Compressors (If Equipped)

Air compressors are offered as options with John Deere OEM engines to provide compressed air to operate air-powered devices like vehicle air brakes.


Air compressors are engine-driven piston types. They are either air cooled or cooled with engine coolant. The compressors are lubricated with engine oil. The compressor runs continuously as gear or spline driven by the auxiliary drive of the engine but has "loaded" and "unloaded" operating modes. This is controlled by the vehicle's air system (refer to vehicle technical manual for complete air system checks and services).

See your John Deere engine distributor or servicing dealer for diagnostic and troubleshooting information. If diagnosis leads to an internal fault in the compressor, replace the complete compressor as a new or remanufactured unit.

- JDLink fuse 10 Amp
- ECU fuse 20 Amp
- Transient Voltage Protection (TVP) fuse 30 Amp

See <u>2.9 L Wiring Diagram 5</u> in the Troubleshooting Section.

ZE59858,00002D6 -19-06DEC13-1/1



General Troubleshooting Information

Troubleshooting engine problems can be difficult. An engine wiring diagram is provided in this section to help isolate electrical problems on power units using John Deere wiring harness and instrument (gauge) panel.

Later in this section is a list of possible engine problems that may be encountered accompanied by possible causes and corrections. The illustrated diagrams and troubleshooting information are of a general nature; final design of the overall system for your engine application may be different. See your engine distributor or servicing dealer if you are in doubt.

A reliable program for troubleshooting engine problems should include the following basic diagnostic thought process:

- Know the engine and all related systems.
- Study the problem thoroughly.
- Relate the symptoms to your knowledge of engine and systems.
- Diagnose the problem starting with the easiest things first.

- Double-check before beginning the disassembly.
- Determine cause and make a thorough repair.
- After making repairs, operate the engine under normal conditions to verify that the problem and cause was corrected.
- NOTE: All engines have electronic control systems which may send diagnostic trouble codes to signal problems (see <u>Diagnostic Trouble Codes (DTCs)</u> <u>— Operation</u> in the Troubleshooting Section).
 - 1. If fault codes are present, perform the suggested corrective actions.
 - 2. If this does not correct the engine problem, contact your servicing dealer.
 - 3. If engine has problems but no fault codes are displayed, see <u>Engine Troubleshooting</u> in the Troubleshooting Section for problems and solutions.

EP89502,0000001 -19-16SEP13-1/1

Diagnostic Trouble Codes (DTCs) — Listing

NOTE: Not all of these codes are used in all engine applications.

NOTE: Not all DTCs are listed below. See your application technical manual for more information.

There are several possible combinations of SPN and FMI codes. To use the table below, first write down the SPN and FMI codes you received from the engine diagnostic gauge. Locate each SPN and its associated definition. In the same way, locate the FMI and its associated definition.

FMI Code	FMI Name	
0	Extremely High	
1	Extremely Low	
2	Invalid	
3	Out of Range High	
4	Out of Range Low	
5	High Resistance	
6	Low Resistance	
7	Mismatch	
8	Signal Missing	
9	Loss of Communication	
10	Change Abnormal	
11	Activated	
12	Error	
13	Fault	
14	Incorrect Message	
15	Slightly High	
16	Moderately High	
17	Slightly Low	
18	Moderately Low	
19	Communication Error	
31	Condition Exists	

SPN Code	SPN Name
28	Digital Throttle Signal
29	Secondary Analog Throttle Signal
91	Primary Analog Throttle Signal
94	Low Pressure Fuel Signal
97	Water-in-fuel Signal
100	Engine Oil Pressure Signal
101	Crankcase Pressure Signal
102	Manifold Air Pressure Signal
105	Manifold Air Temperature Signal
108	Barometric Pressure Signal
110	Engine Coolant Temperature Signal
157	Fuel Rail Pressure Signal
158	ECU Power Down
168	Unswitched Battery Voltage
174	Fuel Temperature Signal
189	Engine Speed Derate
190	Engine Speed
237	VIN Security Data
611	Injector Drive #1
629	ECU EEPROM
636	Camshaft Position Signal
637	Crankshaft Position Signal
651	Injector #1
652	Injector #2
653	Injector #3
676	Cold Start Aid Drive Circuit
970	External Shutdown Commanded
971	External Derate Commanded
974	Remote Analog Throttle Signal Out of Range

Continued on next page

ZE59858,000006B -19-17APR14-1/2

1136	ECU Temperature Signal
1180	Calculated Turbocharger Turbine Inlet Temperature
1209	Exhaust Manifold Pressure Signal
1347	Suction Control Valve Circuit
1569	Engine Power Derate
2002-2253	Source Address 2-253
2797	Injector High Voltage Supply #1
3246	DPF Outlet Temperature
3251	DPF Differential Pressure Signal
3465	Exhaust Throttle Actuator Drive Circuit
3509	Sensor Supply #1 Voltage
3510	Sensor Supply #2 Voltage
3511	Sensor Supply #3 Voltage
3512	Sensor Supply #4 Voltage
3513	Sensor Supply #5 Voltage
3514	Sensor Supply #6 Voltage
3597	Injector Power Supply Voltage
3711	DOC Inlet Temp
3719	Calculated Soot Level
3720	Calculated Ash Level
3936	DPF Fault Occurrences
4765	DOC Inlet Temp
4766	DOC Outlet Temp
4795	DPF Missing
5018	DOC Fault Occurrences
5125	Sensor Supply #7 Voltage
5126	Sensor Supply #8 Voltage
5127	Sensor Supply #9 Voltage
5298	DOC Efficiency Fault
520629	Illegal Operation
522495	Exhaust Filter Temp Module

NOTE: Diagnostic gauge on instrument panel may also display text for communication faults, such as "CAN Bus FAILURE". Contact your servicing dealer.

ZE59858,000006B -19-17APR14-2/2

Diagnostic Trouble Codes (DTCs) — Operation

SPN/FMI CODES

Stored and active diagnostic trouble codes are output on the diagnostic gauge on the Deere electronic instrument panel according to the J1939 standard as a two-part code as shown on the tables on the following pages.

The first part is a Suspect Parameter Number (SPN) followed by a Failure Mode Identifier (FMI) code. In order to determine the exact failure, both parts (SPN and FMI) of the code are needed.

The SPN identifies the system or the component that has the failure; for example SPN 000110 indicates a failure in the engine coolant temperature circuit. The FMI identifies the type of failure that has occurred; for example FMI 03 indicates value out of range high. Combining SPN 000110 with FMI 03 yields a fault code "engine coolant temperature input voltage too high". A corrective action will also be displayed, "check sensor and wiring". If this check does not solve the engine fault, contact your servicing dealer.

Always contact your servicing dealer for help in correcting unsolved diagnostic trouble codes which are displayed for your engine.

DN28805,0001E6B -19-07FEB14-1/1

Intermittent Fault Diagnostics

Intermittent faults are problems that periodically "go away". A problem such as a terminal that intermittently doesn't make contact can cause an intermittent fault. Other intermittent faults may be set only under certain operating conditions such as heavy load, extended idle, etc. When diagnosing intermittent faults, take special note of the condition of wiring and connectors, since a high percentage of intermittent problems originates here. Check for loose, dirty, or disconnected connectors. Inspect the wiring routing, looking for possible shorts caused by contact with external parts (for example, rubbing against sharp sheet metal edges). Inspect the connector vicinity, looking for wires that have pulled out of connector terminals, damaged connectors, poorly positioned terminals, and corroded or damaged splices and terminals. Look for broken wires, damaged splices. and wire-to-wire shorts. Use good judgment if component replacement is thought to be required.

NOTE: The engine control unit (ECU) is the component LEAST likely to fail.

Suggestions for diagnosing intermittent faults:

- If diagnostic charts on preceding pages indicate that the problem is intermittent, try to reproduce the operating conditions that were present when the diagnostic trouble code (DTC) set.
- If a faulty connection or wire is suspected to be the cause of the intermittent problem: clear DTCs, then check the connection or wire by wiggling it while watching the diagnostic gauge to see if the fault resets.

Possible causes of intermittent faults:

- Faulty connection between sensor or actuator harness.
- Faulty contact between terminals in connector.
- Faulty terminal/wire connection.
- Electromagnetic interference (EMI) from an improperly installed 2-way radio, etc., can cause faulty signals to be sent to the ECU.
 - NOTE: Refer to wiring diagrams later in this section as a guide to connections and wiring.

RK80614,000004C -19-26AUG13-1/1

Engine Troubleshooting			n the corrective actions. (See earlier
NOTE: Before troubleshooting the en any fault codes on the diagnost			ion.) If any problems remain, use the harts to solve engine problems.
Symptom	Problem		Solution
Engine Will Not Crank	Low battery output volta discharged battery	age or	Charge or replace batteries.
	Loose or corroded conne	ections	Clean and tighten connections.
	Faulty start circuit relay		See your authorized John Deere engine distributor or servicing dealer.
	Blown fuse		Replace fuse.
	Defective main switch or switch	r start safety	Repair switch as required.
	Starter solenoid defectiv	e	Replace solenoid.
	Starter defective		Replace starter.
Starter Cranks Slowly	Low battery output volta discharged battery	age or	Charge or replace batteries.
	Too high viscosity cranke	case oil	Drain crankcase oil and replace with correct viscosity oil.
	Loose or corroded conne	ections	Clean and tighten connections.
Hard to Start or Will Not Start	Engine starting under loa	ad	Disengage PTO.
	Improper starting proced	lure	Review starting procedure.
	Exhaust restricted		Check and correct exhaust restriction.
	No fuel		Check fuel tank.
	Air in fuel line		Bleed fuel lines.
	Poor fuel quality		Drain fuel and replace with proper grade and quality of fuel for operating condition.
	Water, dirt, or air in fuel	system	Drain, flush, fill, and bleed fuel system.
	Fuel filter restricted or fu	ll of water	Replace fuel filter or drain water from fuel filter.
	Dirty or faulty fuel injecto	ors	See your authorized John Deere engine distributor or servicing dealer.
	Electronic fuel system pr	roblem	See your authorized John Deere engine distributor or servicing dealer.

Continued on next page

ZE59858,0000075 -19-23SEP14-1/11

	5	
Symptom	Problem	Solution
	Cold weather	Use cold weather starting aids. See <u>Cold Weather Operation</u> in the Engine Operation Section.
	Too high viscosity crankcase oil	Drain crankcase oil and replace with correct viscosity oil.
	Electronic Control System Problem or Basic Engine Problem	See your authorized John Deere engine distributor or servicing dealer.
Engine Misfiring or Runs Irregularly	Poor fuel quality	Incorrect fuel/dirty fuel
		Test fuel, drain water from fuel bowl.
	Restricted fuel filter	Replace fuel filter element.
	Water, dirt, or air in fuel system	Drain, flush, fill, and bleed fuel system.
	Low coolant temperature	Remove and check thermostat.
	Dirty or faulty fuel injectors	See your authorized John Deere engine distributor or servicing dealer.
	Electronic fuel system problem	See your authorized John Deere engine distributor or servicing dealer.
	Electronic Control System problem or basic engine problem	See your authorized John Deere engine distributor or servicing dealer.
Lack of Engine Power	Intake air restriction	Service air cleaner.
	Exhaust restricted	Check and correct exhaust restriction.
	Poor fuel quality	Drain fuel and replace with proper grade and quality of fuel for operating condition.
	Restricted fuel filter	Replace fuel filter elements.
	Engine overloaded	Reduce engine load.
	Improper crankcase oil	Drain crankcase oil and replace with correct viscosity oil.
	Low coolant temperature	Remove and check thermostat.
	Improper valve clearance	Adjust valve clearance. See <u>Adjusting</u> <u>Valve Clearance</u> in the Lubrication & Maintenance — 2000 Hours/24 Months.
	Dirty or faulty fuel injectors	See your authorized John Deere engine distributor or servicing dealer.
	Continued on next page	ZE59858.0000075 -19-23SEP14-2/11

Continued on next page

ZE59858,0000075 -19-23SEP14-2/11

	5	
Symptom	Problem	Solution
	Turbocharger not functioning properly	See your authorized John Deere engine distributor or servicing dealer.
	Air leak in engine intake or exhaust manifold	Check intake and exhaust manifold gaskets and manifolds; repair as required. See your authorized John Deere engine distributor or servicing dealer.
	Engine is in derate due to DTC	See your authorized John Deere engine distributor or servicing dealer.
	Electronic Control System problem or basic engine problem	See your authorized John Deere engine distributor or servicing dealer.
Engine Idles Poorly	Poor fuel quality	Drain fuel and replace with proper grade and quality of fuel for operating condition.
	Electronic control system problem or basic engine problem	See your authorized John Deere engine distributor or servicing dealer.
Excessive Fuel Consumption	Engine overloaded	Reduce engine load.
	Air cleaner restricted or dirty	Replace air cleaner element as required.
	Compression too low	Determine cause of low compression and repair as required.
	Leaks in fuel supply system	Locate source of leak and repair as required.
	Improper type of fuel	Drain fuel and replace with proper grade and quality of fuel for operating condition.
	Poor fuel quality	Drain fuel and replace with proper grade and quality of fuel for operating condition.
	Improper valve clearance	Adjust valve clearance. See <u>Adjusting</u> <u>Valve Clearance</u> in the Lubrication & Maintenance — 2000 Hours/24 Months.
	Dirty or faulty fuel injectors	See your authorized John Deere engine distributor or servicing dealer.
	Electronic fuel system problem	See your authorized John Deere engine distributor or servicing dealer.
	Electronic Control System problem or basic engine problem	See your authorized John Deere engine distributor or servicing dealer.
	Continued on next page	ZE59858,0000075 -19-23SEP14-3/11

65-7

	-	
Symptom	Problem	Solution
	Turbocharger not functioning properly	Inspect turbocharger. See your authorized John Deere engine distributor or servicing dealer.
	Low engine temperature	Remove and check thermostat.
Fuel in Oil	Restricted fuel return line	Check and fix fuel return lines.
	Engine load too light	Increase engine load
	Leaking fuel injectors	See your authorized John Deere engine distributor or servicing dealer.
Low-Pressure Fuel System — Fuel Pressure Low	Restricted fuel filter	Replace fuel filter.
	Restricted fuel line	Locate restriction, repair as required.
	Faulty transfer pump	See your authorized John Deere engine distributor or servicing dealer.
	Faulty high-pressure fuel pump	Remove fuel pump, repair/replace pump as required. See your authorized John Deere engine distributor or servicing dealer.
Abnormal Engine Noise	Worn main or connecting rod bearings	Determine bearing clearance. See your authorized John Deere engine distributor or servicing dealer.
	Excessive crankshaft end play	Check crankshaft end play. See your authorized John Deere engine distributor or servicing dealer.
	Loose main bearing caps	Check bearing clearance; replace bearings and bearing cap screws as required. See your authorized John Deere engine distributor or servicing dealer.
	Worn connecting rod bushings and piston pins	Inspect piston pins and bushings. See your authorized John Deere engine distributor or servicing dealer.
	Scored pistons	Inspect pistons. See your authorized John Deere engine distributor or servicing dealer.
	Worn timing gears or excess backlash	Check timing gear back lash. See your authorized John Deere engine distributor or servicing dealer.

Continued on next page

ZE59858,0000075 -19-23SEP14-4/11

Symptom	Problem	Solution
	Excessive valve clearance	Check and adjust valve clearance. See <u>Adjusting Valve Clearance</u> in the Lubrication & Maintenance 2000 Hours/24 Months Section.
	Worn camshaft lobes	Inspect camshaft. See your authorized John Deere engine distributor or servicing dealer.
	Worn rocker arm shaft(s)	Inspect rocker arm shafts. See your authorized John Deere engine distributor or servicing dealer.
	Worn valve guides	Check valve guides for wear. See your authorized John Deere engine distributor or servicing dealer.
	Damaged valve retainers	Inspect retainer and retainer locks for excessive wear. See your authorized John Deere engine distributor or servicing dealer.
	Loose or worn rocker arms	Inspect rocker arms for wear. See your authorized John Deere engine distributor or servicing dealer.
	Bent pushrods	Inspect pushrods for straightness and check contact ends for wear and damage. See your authorized John Deere engine distributor or servicing dealer.
	Broken valve springs	Inspect valve springs. See your authorized John Deere engine distributor or servicing dealer.
	Bent connecting rods	Inspect connecting rod and cap for damage. See your authorized John Deere engine distributor or servicing dealer.
	Worn flywheel	Inspect flywheel and ring gear for damage. See your authorized John Deere engine distributor or servicing dealer.
	Loose flywheel	Check flywheel mounting screws. See your authorized John Deere engine distributor or servicing dealer.
	Excessive piston to liner clearance	Check and adjust piston liner clearance. See your authorized John Deere engine distributor or servicing dealer.

Continued on next page

ZE59858,0000075 -19-23SEP14-5/11

	in eacheening	
Symptom	Problem	Solution
	Excessive thrust bearing clearance	Check and adjust thrust bearing clearance. See your authorized John Deere engine distributor or servicing dealer.
	High oil viscosity	Drain engine oil and refill with correct viscosity engine oil
Turbocharger "Screams"	Leak in intake air system	Check air system for loose clamps, damaged tubes, charged air cooler leaks, and intake manifold gasket leaks; repair as required. See your authorized John Deere engine distributor or servicing dealer.
Turbocharger Noise or Vibration		Determine cause of lack of lubrication;
NOTE: Do not confuse the whine heard during run down with noise which indicates a bearing failure.	pressure)	repair as required. See your authorized John Deere engine distributor or servicing dealer.
The whine heard during turbocharger run down is normal.		
	Air leak in engine intake or exhaust manifold	Check intake and exhaust manifold gaskets and manifolds; repair as required. See your authorized John Deere engine distributor or servicing dealer.
	Improper clearance between turbine wheel and turbine housing	Inspect turbocharger; repair/replace as required. See your authorized John Deere engine distributor or servicing dealer.
	Broken blades (or other wheel failures)	Inspect turbocharger; repair/replace as required. See your authorized John Deere engine distributor or servicing dealer.
Engine has reached Service Only Soot Level	Auto Filter cleaning is disabled for an extended period of time	Enable exhaust filter cleaning.
	Frequent engine shut downs occurred while auto cleaning was in process	Let engine run for 30 min to clean the exhaust filter.
	Interlock switches are not properly set to allow DPF recovery/Regeneration to occur	Machine must be stationary (Parked). Engine speed must be above the minimum setpoint. Any PTO driven device must be shut off. Engine load must be stable.
Engine Emits White Smoke	Engine compression too low	Determine cause of low compression and repair as required. See your authorized John Deere engine distributor or servicing dealer.

Continued on next page

ZE59858,0000075 -19-23SEP14-6/11

Symptom	Problem	Solution
	Defective thermostat(s) (does not close)	Test thermostats; replace thermostats as required.
	Coolant entering combustion chamber (failed cylinder head gasket or cracked cylinder head)	
	Electronic Control System problem or basic engine problem	See your authorized John Deere engine distributor or servicing dealer.
	Improper type of fuel	Drain fuel and replace with proper grade and quality of fuel for operating condition.
	Poor fuel quality	Drain fuel and replace with proper grade and quality of fuel for operating condition.
	Low engine temperature	Warm up engine to normal operating temperature.
	Defective thermostat.	Remove and check thermostat.
	Defective fuel injectors	See your authorized John Deere engine distributor or servicing dealer.
Engine Emits Black, Gray or Blue Smoke	Engine overloaded	Reduce engine load.
Shioke	Engine burning oil	See your authorized John Deere engine distributor or servicing dealer.
	Air cleaner restricted or dirty	Replace air cleaner element as required.
	Electronic control system problem or basic engine problem	See your authorized John Deere engine distributor or servicing dealer.
	Exhaust filter is cracked or damaged	See your authorized John Deere engine distributor or servicing dealer.
	Improper type of fuel	Use proper fuel.
	Fuel injectors dirty	See your authorized John Deere engine distributor or servicing dealer.
	Electronic Control System problem or basic engine problem	See your authorized John Deere engine distributor or servicing dealer.
	Turbocharger not functioning properly	See your authorized John Deere engine distributor or servicing dealer.
Engine Overheats	Air cleaner restricted or dirty	Replace air cleaner element as required.

Continued on next page

ZE59858,0000075 -19-23SEP14-7/11

	9	
Symptom	Problem	Solution
	Lack of coolant in cooling system	Fill cooling system to proper level. Check radiator and hoses for loose connections or leaks.
	Low engine oil level	Check oil level. Add oil as required.
	Radiator core dirty	Clean cooling system as required.
	Cooling system needs flushing	Flush coolant system. (See <u>Flushing</u> <u>And Refilling Cooling System</u> in the Lubrication & Maintenance — 6000 Hours/72 Months Section.)
	Engine overloaded	Reduce engine load.
	Loose or defective fan belt	Check fan and alternator V-belt tension. Replace as required. (See <u>Checking Fan And Alternator</u> <u>V-Belt Tension</u> in the Lubrication & Maintenance — 500 Hours/12 Months Section.)
	Defective or wrong type of thermostat	Test thermostat opening temperature, replace thermostat as required.
	Damaged cylinder head gasket	Replace cylinder head gasket. See your authorized John Deere engine distributor or servicing dealer.
	Leak at cylinder head gasket	Replace cylinder head gasket. See your authorized John Deere engine distributor or servicing dealer.
	Defective coolant pump	Replace coolant pump. See your authorized John Deere engine distributor or servicing dealer.
	Defective radiator cap	Replace radiator cap as required.
	Defective temperature gauge or sender	Check coolant temperature with thermometer and replace, if necessary.
	Incorrect grade of fuel	Use correct grade of fuel.
Coolant Temperature Below Normal	Defective thermostat	Test thermostat, replace thermostat as required.
	Defective temperature gauge or temperature sender	Check gauge, sender, and connections.
Coolant in Crankcase	Cylinder head gasket defective	Replace cylinder head gasket. See your authorized John Deere engine distributor or servicing dealer.

Continued on next page

ZE59858,0000075 -19-23SEP14-8/11

reaseshooling		
Symptom	Problem	Solution
	Cylinder head or block cracked	Locate crack, repair/replace components as required. See your authorized John Deere engine distributor or servicing dealer.
	Cylinder liner seals leaking	Remove and inspect cylinder liners. See your authorized John Deere engine distributor or servicing dealer.
	Pitted cylinder liners	Remove and inspect cylinder liners. See your authorized John Deere engine distributor or servicing dealer.
	Leaking oil cooler	Pressure test oil cooler, repair/replace as required. See your authorized John Deere engine distributor or servicing dealer.
Low Oil Pressure	Low crankcase oil level	Fill crankcase to proper oil level.
	High crankcase oil level	Fill crankcase to proper oil level.
	Faulty pressure sensor	Replace sensor. See your authorized John Deere engine distributor or servicing dealer.
	Restricted oil cooler or filter	Remove and inspect oil cooler. See your authorized John Deere engine distributor or servicing dealer.
	Excessive oil temperature	Remove and inspect oil cooler. See your authorized John Deere engine distributor or servicing dealer.
	Defective oil pump	Remove and inspect oil pump. See your authorized John Deere engine distributor or servicing dealer.
	Incorrect oil	Drain crankcase and refill with correct oil.
	Oil pressure regulating valve failure	Remove and inspect oil pressure regulating valve. See your authorized John Deere engine distributor or servicing dealer.
	Restricted oil pump screen or cracke pick-up tube	d Remove oil pan and clean screen/replace pick-up tube.
	Excessive main or connecting rod bearing clearance	Determine bearing clearance. See your authorized John Deere engine distributor or servicing dealer.

Continued on next page

ZE59858,0000075 -19-23SEP14-9/11

Troubleshooting

	ricasiconicounig	
Symptom	Problem	Solution
	Crankcase oil level too high	Check engine oil level and drain as necessary.
High Oil Pressure	Improper oil classification	Drain crankcase and refill with correct oil.
	Faulty pressure sensor	Replace sensor. See your authorized John Deere engine distributor or servicing dealer.
	Oil pressure regulating valve failure	Remove and inspect oil pressure regulating valve. See your authorized John Deere engine distributor or servicing dealer.
	Stuck or damaged filter bypass valve	Remove and inspect filter bypass valve. See your authorized John Deere engine distributor or servicing dealer.
	Stuck or damaged oil cooler bypass valve	Remove and inspect oil cooler bypass valve. See your authorized John Deere engine distributor or servicing dealer.
Excessive Oil Consumption	Too low viscosity crankcase oil	Drain crankcase and refill with correct viscosity oil.
	Crankcase oil level too high	Drain oil until oil level is correct.
	External oil leak(s)	Determine source of oil leak(s) and repair as required.
	Excessive oil pressure	See High Oil Pressure
	Oil control rings not seated	See your authorized John Deere engine distributor or servicing dealer.
	Oil control rings worn or broken	Replace piston rings. See your authorized John Deere engine distributor or servicing dealer.
	Restricted crankcase vent tube or filter.	Clean vent tube and change crankcase ventilation filter, verify that crankcase oil level is not too high.
	Defective turbocharger	See your authorized John Deere engine distributor or servicing dealer.
	Scored cylinder liners or pistons	Remove and inspect cylinders and liners; replace as required. See your authorized John Deere engine distributor or servicing dealer.

Continued on next page

ZE59858,0000075 -19-23SEP14-10/11

Troubleshooting

	5	
Symptom	Problem	Solution
	Worn valve guides or stems	Inspect and measure valve stems and valve guides; repair as required. See your authorized John Deere engine distributor or servicing dealer.
	Piston ring grooves excessively worn	Remove and inspect pistons. See your authorized John Deere engine distributor or servicing dealer.
	Piston rings sticking in ring grooves	Remove and inspect pistons. See your authorized John Deere engine distributor or servicing dealer.
	Insufficient piston ring tension	Remove and inspect pistons. See your authorized John Deere engine distributor or servicing dealer.
	Piston ring gaps not staggered	Remove and inspect pistons. See your authorized John Deere engine distributor or servicing dealer.
	Front and/or rear crankshaft oil seal faulty	Replace oil seals. See your authorized John Deere engine distributor or servicing dealer.
Undercharged Electrical System	Excessive electrical load from added accessories	Remove accessories or install higher output alternator. See your authorized John Deere engine distributor or servicing dealer.
	Excessive engine idling	Increase engine rpm when heavy electrical load is used.
	Poor electrical connections on battery, ground strap, starter, or alternator	Inspect and clean as necessary.
	Defective battery	Test batteries.
	Defective alternator	Test charging system.
Battery Used Too Much Water	Cracked battery case	Check for moisture and replace as necessary.
	Defective battery	Test battery.
	Battery charging rate too high	Test charging system.
Batteries Will Not Charge	Loose or corroded connections	Clean and tighten connections.
	Sulfated or worn-out batteries	Replace batteries.
	Stretched belt or defective belt tensioner	Adjust belt tension or replace belts.


ZE59858,0000075 -19-23SEP14-11/11


Symptom	Problem	Solution
Starter and Hourmeter Functions; Rest of Electrical System Does Not Function	Blown fuse	Replace fuse.
Entire Electrical System Does Not Function	Faulty battery connection	Clean and tighten connections.
	Sulfated or worn-out batteries	Replace batteries.
	Blown fuse	Replace fuse.
		ZE59858,0000075 -19-23SEP14-12/11


Precautions for Electrical System When Steam Cleaning Engine


IMPORTANT: Do not steam clean any electrical or electronic components while steam cleaning the engine as it could damage sensitive parts.


OURGP11,000012A -19-24AUG10-1/1











Precautions for Welding

Remove paint before welding or heating (see Safety Section in this manual for more information on paint removal and high-pressure lines).

CAUTION: Avoid potentially toxic fumes and dust. Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch. Do all work outside or in a well ventilated area. Dispose of paint and solvent properly. If you sand or grind paint, avoid breathing the dust by wearing an approved respirator. If you use solvent or paint stripper, remove with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area before welding. Allow fumes to disperse at least 15 minutes before welding or heating.

IMPORTANT: Welding on the engine is NOT ALLOWED. If welding must be performed on the machine, follow these precautions.


IMPORTANT: High currents or electrostatic discharge into electronic components from welding may cause permanent damage.

- 1. Remove paint from the area to be welded and ground cable clamp location.
- 2. Disconnect the negative (-) battery cable(s) or open battery (-) switch if equipped.





- 3. Disconnect the positive (+) battery cable(s) or open battery (+) switch if equipped.
- 4. Clear or move any wiring harness sections away from the welding area.
- 5. Welding on engine components is not allowed.
- 6. Never connect the welder ground to any engine component or engine driven components that may be connected to the engine.
- 7. After welding, reverse steps 2-3.


DX,WELDING,PRECAUTIONS -19-06DEC10-1/1




A5501-09— [5410 Black] Wiring Shield A5501-12— [5030 Black] Wiring Shield	A5501-30— [5448 Gray] Crankshaft Position Sensor Return A5501-33— [5494 Yellow] Injector #2 Pulse	Crankshaft Position Sensor Signal A5501-53— [5445 Green] Camshaft Position Sensor Signal B5301— Crankshaft Position Sensor B5301A— Crankshaft Position	C01— Fuel Injector #1 C02— Fuel Injector #2 C03— Fuel Injector #3 Y5002— Suction Control Valve Y5021— Fuel Injector Harness Connector
			ZE59858,0000061 -19-17SEP14-2/2








A5501— ECU Connector 1 A5501-02— [5018 Gray] Exhaust Throttle Actuator Drive Negative A5501-04— [5016 Blue] Exhaust Throttle Actuator Drive Positive A5501-10— [5786 Blue] Exhaust Filter Temperature Module Signal	A5501-19— [5633 Orange] 5 V Sensor Supply #3 Return A5501-20— [5783 Orange] 10 V Sensor Supply A5501-52— [5631 Brown] 5 V Sensor Supply #3 Positive A5502— ECU Connector 2 A5502-03— [5785 Green] DPF Differential Pressure Sensor Signal	A5502-12— [5509 White] Exhaust Throttle Actuator Position Signal A5502-31— [5474 Yellow] 5 V Sensor Supply #6 Return A5502-41— [5437 Violet] 5 V Sensor Supply #6 Positive B5109— DPF Differential Pressure Sensor	B5109A— DPF Differential Pressure Sensor Interconnect B5204— Exhaust Filter Temperature Module B5204A— Exhaust Filter Temperature Module Interconnect Y5402— Exhaust Throttle Actuator
			ZE59858,0000064 -19-17SEP14-2/2



A— [5412 Red] Alternator	A550
Excitation To 2.9 L Wiring	A
Diagram 6	A550
A5501— ECU Connector 1	
A5501-28— [5637 Violet] Sensor	В—
Return #4	v
A5501-46— [5671 Brown] Cold	C—
Start Aid Relay Drive	Т
Positive	Е—
A5503— ECU Connector 3	ι
A5503-13— [5022 Red] ECU	L
Power Positive	F —
A5503-14— [5022 Red] ECU	Ū
Power Positive	v
A5503-23— [5022 Red] ECU	F500
Power Positive	
A5503-24— [5022 Red] ECU	F500
Power Positive	
A5503-27— [5050 Black] Battery	
,	
Negative	

 5503-43— [5050 Black] Battery Negative 5503-44— [5050 Black] Battery Negative - [5422 Red] Start To 2.9 L Wiring Diagram 6 - [5050 Black] Battery Negative To 2.9 L Wiring Diagram 6 - [5092 Red] JD Link Unswitched Power To 2.9 L Wiring Diagram 6 - [5002 Red] Control Panel Unswitched Power To 2.9 L Wiring Diagram 6 000— Control Panel Fuse (30 Amp) 001— Transient Voltage Protection Fuse (30 Amp) 	F5004— JD Link Fuse (10 Amp) F5010— Cold Start Aid Fuse (50 Amp) F5012— ECU Power Fuse (20 Amp) G— [5002 Red] Control Panel Unswitched Power To 2.9 L Wiring Diagram 7 G5000— Battery G5000— Battery G5000— Battery G5001— Battery Power Positive G5001— Alternator K5801— Starter Relay K5801-1— [5777 Violet] Starter Excitation K5803— Cold Start Aid Relay R5604— Cold Start Aid Relay Connector	R5607— Cold Start Aid V5700— Transient Voltage Protection X5002— Alternator Excitation Interconnect X5009— Alternator Excitation X5069— Fuse Block Assembly X5069—B12— [5332 Red] Transient Voltage Protection X5800— Starter Relay Coil (Power) X5801— Starter Relay Coil (Ground) Y5017— Starter Solenoid	_

ZE59858,0000065 -19-17SEP14-2/2





Troubleshooting

A— [5412 Red] Alternator	A5503-18— [5019 White] Variabl
Excitation From 2.9 L Wiring	Speed Fan Signal
Diagram 5	A5503-19— [5027 Violet] PTO
A5503— ECU Connector 3	Speed
A5503-01— [5905 Green] Primary	/ A5503-20- [5436 Blue] Engine
CAN Low	Coolant Level Switch
A5503-02— [5904 Yellow] Primary	y A5503-21— [5020 Black] Primar
CAN High	CAN Shield
A5503-03— [5024 Yellow] Remote	e A5503-22— [5936 Blue] Cruise
Throttle	Resume/Bump Down
A5503-04— [5044 Yellow] Wait To	Switch
Start Lamp	A5503-28— [5911 Brown] 5
A5503-05— [5473 Orange] Stop	V Sensor Supply #5
Engine Lamp	Positive
A5503-06— [5916 Blue] Warning	A5503-31— [5948 Gray] Cruise
Lamp	External Override
A5503-07— [5012 Red] Key	A5503-32— [5955 Green] Set
Switch	Accelerator/Bump Up
A5503-08— [5981 Brown] PWM	Switch
Throttle/Alternator	A5503-33— [5814 Yellow] 5 V
Feedback	Sensor Supply #4 Retur
A5503-09— [5913 Orange]	A5503-34— [5714 Yellow] 5 V
Secondary Throttle	Sensor Supply #5 Retur
A5503-10— [5915 Green] Primary	
Throttle	Tachometer
A5503-11— [5954 Yellow] Cruise	
On Switch	Speed Signal
A5503-12— [5943 Orange] Cruise	
Brake Switch	Multi-State Throttle
A5503-15— [5018 Gray] Variable	
Speed Fan Clutch Contro	0I


beed Fan Signal – [5027 Violet] PTO beed – [5436 Blue] Engine bolant Level Switch – [5020 Black] Primary AN Shield – [5936 Blue] Cruise issume/Bump Down witch – [5911 Brown] 5 Sensor Supply #5 bitive – [5948 Gray] Cruise isternal Override – [5955 Green] Set iscelerator/Bump Up witch – [5814 Yellow] 5 V ensor Supply #4 Return – [5714 Yellow] 5 V	 A5503-38— [5917 Violet] Cruise Remote Switch A5503-39— [5971 Brown] Cruise Cancel/Resume Switch A5503-42— [5939 White] External Derate Switch A5503-45— [5036 Blue] Optional Sensor A5503-46— [5017 Violet] AC High Pressure Switch A5503-46— [5017 Violet] AC High Pressure Switch A5503-47— [5937 Violet] Isochronous Governor A5503-48— [5015 Green] Spare Driver Positive A5503-49— [5616 Blue] 5 V Sensor Supply #4 Positive A5503-51— [5941 Brown] External Shutdown Switch A5503-53— [5923 Orange] Bump Enable Switch A5503-54— [5918 Gray] Shutdown Override Switch B— [5422 Red] Start From 2.9 L Wiring Diagram 5 C— [5050 Black] Battery Negative From 2.9 L Wiring Diagram 5 	For Mating Connector I— To 2.9 L Wiring Diagram 9 For Mating Connector R5601— Primary CAN Terminator X5005— Diagnostic Connector X5007— Remote On/Off X5020— Auxiliary Connector X5021— Control Panel Connector X5021-B— [5032 Red] Fused Unswitched Power X5025— JD Link Connector Y5005— Variable Speed Fan

ZE59858,0000066 -19-17SEP14-2/2





H— From 2.9 L Wiring Diagram 6 For Mating Connector	S5009— External Derate Switch S5100— AC High Pressure Switch		X5020-Q— [5036 Blue] Optional Sensor
H5000— Stop Engine Lamp	U5000— PWM Throttle/Alternator	X5020-H- [5039 White] Vehicle	X5020-R— [5981 Brown] PWM
P5300— PTO Speed	Feedback	Speed Signal	Throttle/Alternator
P5301— Vehicle Speed	X5020— Auxiliary Connector	X5020-J— [5939 White] External	Feedback
R5001— Secondary Throttle	X5020-A— [5911 Brown] 5	Derate Switch	X5020-T— [5024 Yellow] Remote
R5002— Remote Throttle	V Sensor Supply #5	X5020-K— [5941 Brown] External	Throttle
S5011— Cruise External Override	Positive	Shutdown Switch	X5020-U— [5017 Violet] AC High
S5003— Cruise Cancel/Resume	X5020-B— [5012 Red] Key Switch	X5020-L— [5917 Violet] Cruise	Pressure Switch
Switch	X5020-C— [5714 Yellow] 5 V	Remote Switch	X5020-V— [5015 Green] Spare
S5004— Cruise On Switch		X5020-M— [5948 Gray] Cruise	Driver Positive
S5005— External Shutdown	X5020-D— [5971 Brown] Cruise	External Override	X5020-W— [5473 Orange] Stop
Switch	Cancel/Resume Switch	X5020-N— [5436 Blue] Engine	Lamp
S5006— Cruise Remote Switch	X5020-E— [5954 Yellow] Cruise	Coolant Level Switch	X5020-X— [5050 Black] Battery
S5007— Cruise Brake Switch	On Switch	X5020-O— [5943 Orange] Cruise	Negative
S5008— Isochronous/Droop	X5020-F— [5913 Orange]	Brake Switch	
Governor Switch	Secondary Throttle	X5020-P— [5937 Violet]	
		Isochronous Governor	
			ZE59858,0000068 -19-17SEP14-2



A5504-01— [Red] Voltage Positive A5504-03— [White] Data Positive A5504-04— [Orange] Data Negative A5504-06— [Black] Single Point Ground I— From 2.9 L Wiring Diagram 6	Switch S5012— Speed Select Switch S5013— Bump Enable Switch X5021— Control Panel Connector X5021-B— [022 White] Fused Unswitched Power X5021-C— [914 White] 5 V Sensor Supply #4 Return X5021-D— [422 White] Start X5021-E— [050 White] Battery Negative X5021-F— [020 White] Primary	Throttle X5021-M— [911 White] 5 V Sensor Supply #4 Positive X5021-N— [918 White] Shutdown Override Switch X5021-P— [464/914 White] 5 V Sensor Supply #5 Return X5021-R— [947 White] Multi-State Throttle X5021-S— [414/914 White] 5 V	Resume/Bump Down Switch X5021-U— [905 White] Primary CAN Low X5021-V— [904 White] Primary CAN High X5021-W— [955 White] Set Accelerator/Bump Up
	CAN Shield	Sensor Supply #5 Return	ZE59858,0000069 -19-17SEP14-2/2

Engine Storage Guidelines

- IMPORTANT: Special considerations should be taken prior to storage when using BioDiesel. See <u>BioDiesel Fuel</u> in the Fuels, Lubricants, and Coolant Section.
- 1. John Deere engines can be stored outside for up to three months with no long-term preparation if covered by a waterproof covering. No outside storage is recommended without a waterproof covering.
- 2. John Deere engines can be stored in a standard overseas shipping container for up to three months with no long-term preparation.
- 3. John Deere engines can be stored inside for up to six months with no long-term preparation.
- John Deere engines expected to be stored more than six months must have long-term storage preparation. See <u>Preparing Engine for Long-Term Storage</u> in the Storage Section.

RK80614,0000060 -19-04FEB15-1/1

Preparing Engine for Long-Term Storage

- IMPORTANT: Any time the engine is not used for over six months, the following recommendations for storing it and removing it from storage helps to minimize corrosion and deterioration.
- IMPORTANT: Long-term storage is not advised when using BioDiesel. For storage longer than one year, use straight hydrocarbon fuel.

If BioDiesel must be used it is recommended the blend not exceed B7 and a high-quality fuel stabilizer be used. Storage should not exceed one year.

For more information see <u>BioDiesel Fuel</u> in the Fuels, Lubricants, and Coolants Section.

- NOTE: The following storage preparations are used for long-term engine storage up to one year. After that, the engine should be started, warmed up, and retreated for an extended storage period.
- Change engine oil and replace filter. Used oil does not give adequate protection. Add 30 mL of rust preventive oil to the engine crankcase for every 1 L of engine oil, or 1 oz of rust preventative oil per 1 qt. of engine oil. This rust preventive oil should be an SAE 10 oil with 1%-4% morpholine or equivalent vapor corrosion inhibitor.
- 2. Replace air cleaner.
- Draining and flushing of cooling system is not necessary if the engine is only stored for less than one year. However, for extended storage periods of a year or longer, it is recommended that the cooling system be drained, flushed, and refilled. Refill with appropriate coolant. See <u>Diesel Engine Coolant (engine with wet sleeve cylinder liners)</u> in the Fuels, Lubricants, and Coolants Section.
- 4. Prepare a solution of diesel fuel and rust preventive oil in a temporary container, add 78 mL of rust preventive

oil per 1 L of diesel fuel, 10 oz. of rust preventive oil per 1 gal. of diesel fuel.

5. Remove existing lines and plugs as required. Run a temporary line from the temporary container to the engine fuel intake before the fuel filters, and another temporary line from the fuel return to the temporary container, so rust preventive oil solution is circulated through the injection system during cranking.

IMPORTANT: Do not operate starter more than 30 seconds at a time. Wait at least 2 minutes for starter to cool before trying again.

6. Crank the engine several revolutions with starter. Do not allow the engine to start. This allows rust preventive oil solution to circulate.

See your authorized dealer for the proper procedure for your application.

- 7. Remove temporary lines installed in Step 5 above, and replace any lines or plugs previously removed.
- 8. Loosen (or remove) and store fan and alternator poly-vee belt.
- 9. Remove and clean batteries. Store them in a cool, dry place and keep them fully charged.
- 10. Disengage the clutch for any driveline.
- 11. Clean the exterior of the engine with salt-free water and touch up any scratched or chipped painted surfaces with a good quality paint.
- 12. Coat all exposed bare metal surfaces with grease or corrosion inhibitor if not feasible to paint.
- 13. Seal all openings on engine with plastic bags and tape.
- 14. Store the engine in a dry protected place. If engine must be stored outside, cover it with a waterproof canvas or other suitable protective material and use a strong waterproof tape.

ZE59858,00002D8 -19-04FEB15-1/1

Removing Engine from Long-Term Storage

NOTE: The following storage removal procedure is used for long-term engine storage up to one year. After that, the engine should be started, warmed up, and retreated for an extended storage period.

Refer to the appropriate section for detailed services listed below or have an authorized servicing dealer or engine distributor perform unfamiliar services.

- 1. Remove all protective coverings from engine. Unseal all openings in engine and remove covering from electrical systems.
- 2. Remove grease from all exposed metal surfaces.
- 3. Remove the batteries from storage. Install batteries (fully charged) and connect the terminals.
- 4. Install fan and alternator poly-vee belt, if removed.
- 5. Fill fuel tank.
- Perform all appropriate prestarting checks. See <u>Daily</u> <u>Prestarting Checks</u> in the Lubrication & Maintenance — Daily Section for more information.

IMPORTANT: DO NOT operate starter more than 30 seconds at a time. Wait at least 2 minutes for starter to cool before trying again.

7. Crank engine for 20 seconds with starter. Do not allow the engine to start. Wait 2 minutes and crank engine an additional 20 seconds to assure bearing surfaces are adequately lubricated.

See your authorized dealer for the proper procedure for your application.

- 8. Start engine and run at low idle and no load for 15 minutes.
- 9. Shut engine off. Change engine oil and replace filter.
- 10. Warm up engine and check all gauges before placing engine under load.
- 11. On the first day of operation after storage, check overall engine for leaks and check all gauges for correct operation.
- NOTE: If using BioDiesel blends after long-term storage, frequency of fuel filter plugging can increase initially.

ZE59858,00002D9 -19-06DEC13-1/1

Specifications

General OEM Engine Specifications

ITEM	UNIT OF MEASURE	3029HFC03 3029HFG03
General Data		
Number of Cylinders		3
Bore	mm (in.)	106.5 (4.2)
Stroke	mm (in.)	110 (4.3)
Displacement	L (cu in.)	2.9 (177)
Compression Ratio		16.9:1
Aspiration		Turbocharged
Engine Firing Order		1-2-3
Valves Per Cylinder		1 Intake 1 Exhaust
Valve Clearance (Cold)	mm (in.)	Intake — 0.35 (0.014) Exhaust — 0.45 (0.018)
Physical Dimensions		
Length	mm (in.)	715 (28.1)
Width	mm (in.)	596 (23.5)
Height	mm (in.)	956 (37.6)
Weight	kg (lb.)	400 (882)
Performance Data	· · · · ·	
Power and Speed Ratings	See Engine Power And Speed Ratir	ng Specifications in the Specifications Section
Lubrication System		
Crankcase Oil Fill Capacity	See Engine Crankcase Oil Fill	Quantities in the Specifications Section.
Oil Pressure At Rated Speed	kPa (Bar) (psi)	357 (3.57) (52)
Oil Pressure At Low Idle (Minimum)	kPa (Bar) (psi)	254 (2.54) (37)
Cooling System		
Thermostat Start To Open Temperature	°C (°F)	83 (181)
Thermostat Fully Open Temperature	°C (°F)	95 (203)
Recommended Radiator Pressure Cap	kPa (Bar) (psi)	125 (1.25) (18)
Fuel System		
ECU Level		L23
Fuel Injection Type		HPCR
Primary Fuel Filter		5 micron
Electrical System		
Battery Capacities 12-Volt System	CCA	640
Battery Capacities 24-Volt System	CCA	570
Air System		
Maximum Air Intake Restriction	kPa (Bar) (psi)	3.0 (0.03)
	(psi)	(0.44)


Engine Power Ratings And Fuel System Specifications

- NOTE: Power ratings are for bare engines without drag effect of cooling fan or accessories like air compressors.
- NOTE: Engine speeds listed are preset to factory specification. Slow idle speed may be reset

depending upon specific vehicle application requirements. Refer to your machine operator's manual for engine speeds that are different from those preset at the factory.

Engine Model	Electronic Software Option Codes	System Voltage V	Power Rating @ Rated Speed kW (hp)	Rated Speed (rpm)
	7APG	12	36 (48)	2200
	7APE	12	36 (48)	2400
	7ANY	12	48 (64)	2200
3029HFC03	7ANW	12	48 (64)	2400
	7ANU	12	55 (74)	2200
	7ANS	12	55 (74)	2400
	7APN	12	36 (48); 36 (48)	1800; 1500
3029HFG03	7APL	12	48 (64); 48 (64)	1800; 1500
	7APJ	12	55 (74); 48 (64)	1800, 1500

ZE59858,000006D -19-10MAR15-1/1



each code identify the specific oil pan on your engine. The following table lists engine crankcase oil fill quantities: amount shown. ALWAYS fill crankcase to within crosshatch on dipstick. DO NOT overfill.

ZE59858,000006E -19-28JUL14-1/1

Unified Inch Bolt and Screw Torque Values TS1671 – UN-01MAY03

		\bigcirc	\bigcirc		$\bigcirc \bigcirc \bigcirc$
--	--	------------	------------	--	------------------------------


Bolt or Screw		SAE G	rade 1			SAE G	SAE Grade 2 ^a			Grade	5, 5.1 o	r 5.2	SAE Grade 8 or 8			8.2
Size	Lubri	cated ^b	Di	r y c	Lubri	cated ^b	Di	r y c	Lubri	cated ^b	Di	у ^с	Lubri	cated ^b	D	ry ^c
	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin
1/4	3.7	33	4.7	42	6	53	7.5	66	9.5	84	12	106	13.5	120	17	150
													N∙m	lbft.	N∙m	lbft
5/16	7.7	68	9.8	86	12	106	15.5	137	19.5	172	25	221	28	20.5	35	26
									N∙m	lbft.	N∙m	lbft.				
3/8	13.5	120	17.5	155	22	194	27	240	35	26	44	32.5	49	36	63	46
			N∙m	lbft.	N∙m	lbft.	N∙m	lbft.								
7/16	22	194	28	20.5	35	26	44	32.5	56	41	70	52	80	59	100	74
	N∙m	lbft.														
1/2	34	25	42	31	53	39	67	49	85	63	110	80	120	88	155	115
9/16	48	35.5	60	45	76	56	95	70	125	92	155	115	175	130	220	165
5/8	67	49	85	63	105	77	135	100	170	125	215	160	240	175	305	225
3/4	120	88	150	110	190	140	240	175	300	220	380	280	425	315	540	400
7/8	190	140	240	175	190	140	240	175	490	360	615	455	690	510	870	640
1	285	210	360	265	285	210	360	265	730	540	920	680	1030	760	1300	960
1-1/8	400	300	510	375	400	300	510	375	910	670	1150	850	1450	1075	1850	1350
1-1/4	570	420	725	535	570	420	725	535	1280	945	1630	1200	2050	1500	2600	1920
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2140	1580	2700	2000	3400	250
1-1/2	990	730	1250	930	990	730	1250	930	2250	1650	2850	2100	3600	2650	4550	3350
Torque values lis or screw. DO NC procedure is give type lock nuts, fo tightening instruc under predetermi	DT use to n for a so r stainle tions for	hese val specific a ss steel the spe	ues if a application fastene cific app	different on. For p rs, or for lication.	torque blastic in nuts or Shear b	value or isert or o 0 U-bolts iolts are	tightenii crimped , see the designe	ng steel e d to fail	grade f original properl plain of or whe	asteners I. Make y start th r zinc pla	s are use sure fas nread en ated fast unless d	ed, tighte tener thr gageme eners ot	en these eads ar nt. Whe her than	her grad to the s e clean a en possit lock nut ons are g	trength and that ble, lubri ts, whee	of the you icate

b"Lubricated" means coated with a lubricant such as engine oil, fasteners with phosphate and oil coatings, or 7/8 in.
 and larger fasteners with JDM F13C, F13F or F13J zinc flake coating.
 ^c"Dry" means plain or zinc plated without any lubrication, or 1/4 to 3/4 in. fasteners with JDM F13B, F13E or F13H zinc flake coating.

DX,TORQ1 -19-12JAN11-1/1

Metric Bolt and Screw Torque Values

TS1670 -UN-01MAY03



Bolt or Screw		Class	s 4.8		Class 8.8 or 9.8			Class 10.9				Class 12.9				
Size	Lubri	cated ^a	D	'y b	Lubri	cated ^a	Di	r y b	Lubri	cated ^a	Di	'y b	Lubri	cated ^a	D	r y b
	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.	N∙m	lbin.
M6	4.7	42	6	53	8.9	79	11.3	100	13	115	16.5	146	15.5	137	19.5	172
					1		1		N∙m	lbft.	N∙m	lbft.	N∙m	lbft.	N∙m	lbft.
M8	11.5	102	14.5	128	22	194	27.5	243	32	23.5	40	29.5	37	27.5	47	35
			N∙m	lbft.	N∙m	lbft.	N∙m	lbft.								
M10	23	204	29	21	43	32	55	40	63	46	80	59	75	55	95	70
	N∙m	lbft.														
M12	40	29.5	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	46	80	59	120	88	150	110	175	130	220	165	205	150	260	190
M16	100	74	125	92	190	140	240	175	275	200	350	255	320	235	400	300
M18	135	100	170	125	265	195	330	245	375	275	475	350	440	325	560	410
M20	190	140	245	180	375	275	475	350	530	390	675	500	625	460	790	580
M22	265	195	330	245	510	375	650	480	725	535	920	680	850	625	1080	800
M24	330	245	425	315	650	480	820	600	920	680	1150	850	1080	800	1350	1000
M27	490	360	625	460	950	700	1200	885	1350	1000	1700	1250	1580	1160	2000	1475
M30	660	490	850	625	1290	950	1630	1200	1850	1350	2300	1700	2140	1580	2700	2000
M33	900	665	1150	850	1750	1300	2200	1625	2500	1850	3150	2325	2900	2150	3700	2730
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2770	4750	3500

Torque values listed are for general use only, based on the strength of the bolt or screw. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For stainless steel fasteners or for nuts on U-bolts, see the tightening instructions for the specific application. Tighten plastic insert or crimped steel type lock nuts by turning the nut to the dry torque shown in the chart, unless different instructions are given for the specific application.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class. Replace fasteners with the same or higher property class. If higher property class fasteners are used, tighten these to the strength of the original. Make sure fastener threads are clean and that you properly start thread engagement. When possible, lubricate plain or zinc plated fasteners other than lock nuts, wheel bolts or wheel nuts, unless different instructions are given for the specific application.

^a"Lubricated" means coated with a lubricant such as engine oil, fasteners with phosphate and oil coatings, or M20 and larger fasteners with JDM F13C, F13F or F13J zinc flake coating. ^b"Dry" means plain or zinc plated without any lubrication, or M6 to M18 fasteners with JDM F13B, F13E or F13H zinc flake coating.

DX,TORQ2 -19-12JAN11-1/1

Using Lubrication and Maintenance Records

Refer to specific Lubrication and Maintenance Section for detailed service procedures.

- 1. Keep a record of the number of hours you operate your engine by regular observation of hour meter.
- 2. Check your record regularly to learn when your engine needs service.
- 3. DO ALL the services within an interval section. Write the number of hours (from your service records) and

the date in the spaces provided. For a complete listing of all items to be performed and the service intervals required, refer to the quick-reference chart near the front of the Lubrication and Maintenance Section.

IMPORTANT: The service recommendations covered in this manual are for the accessories that are provided by John Deere. Follow manufacturer's service recommendations for servicing engine driven equipment not supplied by Deere.

Check air cleaner dust unloader valve and air filter

Check fuel filters/water bowls.

restriction indicator, if equipped.

Perform visual walkaround inspection.

RG,RG34710,5620 -19-24AUG10-1/1

ZE59858,00002CE -19-06DEC13-1/1

Daily (Prestarting) Service

- Check engine oil level.
- Check coolant level.
- Check fan, alternator, and drive belts.

250 Hours or 12 Months Service

• Replace fuel filter elements.

Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				

500 Hours or 12 Months Service

- Service fire extinguisher.
- Service battery.
- Change engine oil and filter.¹
 Inspect coolant pump.
- Check open crankcase vent system.
- Check engine mounts.

- Check V-belt wear.
- Check Air Intake System.
- Check engine electrical ground connection.Check cooling system.
- Pressure test cooling system.
- Check engine speeds.

Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				

¹Service intervals depend on sulfur content of the diesel fuel, oil pan capacity, and the oil and filter used. (See DIESEL ENGINE OIL AND FILTER SERVICE INTERVALS, in Fuels, Lubricants, and Coolant Section.)

RK80614,0000537 -19-12DEC14-1/1

1200 Hours

• Check and Adjust Engine Valve Clearance.

Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				

ZE59858,0000070 -19-19SEP14-1/1

1500 Hours or 24 Months Service

• Changing Open Crankcase Ventilation (OCV) Filter.

Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				
Hours				
Date				

ZE59858,0000071 -19-19SEP14-1/1

 Flush and refill cooling system. 	 Test therm 	ostats.	
Hours			
Date			
Hours			
Date			
Hours			
Date			
Hours			
Date			
Hours			
Date			
Hours			
Date			
Hours			
Date			
Hours			
Date			

Service As Required

- Drain water from fuel filter.
- Bleed fuel system.
- Add coolant.
- Pre-Start Cleaning Guide.Service/Replace air cleaner.

- Clean exhaust filter.
- Replace fan belt.
- Check fuses.
- Check electrical wiring and connections.
- Check air compressor (if equipped).

Hours Date ZE59858,0000073 -19-16SEP14-1/1

John Deere Warranty in OEM Applications

Overview

This section focuses on John Deere engines marketed in products manufactured by companies other than John Deere or its affiliates, and on John Deere repower engines in all applications. Herein appears the original warranty applicable to the engine as delivered to the retail purchaser on or after 1 May 2010. The following is information about the warranty and warranty service.

NOTE: "John Deere" means John Deere Power Systems with respect to users in the United States, John Deere Limited with respect to users in Canada, and Deere & Company or its subsidiary responsible for making John Deere equipment in other countries where the user is located.

Promptly register your engine online at https://www.johndeere.com/enginewarranty

or

Mail or FAX the registration form found in this manual to John Deere as indicated on the form.

When Warranty Service Is Needed

The nearest dealer stands ready with genuine parts and trained and equipped personnel should the need arise. If following the Operator's Manual delivered with the engine/machine are not adequate to correct an engine problem, contact the nearest John Deere service dealer for assistance. Authorized engine service dealers can be found at: https://www.johndeere.com/ (click on "Dealer Locator").

NOTE: When requesting warranty service, the purchaser must be prepared to provide proof that the engine is within the warranty period.

The following information is always required: Engine serial number, date of delivery, engine owner, name and location of dealer and specific person contacted, date of contact, nature of engine problem, and outcome of the service dealer contact.

Given that normally it is the dealer contacted who in the end will provide the service required, maintaining a purchaser-dealer relationship of mutual respect from the beginning is always helpful.

Privacy Notice

At John Deere your privacy is important to us. We collect, use, and disclose your personal information in accordance with the John Deere privacy statement. For instance, we collect, use, and disclose your personal information to provide you with the products and services that you request; to communicate with you as our customer (examples include warranty and product improvement programs) and to meet safety and legal requirements; and for marketing and promotional purposes. Sometimes, we may ask our John Deere affiliates, dealers, or business partners to do work for us which involves your information. For complete details on your privacy rights and to obtain a copy of the John Deere Privacy Statement, please visit our website at https://www.johndeere.com/.

Warranty Duration

Unless otherwise provided in writing by John Deere, John Deere makes the following warranty to the first retail purchaser and each subsequent purchaser (if purchase is made prior to the expiration of applicable warranty) of each John Deere new off-highway engine marketed as part of a product manufactured by a company other than John Deere or its affiliates and on each John Deere engine used in an off-highway repower application:

- 12 months, unlimited hours of use, or
- 24 months and before the accumulation of 2000 hours of use.

NOTE: In the absence of a functional hourmeter, hours of use will be determined on the basis of 12 hours of use per calendar day.

Warranty Coverage

This warranty applies to the engine and to integral components and accessories sold by John Deere, and delivered to the first retail purchaser on or after 1 May 2010.

All John Deere-warranted parts and components of John Deere engines which, as delivered to the purchaser, are defective in materials and/or workmanship will be repaired or replaced, as John Deere elects. Warrantable repairs will be made without charge for parts or engine repair labor, including reasonable labor costs to remove and reinstall non-engine parts or components of the equipment in which the engine is installed. If required, reasonable labor costs for engine removal and reinstallation will also be included. All coverage is based on the defect appearing within the warranty period as measured from the date of delivery to the first retail purchaser.

Obtaining Warranty Service

Warranty service must be requested of the nearest authorized John Deere engine service outlet before the expiration of the warranty. An *authorized* service outlet is a John Deere engine distributor, a John Deere engine service dealer, or a John Deere equipment dealer selling and servicing equipment with an engine of the type covered by this warranty. (See When Warranty Service is Needed above.)

Authorized service outlets will use only new or remanufactured parts or components furnished or approved by John Deere.

NOTE: Authorized engine service locations are listed on the Internet at https://www.johndeere.com/ (Click on "Dealer Locator".)

Continued on next page

JR74534,0000462 -19-22AUG14-1/3

At the time of requesting warranty service, the purchaser must be prepared to present evidence of the date of delivery of the engine.

John Deere reimburses authorized service outlets for limited travel expenses incurred in making warranty service repairs in non-John Deere applications when travel is actually performed. The limit, as of the date of publication of this booklet, is US\$400.00 (US\$500.00 if engine is marine) or equivalent. If distances and travel times are greater than reimbursed by John Deere, the service outlet will charge the purchaser for the difference.

Warranty Exclusions

John Deere's obligations will not apply to components and accessories which are not furnished or installed by John Deere, nor to failures caused by such items, except as required by law.

Purchaser's Responsibilities

The cost of normal maintenance and depreciation.

Periodic cleaning of the diesel particulate filter (DPF).

Consequences of negligence, misuse, or accident involving the product, or improper application, installation, or storage.

Consequences of service performed by someone other than an authorized John Deere engine service outlet.

Consequences of any product modification or alteration not approved by John Deere, including, but not limited to, tampering with engine fuel and air delivery systems.

Consequences of failure of non-product components.

Consequences of fuels, lubricants, or coolants that fail to meet the specifications and requirements listed in the Operator's Manual.

The effects of cooling system neglect as manifested in cylinder liner or cylinder block cavitation ("pitting, "erosion", "electrolysis").

Any premium for overtime labor requested by the purchaser.

Costs of transporting the product or the equipment in which it is installed to and from the location at which the warranty service is performed, if such costs are in excess of the travel reimbursement payable to the dealer had the warranty service been performed at the product's location.

Costs incurred in gaining access; for example, overcoming physical barriers such as walls, fences, floors, decks, or similar structures impeding access to the product, rental of cranes or similar, or construction of ramps or lifts or protective structures for product removal and reinstallation.

Incidental travel costs including meals, lodging, and similar, and any travel time or mileage costs in excess of the maximum allowance. Service outlet costs incurred in solving or attempting to solve non-warrantable problems.

Services performed by a party other than an authorized John Deere service dealer.

Charges by dealers for initial start-up and inspection deemed unnecessary by John Deere when an Operator's Manual is supplied with the product are followed.

Costs related to interpretation or translation services.

No Representations or Implied Warranty

Where permitted by law, neither John Deere nor any company affiliated with it makes any guaranties, warranties, conditions, representations or promises, express or implied, oral or written, as to the nonoccurrence of any defect or the quality of performance of its engines other than those set forth in this booklet, and DOES NOT MAKE ANY IMPLIED WARRANTY OR CONDITIONS OF MERCHANTABILITY OR FITNESS otherwise provided for in the Uniform Commercial Code or required by any Sale of Goods Act or any other statute. This exclusion includes fundamental terms. In no event will a John Deere engine distributor or engine service dealer, John Deere equipment dealer, or John Deere or any company affiliated with John Deere be liable for incidental or consequential damages or injuries including, but not limited to, loss of profits, loss of crops, rental of substitute equipment or other commercial loss, damage to the equipment in which the engine is installed or for damage suffered by purchaser as a result of fundamental breaches of contract or breach of fundamental terms, unless such damages or injuries are caused by the gross negligence or intentional acts of the foregoing parties.

Remedy Limitation

The remedies set forth in this warranty are the purchaser's exclusive remedies in connection with the performance of, or any breach of guaranty, condition, or warranty in respect of new John Deere engines. In the event the above warranty fails to correct purchaser's performance problems caused by defects in workmanship and/or materials, purchaser's exclusive remedy shall be limited to payment by John Deere of actual damages in an amount not to exceed the cost of the engine.

No Seller's Warranty

No person or entity, other than John Deere, who sells the engine or product in which the engine has been installed makes any guaranty or warranty of its own on any engine warranted by John Deere unless it delivers to the purchaser a separate written guaranty certificate specifically guaranteeing the engine, in which case John Deere shall have no obligation to the purchaser. Neither original equipment manufacturers, engine or equipment distributors, engine or equipment dealers, nor any other person or entity, has any authority to make any representation or promise on behalf of John Deere or to modify the terms or limitations of this warranty in any way.

Continued on next page

Replacement Parts Warranty

John Deere and John Deere Reman parts and components (excluding replacement engines) installed during engine warranty service are warranted for the remaining warranty period of the engine or the applicable warranty term for the installed service part, whichever is greater. A new or remanufactured engine replacing a failed engine under warranty is warranted for 90 days or the remaining warranty period of the original engine, whichever is greater.

Warranty Transfer

The remainder of the original engine warranty and the emissions control-related warranty may be transferred to a subsequent owner of the engine. The Engine Warranty Transfer card should be used to report the transfer to John Deere. If a card is not available, contact your Dealer or simply send the following Information to JDPS Warranty Administration at Diesel-US@JohnDeere.com.

- 1. The complete 13-character engine serial number.
- 2. The name and mailing address of the original purchaser.
- 3. Delivery date to the original purchaser.
- 4. Hours at the time of transfer.
- 5. Date of transfer to the new owner.
- 6. Name and mailing address of the new owner.
- How the engine/drivetrain being used, i.e., what equipment it powers, by manufacturer and model.
- 8. Equipment it powers, by manufacturer and model.

Purchased Extended Warranty

Extended warranty may be purchased on most engines in many areas of the world. John Deere engine distributors and equipment dealers, and dealers of manufacturers using John Deere engines in their products, have details. John Deere may also be contacted at U.S.A. fax number 1-319-292-5844, or in Europe fax number 33.2.38.84.62.66.

Emissions Warranties

Emissions warranties appear in the Operator's Manual furnished with the engine/machine. (Warning: Statutes providing severe penalties for tampering with emissions controls may apply at the user's location.) John Deere may also be contacted at U.S.A. fax number 1-319-292-5844; or in Europe fax number 33.2.38.84.62.66.

Local Warranty Requirements

Warranties required by local statutes will be furnished by the seller.

Option Codes (Engine Manufacturing Configuration)

When in need of engine replacement parts, your authorized John Deere service dealer will need to know the corresponding "Option Codes" for your engine. The option code label on the engine rocker arm cover may become damaged over time. By recording the four-digit codes when the engine is new, and storing this manual where it can be found when parts are needed, fast, accurate parts ordering and service will be assured. (See Engine Option Codes in the Record Keeping Section).

Should there be a question about an engine option code, note the engine serial number and call 1-800-JDENGINE from the U.S.A. or Canada, or fax U.S.A. number 1-319-292-5844; or E-mail at diesel-us@johndeere.com, Attention: Warranty Administration; or in Europe fax number 33.2.38.84.62.66, or E-mail at saranservice@johndeere.com.

Registering The Engine For Warranty

Completion and submission of the John Deere Engine Warranty Registration form (cut out sheet found in this manual) is very important. John Deere will not deny warranty service on an engine within its warranty period if the engine has not been registered. However, registering your engine will assure your servicing dealer that the engine is within the warranty period.

The easiest way to register your engine is via the Internet. Go to website https://www.johndeere.com/enginewarranty You can use the sheet in this manual to gather the information needed to register the warranty.

NOTE: Information provided on the form must be legible!

Typing is preferred, but legible handwritten reports are acceptable. "Block" numbers and Roman alphabet letters should be used. For example: 1,2,3,4 and A, B, C, D.

All requested information should be given. Much of it contributes to reports, including those required by governments.

The purchaser's telephone number or E-mail address allows John Deere to make contact should there be questions concerning the registration. The purchaser should sign and date the form.

JR74534,0000462 -19-22AUG14-3/3



to new engines having the certification label affixed to the

engine and sold as stated above in the geographic areas.

The presence of an EU number signifies that the engine

has been certified with the European Union countries per

Directive 97/68/EC. The EPA and/or CARB emissions

warranties do not apply to the EU countries.

The U.S. EPA and California ARB prohibit the removal or rendering inoperative of any device or element of design installed on or in engines/equipment in compliance with applicable emission regulations prior to or after the sale and delivery of the engines/equipment to the ultimate purchaser.

DX,EMISSIONS,LABEL -19-01AUG14-1/1

EPA Non-road Emissions Control Warranty Statement—Compression Ignition

DXLOGOV1 -UN-28APR09



U.S. AND CANADA EMISSION CONTROL WARRANTY STATEMENT YOUR WARRANTY RIGHTS AND OBLIGATIONS

To determine if the John Deere engine qualifies for the additional warranties set forth below, look for the "Emissions Control Information" label located on the engine. If the engine is operated in the United States or Canada and the Emissions Control information label states: "This engine complies with US EPA regulations for nonroad and stationary diesel engines", or "This engine conforms to US EPA nonroad compression-ignition regulations", refer to the "U.S. and Canada Emission Control Warranty Statement." If the engine is operated in California, and the label states: "This engine complies with US EPA and CARB regulations for nonroad diesel engines", or "This engine conforms to US EPA and California nonroad compression-ignition emission regulations", also refer to the "California Emission Control Warranty Statement."

Warranties stated on this certificate refer only to emissions-related parts and components of your engine. The complete engine warranty, less emissions-related parts and components, is provided separately. If you have any questions about your warranty rights and responsibilities, you should contact John Deere at 1-319-292-5400.

JOHN DEERE'S WARRANTY RESPONSIBILITY

John Deere warrants to the ultimate purchaser and each subsequent purchaser that this off-road diesel engine including all parts of its emission-control system was designed, built and equipped so as to conform at the time of the sale with Section 213 of the Clean Air Act and is free from defects in materials and workmanship which would cause the engine to fail to conform with applicable US EPA regulations for a period of five years from the date the engine is placed into service or 3,000 hours of operation, whichever first occurs.

Where a warrantable condition exists, John Deere will repair or replace, as it elects, any part or component with a defect in materials or workmanship that would increase the engine's emissions of any regulated pollutant within the stated warranty period at no cost to you, including expenses related to diagnosing and repairing or replacing emission-related parts. Warranty coverage is subject to the limitations and exclusions set forth herein. Emission- related components include engine parts developed to control emissions related to the following:

Air-Induction System Fuel System Ignition System Exhaust Gas Recirculation Systems Aftertreatment Devices Crankcase Ventilation Valves Sensors Engine Electronic Control Units

EMISSION WARRANTY EXCLUSIONS

John Deere may deny warranty claims for malfunctions or failures caused by:

- Non-performance of maintenance requirements listed in the Operator's Manual
- The use of the engine/equipment in a manner for which it was not designed
- · Abuse, neglect, improper maintenance or unapproved modifications or alterations
- Accidents for which it does not have responsibility or by acts of God

The off-road diesel engine is designed to operate on diesel fuel as specified in the Fuels, Lubricants and Coolants section in the Operators Manual. Use of any other fuel can harm the emissions control system of the engine/equipment and is not approved for use.

To the extent permitted by law John Deere is not liable for damage to other engine components caused by a failure of an emission-related part, unless otherwise covered by standard warranty.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. REMEDIES UNDER THIS WARRANTY ARE LIMITED TO THE PROVISIONS OF MATERIAL AND SERVICES AS SPECIFIED HEREIN. WHERE PERMITTED BY LAW, NEITHER JOHN DEERE NOR ANY AUTHORIZED JOHN DEERE ENGINE DISTRIBUTOR, DEALER, OR REPAIR FACILITY OR ANY COMPANY AFFILIATED WITH JOHN DEERE WILL BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Emission_CI_EPA (18Dec09)

Continued on next page

DX, EMISSIONS, EPA -19-12DEC12-1/2

Warranty



JOHN DEERE

U.S. AND CANADA EMISSION CONTROL WARRANTY STATEMENT YOUR WARRANTY RIGHTS AND OBLIGATIONS

To determine if the John Deere engine qualifies for the additional warranties set forth below, look for the "Emissions Control Information" label located on the engine. If the engine is operated in the United States or Canada and the Emissions Control information label states: "This engine complies with US EPA regulations for nonroad and stationary diesel engines", or "This engine conforms to US EPA nonroad compression-ignition regulations", refer to the "U.S. and Canada Emission Control Warranty Statement." If the engine is operated in California, and the label states: "This engine complies with US EPA and CARB regulations for nonroad diesel engines", or "This engine conforms to US EPA and California nonroad compression-ignition emission regulations", also refer to the "California Emission Control Warranty Statement."

Warranties stated on this certificate refer only to emissions-related parts and components of your engine. The complete engine warranty, less emissions-related parts and components, is provided separately. If you have any questions about your warranty rights and responsibilities, you should contact John Deere at 1-319-292-5400.

JOHN DEERE'S WARRANTY RESPONSIBILITY

John Deere warrants to the ultimate purchaser and each subsequent purchaser that this off-road diesel engine including all parts of its emission-control system was designed, built and equipped so as to conform at the time of the sale with Section 213 of the Clean Air Act and is free from defects in materials and workmanship which would cause the engine to fail to conform with applicable US EPA regulations for a period of five years from the date the engine is placed into service or 3,000 hours of operation, whichever first occurs.

Where a warrantable condition exists, John Deere will repair or replace, as it elects, any part or component with a defect in materials or workmanship that would increase the engine's emissions of any regulated pollutant within the stated warranty period at no cost to you, including expenses related to diagnosing and repairing or replacing emission-related parts. Warranty coverage is subject to the limitations and exclusions set forth herein. Emission- related components include engine parts developed to control emissions related to the following:

Aftertreatment Devices

Sensors

Crankcase Ventilation Valves

Engine Electronic Control Units

Air-Induction System Fuel System Ignition System Exhaust Gas Recirculation Systems

EMISSION WARRANTY EXCLUSIONS

John Deere may deny warranty claims for malfunctions or failures caused by:

- Non-performance of maintenance requirements listed in the Operator's Manual
- The use of the engine/equipment in a manner for which it was not designed
- Abuse, neglect, improper maintenance or unapproved modifications or alterations
- · Accidents for which it does not have responsibility or by acts of God

The off-road diesel engine is designed to operate on diesel fuel as specified in the Fuels, Lubricants and Coolants section in the Operators Manual. Use of any other fuel can harm the emissions control system of the engine/equipment and is not approved for use.

To the extent permitted by law John Deere is not liable for damage to other engine components caused by a failure of an emission-related part, unless otherwise covered by standard warranty.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. REMEDIES UNDER THIS WARRANTY ARE LIMITED TO THE PROVISIONS OF MATERIAL AND SERVICES AS SPECIFIED HEREIN. WHERE PERMITTED BY LAW, NEITHER JOHN DEERE NOR ANY AUTHORIZED JOHN DEERE ENGINE DISTRIBUTOR, DEALER, OR REPAIR FACILITY OR ANY COMPANY AFFILIATED WITH JOHN DEERE WILL BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

Emission_CI_EPA (18Dec09)

DX,EMISSIONS,EPA -19-12DEC12-2/2

CARB Non-road Emissions Control Warranty Statement—Compression Ignition

Emissions Control Warranty Statement 2013 through 2015

DXLOGOV1 -UN-28APR09



John Deere

CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT YOUR WARRANTY RIGHTS AND OBLIGATIONS

To determine if the John Deere engine qualifies for the additional warranties set forth below, look for the "Emission Control Information" label located on the engine. If the engine is operated in the United States or Canada and the engine label states: "This engine complies with US EPA regulations for nonroad and stationary diesel engines", or "This engine complies with US EPA regulations for stationary emergency diesel engines", refer to the "U.S. and Canada Emission Control Warranty Statement." If the engine is operated in California, and the engine label states: "This engine complies with US EPA and CARB regulations for nonroad diesel engines" also refer to the "California Emissions Control Warranty Statement."

Warranties stated on this certificate refer only to emissions-related parts and components of your engine. The complete engine warranty, less emission-related parts and components, is provided separately. If you have any questions about your warranty rights and responsibilities, you should contact John Deere at 1-319-292-5400.

CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT:

The California Air Resources Board (CARB) is pleased to explain the emission-control system warranty on 2013 through 2015 off-road diesel engines. In California, new off-road engines must be designed, built and equipped to meet the State's stringent anti-smog standards. John Deere must warrant the emission control system on your engine for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the fuel injection system and the air induction system. Also included may be hoses, belts, connectors and other emission-related assemblies.

John Deere warrants to the ultimate purchaser and each subsequent purchaser that this off-road diesel engine was designed, built, and equipped so as to conform at the time of sale with all applicable regulations adopted by CARB and is free from defects in materials and workmanship which would cause the failure of a warranted part to be identical in all material respects to the part as described in John Deere's application for certification for a period of five years from the date the engine is delivered to an ultimate purchaser or 3,000 hours of operation, whichever occurs first for all engines rated at 19 kW and greater. In the absence of a device to measure hours of use, the engine shall be warranted for a period of five years.

EMISSIONS WARRANTY EXCLUSIONS:

John Deere may deny warranty claims for failures caused by the use of an add-on or modified part which has not been exempted by the CARB. A modified part is an aftermarket part intended to replace an original emission-related part which is not functionally identical in all respects and which in any way affects emissions. An add-on part is any aftermarket part which is not a modified part or a replacement part.

In no event will John Deere, any authorized engine distributor, dealer, or repair facility, or any company affiliated with John Deere be liable for incidental or consequential damage.

Continued on next page

DX,EMISSIONS,CARB -19-01AUG14-1/8

JOHN DEERE'S WARRANTY RESPONSIBILITY:

Where a warrantable condition exists, John Deere will repair or replace, as it elects, your off-road diesel engine at no cost to you, including diagnosis, parts or labor. Warranty coverage is subject to the limitations and exclusions set forth herein. The off-road diesel engine is warranted for a period of five years from the date the engine is delivered to an ultimate purchaser or 3,000 hours of operation, whichever occurs first. The following are emissions-related parts:

Air Induction System	Emission control labels	Advanced Oxides of Nitrogen (NOx) Controls
 Intake manifold Turbocharger 	Particulate Controls	 NOx absorbers and catalysts
Charge air cooler	 Any device used to capture particulate emissions 	SCR systems and urea containers/dispensing systems
Fuel Metering system	• Any device used in the regeneration of the	Miscellaneous Items used in Above Systems
 Fuel injection system 	capturing system Enclosures and manifolding 	,
Exhaust Gas Recirculation	 Smoke Puff Limiters 	 Electronic control units, sensors, actuators, wiring harnesses, hoses, connectors, clamps,
• EGR valve	Positive Crankcase Ventilation (PCV) System	fittings, gasket, mounting hardware
Catalyst or Thermal Reactor Systems	PCV valveOil filler cap	
Catalytic converter		

Exhaust manifold

Any warranted emissions-related part scheduled for replacement as required maintenance is warranted by John Deere for the period of time prior to the first scheduled replacement point for the part. Any warranted emissions-related part not scheduled for replacement as required maintenance or scheduled only for regular inspection is warranted by John Deere for the stated warranty period.

OWNER'S WARRANTY RESPONSIBILITIES:

As the off-road diesel engine owner you are responsible for the performance of the required maintenance listed in your Operator's Manual. John Deere recommends that the owner retain all receipts covering maintenance on the off-road diesel engine, but John Deere cannot deny warranty solely for the lack of receipts or for the owner's failure to ensure the performance of all scheduled maintenance. However, as the off-road diesel engine owner, you should be aware that John Deere may deny you warranty coverage if your off-road diesel engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

The off-road diesel engine is designed to operate on diesel fuel as specified in the Fuels, Lubricants and Coolants section in the Operators Manual. Use of any other fuel may result in the engine no longer operating in compliance with applicable emissions requirements.

The owner is responsible for initiating the warranty process, and should present the machine to the nearest authorized John Deere dealer as soon as a problem is suspected. The warranty repairs should be completed by the authorized John Deere dealer as quickly as possible.

Emissions regulations require the customer to bring the unit to an authorized servicing dealer when warranty service is required. As a result, John Deere is NOT liable for travel or mileage on emissions warranty service calls.

Emission_CI_CARB (19Sep12)

Continued on next page

DX,EMISSIONS,CARB -19-01AUG14-2/8

Emissions Control Warranty Statement 2013 through 2015

DXLOGOV1 -UN-28APR09



CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT

YOUR WARRANTY RIGHTS AND OBLIGATIONS

To determine if the John Deere engine qualifies for the additional warranties set forth below, look for the "Emission Control Information" label located on the engine. If the engine is operated in the United States or Canada and the engine label states: "This engine complies with US EPA regulations for nonroad and stationary diesel engines", or "This engine complies with US EPA regulations for stationary emergency diesel engines", refer to the "U.S. and Canada Emission Control Warranty Statement." If the engine is operated in California, and the engine label states: "This engine complies with US EPA and CARB regulations for nonroad diesel engines" also refer to the "California Emissions Control Warranty Statement."

Warranties stated on this certificate refer only to emissions-related parts and components of your engine. The complete engine warranty, less emission-related parts and components, is provided separately. If you have any questions about your warranty rights and responsibilities, you should contact John Deere at 1-319-292-5400.

CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT:

The California Air Resources Board (CARB) is pleased to explain the emission-control system warranty on 2013 through 2015 off-road diesel engines. In California, new off-road engines must be designed, built and equipped to meet the State's stringent anti-smog standards. John Deere must warrant the emission control system on your engine for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the fuel injection system and the air induction system. Also included may be hoses, belts, connectors and other emission-related assemblies.

John Deere warrants to the ultimate purchaser and each subsequent purchaser that this off-road diesel engine was designed, built, and equipped so as to conform at the time of sale with all applicable regulations adopted by CARB and is free from defects in materials and workmanship which would cause the failure of a warranted part to be identical in all material respects to the part as described in John Deere's application for certification for a period of five years from the date the engine is delivered to an ultimate purchaser or 3,000 hours of operation, whichever occurs first for all engines rated at 19 kW and greater. In the absence of a device to measure hours of use, the engine shall be warranted for a period of five years.

EMISSIONS WARRANTY EXCLUSIONS:

John Deere may deny warranty claims for failures caused by the use of an add-on or modified part which has not been exempted by the CARB. A modified part is an aftermarket part intended to replace an original emission-related part which is not functionally identical in all respects and which in any way affects emissions. An add-on part is any aftermarket part which is not a modified part or a replacement part.

In no event will John Deere, any authorized engine distributor, dealer, or repair facility, or any company affiliated with John Deere be liable for incidental or consequential damage.

Continued on next page

DX.EMISSIONS.CARB -19-01AUG14-3/8

RG25841

JOHN DEERE'S WARRANTY RESPONSIBILITY:

Where a warrantable condition exists, John Deere will repair or replace, as it elects, your off-road diesel engine at no cost to you, including diagnosis, parts or labor. Warranty coverage is subject to the limitations and exclusions set forth herein. The off-road diesel engine is warranted for a period of five years from the date the engine is delivered to an ultimate purchaser or 3,000 hours of operation, whichever occurs first. The following are emissions-related parts:

Air Induction System	Emission control labels	Advanced Oxides of Nitrogen (NOx) Controls
 Intake manifold Turbocharger 	Particulate Controls	 NOx absorbers and catalysts
Charge air cooler	 Any device used to capture particulate emissions 	SCR systems and urea containers/dispensing systems
Fuel Metering system	• Any device used in the regeneration of the	-
 Fuel injection system 	capturing system Enclosures and manifolding Smoke Puff Limiters 	 Miscellaneous Items used in Above Systems Electronic control units, sensors, actuators,
Exhaust Gas Recirculation	omoke i un Einners	wiring harnesses, hoses, connectors, clamps,
• EGR valve	Positive Crankcase Ventilation (PCV) System	fittings, gasket, mounting hardware
Catalyst or Thermal Reactor Systems	PCV valveOil filler cap	
 Catalytic converter Exhaust manifold 		

Any warranted emissions-related part scheduled for replacement as required maintenance is warranted by John Deere for the period of time prior to the first scheduled replacement point for the part. Any warranted emissions-related part not scheduled for replacement as required maintenance or scheduled only for regular inspection is warranted by John Deere for the stated warranty period.

OWNER'S WARRANTY RESPONSIBILITIES:

As the off-road diesel engine owner you are responsible for the performance of the required maintenance listed in your Operator's Manual. John Deere recommends that the owner retain all receipts covering maintenance on the off-road diesel engine, but John Deere cannot deny warranty solely for the lack of receipts or for the owner's failure to ensure the performance of all scheduled maintenance. However, as the off-road diesel engine owner, you should be aware that John Deere may deny you warranty coverage if your off-road diesel engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

The off-road diesel engine is designed to operate on diesel fuel as specified in the Fuels, Lubricants and Coolants section in the Operators Manual. Use of any other fuel may result in the engine no longer operating in compliance with applicable emissions requirements.

The owner is responsible for initiating the warranty process, and should present the machine to the nearest authorized John Deere dealer as soon as a problem is suspected. The warranty repairs should be completed by the authorized John Deere dealer as quickly as possible.

Emissions regulations require the customer to bring the unit to an authorized servicing dealer when warranty service is required. As a result, John Deere is NOT liable for travel or mileage on emissions warranty service calls.

Emission CI CARB (19Sep12)

Continued on next page

DX, EMISSIONS, CARB -19-01AUG14-4/8

Emissions Control Warranty Statement 2016 through 2018

DXLOGOV1 -UN-28APR09



JOHN DEERE CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT YOUR WARRANTY RIGHTS AND OBLIGATIONS

To determine if the John Deere engine qualifies for the additional warranties set forth below, look for the "Emission Control Information" label located on the engine. If the engine is operated in the United States or Canada and the engine label states: "This engine complies with US EPA regulations for nonroad and stationary diesel engines", or "This engine complies with US EPA regulations for stationary emergency diesel engines", refer to the "U.S. and Canada Emission Control Warranty Statement." If the engine is operated in California, and the engine label states: "This engine complies with US EPA and CARB regulations for nonroad diesel engines" also refer to the "California Emissions Control Warranty Statement."

Warranties stated on this certificate refer only to emissions-related parts and components of your engine. The complete engine warranty, less emission-related parts and components, is provided separately. If you have any questions about your warranty rights and responsibilities, you should contact John Deere at 1-319-292-5400.

CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT:

The California Air Resources Board (CARB) is pleased to explain the emission-control system warranty on 2016 through 2018 off-road diesel engines. In California, new off-road engines must be designed, built and equipped to meet the State's stringent anti-smog standards. John Deere must warrant the emission control system on your engine for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the fuel injection system and the air induction system. Also included may be hoses, belts, connectors and other emission-related assemblies.

John Deere warrants to the ultimate purchaser and each subsequent purchaser that this off-road diesel engine was designed, built, and equipped so as to conform at the time of sale with all applicable regulations adopted by CARB and is free from defects in materials and workmanship which would cause the failure of a warranted part to be identical in all material respects to the part as described in John Deere's application for certification for a period of five years from the date the engine is delivered to an ultimate purchaser or 3,000 hours of operation, whichever occurs first for all engines rated at 19 kW and greater. In the absence of a device to measure hours of use, the engine shall be warranted for a period of five years.

EMISSIONS WARRANTY EXCLUSIONS:

John Deere may deny warranty claims for failures caused by the use of an add-on or modified part which has not been exempted by the CARB. A modified part is an aftermarket part intended to replace an original emission-related part which is not functionally identical in all respects and which in any way affects emissions. An add-on part is any aftermarket part which is not a modified part or a replacement part.

In no event will John Deere, any authorized engine distributor, dealer, or repair facility, or any company affiliated with John Deere be liable for incidental or consequential damage.

Continued on next page

DX,EMISSIONS,CARB -19-01AUG14-5/8

JOHN DEERE'S WARRANTY RESPONSIBILITY:

Where a warrantable condition exists, John Deere will repair or replace, as it elects, your off-road diesel engine at no cost to you, including diagnosis, parts or labor. Warranty coverage is subject to the limitations and exclusions set forth herein. The off-road diesel engine is warranted for a period of five years from the date the engine is delivered to an ultimate purchaser or 3,000 hours of operation, whichever occurs first. The following are emissions-related parts:

Air Induction System	Emission control labels	Advanced Oxides of Nitrogen (NOx) Controls
 Intake manifold Turbocharger 	Particulate Controls	 NOx absorbers and catalysts
Charge air cooler	 Any device used to capture particulate emissions 	SCR systems and urea containers/dispensing systems
Fuel Metering system	• Any device used in the regeneration of the	
 Fuel injection system 	 capturing system Enclosures and manifolding 	Miscellaneous Items used in Above Systems
Exhaust Gas Recirculation	Smoke Puff Limiters	 Electronic control units, sensors, actuators, wiring harnesses, hoses, connectors, clamps,
• EGR valve	Positive Crankcase Ventilation (PCV) System	fittings, gasket, mounting hardware
Catalyst or Thermal Reactor Systems	PCV valveOil filler cap	
 Catalytic converter Exhaust manifold 		

Any warranted emissions-related part scheduled for replacement as required maintenance is warranted by John Deere for the period of time prior to the first scheduled replacement point for the part. Any warranted emissions-related part not scheduled for replacement as required maintenance or scheduled only for regular inspection is warranted by John Deere for the stated warranty period.

OWNER'S WARRANTY RESPONSIBILITIES:

As the off-road diesel engine owner you are responsible for the performance of the required maintenance listed in your Operator's Manual. John Deere recommends that the owner retain all receipts covering maintenance on the off-road diesel engine, but John Deere cannot deny warranty solely for the lack of receipts or for the owner's failure to ensure the performance of all scheduled maintenance. However, as the off-road diesel engine owner, you should be aware that John Deere may deny you warranty coverage if your off-road diesel engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

The off-road diesel engine is designed to operate on diesel fuel as specified in the Fuels, Lubricants and Coolants section in the Operators Manual. Use of any other fuel may result in the engine no longer operating in compliance with applicable emissions requirements.

The owner is responsible for initiating the warranty process, and should present the machine to the nearest authorized John Deere dealer as soon as a problem is suspected. The warranty repairs should be completed by the authorized John Deere dealer as quickly as possible.

Emissions regulations require the customer to bring the unit to an authorized servicing dealer when warranty service is required. As a result, John Deere is NOT liable for travel or mileage on emissions warranty service calls.

Emission_CI_CARB (13Jun14)

Continued on next page

DX,EMISSIONS,CARB -19-01AUG14-6/8

Emissions Control Warranty Statement 2016 through 2018

DXLOGOV1 -UN-28APR09



CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT YOUR WARRANTY RIGHTS AND OBLIGATIONS

To determine if the John Deere engine qualifies for the additional warranties set forth below, look for the "Emission Control Information" label located on the engine. If the engine is operated in the United States or Canada and the engine label states: "This engine complies with US EPA regulations for nonroad and stationary diesel engines", or "This engine complies with US EPA regulations for stationary emergency diesel engines", refer to the "U.S. and Canada Emission Control Warranty Statement." If the engine is operated in California, and the engine label states: "This engine complies with US EPA and CARB regulations for nonroad diesel engines" also refer to the "California Emissions Control Warranty Statement."

Warranties stated on this certificate refer only to emissions-related parts and components of your engine. The complete engine warranty, less emission-related parts and components, is provided separately. If you have any questions about your warranty rights and responsibilities, you should contact John Deere at 1-319-292-5400.

CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT:

The California Air Resources Board (CARB) is pleased to explain the emission-control system warranty on 2016 through 2018 off-road diesel engines. In California, new off-road engines must be designed, built and equipped to meet the State's stringent anti-smog standards. John Deere must warrant the emission control system on your engine for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your engine.

Your emission control system may include parts such as the fuel injection system and the air induction system. Also included may be hoses, belts, connectors and other emission-related assemblies.

John Deere warrants to the ultimate purchaser and each subsequent purchaser that this off-road diesel engine was designed, built, and equipped so as to conform at the time of sale with all applicable regulations adopted by CARB and is free from defects in materials and workmanship which would cause the failure of a warranted part to be identical in all material respects to the part as described in John Deere's application for certification for a period of five years from the date the engine is delivered to an ultimate purchaser or 3,000 hours of operation, whichever occurs first for all engines rated at 19 kW and greater. In the absence of a device to measure hours of use, the engine shall be warranted for a period of five years.

EMISSIONS WARRANTY EXCLUSIONS:

UN-24JUN14 John Deere may deny warranty claims for failures caused by the use of an add-on or modified part which has not been exempted by the CARB. A modified part is an aftermarket part intended to replace an original emission-related part which is not functionally identical in all respects and which in any way affects emissions. An add-on part is any aftermarket part which is not a modified part or a replacement part. RG26035

In no event will John Deere, any authorized engine distributor, dealer, or repair facility, or any company affiliated with John Deere be liable for incidental or consequential damage.

Continued on next page

DX, EMISSIONS, CARB -19-01AUG14-7/8

JOHN DEERE'S WARRANTY RESPONSIBILITY:

Where a warrantable condition exists, John Deere will repair or replace, as it elects, your off-road diesel engine at no cost to you, including diagnosis, parts or labor. Warranty coverage is subject to the limitations and exclusions set forth herein. The off-road diesel engine is warranted for a period of five years from the date the engine is delivered to an ultimate purchaser or 3,000 hours of operation, whichever occurs first. The following are emissions-related parts:

Air Induction System

Emission control labels

- Intake manifold
- TurbochargerCharge air cooler
- · Charge all coolei

Fuel Metering system

• Fuel injection system

Exhaust Gas Recirculation

EGR valve

Catalyst or Thermal Reactor Systems

- Catalytic converter
- Exhaust manifold

Particulate Controls

- Any device used to capture particulate emissions
- Any device used in the regeneration of the capturing system
- Enclosures and manifolding
- Smoke Puff Limiters

Positive Crankcase Ventilation (PCV) System

- PCV valve
- Oil filler cap

- Advanced Oxides of Nitrogen (NOx) Controls
- NOx absorbers and catalysts

SCR systems and urea containers/dispensing systems

Miscellaneous Items used in Above Systems

 Electronic control units, sensors, actuators, wiring harnesses, hoses, connectors, clamps, fittings, gasket, mounting hardware

Any warranted emissions-related part scheduled for replacement as required maintenance is warranted by John Deere for the period of time prior to the first scheduled replacement point for the part. Any warranted emissions-related part not scheduled for replacement as required maintenance or scheduled only for regular inspection is warranted by John Deere for the stated warranty period.

OWNER'S WARRANTY RESPONSIBILITIES:

As the off-road diesel engine owner you are responsible for the performance of the required maintenance listed in your Operator's Manual. John Deere recommends that the owner retain all receipts covering maintenance on the off-road diesel engine, but John Deere cannot deny warranty solely for the lack of receipts or for the owner's failure to ensure the performance of all scheduled maintenance. However, as the off-road diesel engine owner, you should be aware that John Deere may deny you warranty coverage if your off-road diesel engine or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

The off-road diesel engine is designed to operate on diesel fuel as specified in the Fuels, Lubricants and Coolants section in the Operators Manual. Use of any other fuel may result in the engine no longer operating in compliance with applicable emissions requirements.

The owner is responsible for initiating the warranty process, and should present the machine to the nearest authorized John Deere dealer as soon as a problem is suspected. The warranty repairs should be completed by the authorized John Deere dealer as quickly as possible.

Emissions regulations require the customer to bring the unit to an authorized servicing dealer when warranty service is required. As a result, John Deere is NOT liable for travel or mileage on emissions warranty service calls.

Emission_CI_CARB (13Jun14)

DX, EMISSIONS, CARB -19-01AUG14-8/8

RG26036

Α

Additional Service Information	
Air cleaner	
Replace single stage element	60-6
Air compressor	60-11
Air Filter Replacement	
Air Filter, Radial, Replacement	
Air intake system, check	
Alternator belt	
Auto Exhaust Filter Cleaning	
Auxiliary gear drive, limitations	
Avoid static electricity risk when fueling	

В

Battery	
Charge/boost	20-8
Battery Handling, Safety	
Safety, Battery Handling	05-12
Belt, fan and alternator	
Replacing	60-10
Belts, fan and alternator	
Checking tension	
Replacing	
BioDiesel fuel	
Bleeding fuel system	60-2
Bolt and screw torque values	
Metric	
Unified inch	
Break-in engine oil	
Interim tier 4, final tier 4, stage IIIB, and	
stage IV	10-6
Break-in, engine	20-1

С

Chart, service interval Check and adjust	30-2
Valves	45-1
Cleaning Engine	65-16
Compressor, air	60-11
Configuration data, viewing	15-5
Coolant	
Adding	60-4
Diesel engine	
Engine with wet sleeve cylinder liners	10-10
Disposing	
Mixing with concentrate, water quality	
Testing freeze point	
Warm temperature climates	
Coolant pump	
Inspecting	40-5
Cooling system	
Adding coolant	60-4
Check	40-9

Page

Flush	55-1
Pressure test	40-10
Refill	55-1

D

Daily prestarting checks	35-1
Daily Service	80-1
Diagnostic Gauge Keys and Indicators	25-4
Diagnostic procedure	
Using diagnostic gauge	15-3
Diagnostic trouble codes (DTCs)	
Active engine service codes, viewing	15-9
Intermittent fault code diagnostics	
Listing	
Operation	
Stored service codes, viewing	15-7
Diesel engine oil	
Interim tier 4, final tier 4, stage IIIB, and	
stage IV	10-6
Diesel engines, cold weather effect	10-5
Diesel fuel	10-1
Supplemental additives	
Diesel fuel, testing	
Testing Diesel Fuel	
Disable Exhaust Filter Cleaning	25-7
DTCs (Diagnostic Trouble Codes)	
View active service codes	
View stored service codes	15-7

Е

Effect of cold weather on diesel engines Electrical connections Emission system	
Certification label Engine	85-4
Adjust speed	40-11
Break-in	
Changing speed	20-5
Check ground connection	
Cold weather operation	
Daily prestarting checks	
Idling	
Operation	
Option codes	
Starting	
Stopping	
Troubleshooting	
Warming	
Engine Control Unit (ECU) serial number	
Engine coolant	
Disposing of	10 12
Engine mounts	10-12
	40.6
Checking	40-6

Continued on next page

Engine oil Break-In Interim tier 4, final tier 4, stage IIIB, and stage IV
Interim tier 4, final tier 4, stage IIIB, and
stage IV
OEM applications 10-7 Engine oil filter
Service intervals 10-8
Engine speed
Changing
Engine wiring layout 65-17
Exhaust Filter
Exhaust Filter Cleaning Disable
Exhaust Filter Service Required
Exhaust Filters
Ash handling and disposal 25-2
Automatic cleaning
Cleaning
Disposal
Maintenance and service
Manual/parked cleaning25-6
Passive regeneration/natural cleaning
Service required

F

Fan belt	60-10
Fan belts	
Filter, Air, Replacement	
Filter, Axial air	60-7
Filter, replace	
Fuel	37-1
Oil	40-3
Filters	
Exhaust	
Ash handling and disposal	25-2
Automatic cleaning	
Cleaning	
Cleaning and maintenance	
Disposal	25-2
Maintenance and service	25-2
Manual/parked cleaning	25-6
Passive regeneration/natural cleaning	25-5
Service required	25-7
System overview	25-3
Filters, Oil	
Oil Filters	10-9

Page

Fire extinguisher, service	40-1
Fuel	
BioDiesel	10-3
Diesel	10-1
Handling and storing	
Lubricity	
Fuel filter	
Replace	37-1
Fuel Filter	
Drain water	60-2
Fuel Filters	
Filters, Fuel	10-4
Filters, Fuel Fuel pump model number	01-3
Fuel system	
Bleeding	60-2
Fuels, lubricants and coolant	30-1
Fuses	
Checking	60-11

G

Generator set (sta	andby) applications	20-2
--------------------	---------------------	------

Н

Hardware torque values	
Metric	75-4
Unified inch	75-3

I

Instrument panels	
Adjust backlighting	15-12
Adjust contrast	15-14
Changing units of measure	15-15
Component function	15-1
John Deere PowerSight	15-27
Main menu navigation	15-3
Setup 1-up display	15-17
Setup 4-up display	15-23
Shutdown codes	15-11
Using diagnostic gauge	15-3
Viewing active service codes	15-9
Viewing configuration data	15-5
Viewing stored service codes	15-7
Intermittent fault code diagnostics	65-4

J

John Deere PowerSight 15-	27
---------------------------	----

L

Long-term storage	
Preparing engine	70-1
Removing from	70-2

Continued on next page

Lubricant	
Mixing	. 10-8
Lubricant Storage	
Storage, Lubricant	10-9
Lubricants, Safety	
Safety, Lubricants	10-8
Lubrication and maintenance	
1500 hours	
Changing open crankcase vent (OCV) filter	50-1
500 hours/12 months	
Checking and adjusting engine speeds	.40-11
Checking cooling system	40-9
Checking engine ground connection	
Checking open crankcase vent (OCV)	
Chekcing engine mounts	40-6
Inspecting coolant pump	
Pressure testing cooling system	
Servicing battery	40-1
Servicing fire extinguisher	40-1
•	60 11
Checking electrical wiring and connections Checking fuses	60_11
Cleaning the exhaust filter	60-10
Drain water from fuel filter	60-2
Pre-start cleaning guide	
Daily	
Prestarting checks	35-1
Lubrication and Maintenance	
Service Interval Chart	30-2
Lubrication and Maintenance Records	
Lubricity of diesel fuel	10-2
-	

Μ

Maintenance Records	80-1
Manual/parked filter cleaning	
Metric bolt and screw torque values	75-4
Mixing lubricants	

Ν

Natural Cleaning25	-;	5
--------------------	----	---

0

Oil	
Engine	
Interim tier 4, final tier 4, stage IIIB, and	
stage IV	10-6
Fill quantity	
Oil filter, change	40-3
Open crankcase vent (OCV)	
Checking	40-5
Operating engine	
Break-in	20-1
Changing speed	20-5
Cold weather	20-6

Idling20-4Normal operation20-3Warming engine20-4Option codes01-2Orientation View, Engine-5

Ρ

Passive Regeneration	25-5
Power ratings	
Pre start cleaning	
Guide	60-5
Prestarting Service, Daily	80-1
Proposition 65	05-2

R

Recordkeeping	
Engine Control Unit (ECU) serial number	01-4
Engine option codes	01-2
Fuel pump model number	01-3
Refueling, avoid static electricity risk	05-10
Registration	

S

Safety, Avoid High-Pressure Fluids	
Avoid High-Pressure Fluids	05-9
Safety, Handle Fuel Safely, Avoid Fires	
Avoid Fires, Handle Fuel Safely	05-10
Serial number	
Engine Control Unit (ECU)	01-4
High-pressure fuel pump	01-3
Serial Number Plate	
Engine Serial Number	01-1
Service	
1500 hours	
Changing open crankcase vent (OCV) filter	50-1
500 hours/12 months	
Checking and adjusting engine speeds	40-11
Checking cooling system	
Checking engine ground connection	
Checking engine mounts	
Checking open crankcase vent (OCV)	
Inspecting coolant pump	40-5
Pressure testing cooling system	40-10
Servicing battery	40-1
Servicing fire extinguisher	40-1
As required	
Checking electrical wiring and connections	
Checking fuses	
Cleaning the exhaust filter	60-10
Drain water from fuel filter	60-2
Pre-start cleaning guide	60-5
Daily	
Prestarting checks	35-1
Intervals	30-2

Continued on next page

Page

Service Chart	
500 hours or 12 months	80-1, 80-2
As required	80-4
Service Information, Additional	60-1
Service intervals	
General information	30-1
Service Records	
1500 hours	80-2
3000 hours or 36 months	
6000 hours or 72 months	80-3
Service, Daily Prestarting	80-1
Specifications	
2.9 L Wiring Diagram 1	65-23
2.9 L Wiring Diagram 2	65-25
2.9 L Wiring Diagram 3	65-26
2.9 L Wiring Diagram 4	
2.9 L Wiring Diagram 5	
2.9 L Wiring Diagram 6	65-32
2.9 L Wiring Diagram 7	65-34
2.9 L Wiring Diagram 8	65-35
2.9 L Wiring Diagram 9	
Engine crankcase oil fill	
Fuel injection pump and power ratings	
General OEM	
Starting engine	
Steam Cleaning Engine	
Stopping engine	
Storage	70.4
Guidelines	
Storing fuel	10-2

Т

Thermostat Install	55-3
Remove	55-3
Test opening temperature	55-3
Torque charts	
Metric	75-4
Unified inch	
Trademarks	6
Troubleshooting	
DTC Operation	
General information	65-1
General, engine	65-5
Intermittent fault diagnostics	
Listing DTCs	

U

Unified inch bolt and screw torque values7	5-3
Units of measure, changing 15	-15

V

Valves	
Clearance, check and adjust 45-1	

W

Warranty Non-road emissions control warranty statementcompression ignition	
CARB	85-7
EPA	85-5
OEM applications	85-1
Welding precautions, Safety	65-22
Wiring connections	

Page

OEM Engine and Drivetrain Warranty Registration

Why registering your OEM engine or drivetrain product is a really smart idea:¹

Get faster service. Registering your engine or drivetrain product gives us the information we need to meet your service needs promptly and completely.

Protect your investment. You'll be kept up-to-date on engine or drivetrain product updates.

Extend your warranty. You'll be given the option to extend your coverage before your standard warranty term expires.

Stay informed. Be the first to know about new products and money-saving offers from John Deere.

NOTE: A mail-in registration form is located at the back of this manual.

You're Covered

When you buy a John Deere engine or drivetrain product you aren't just buying pistons and crankshafts and gear drives. You're buying the ability to get work done. Without downtime, without worries, and without hassles. And you're buying the assurance that if you do need help, a strong support network will be there — ready to step in.

Confidence. That's what John Deere engines, John Deere drivetrains, and John Deere Warranties are all about.

Long durations. Warranties designed to give you confidence in your engine or drivetrain product.

Worldwide support. Get service when and where you need it. John Deere has 4,000+ service locations worldwide.

Genuine John Deere parts and service. Authorized service outlets will use only new or remanufactured parts or components furnished by John Deere.

Warranty Duration

¹Register your OEM engine or drivetrain product online and select an authorized John Deere service location. If available in your region, you'll receive information regarding new products and current money-saving offers from John Deere. Limit one money-saving offer per engine warranty registration. Not transferable. Not valid with any other offer. Offer ends 90 days from the date of issue. Some restrictions apply. See your John Deere service location for complete details.



Scan this code to register your OEM engine online now and learn of current money-saving offers available to you.¹ You can also visit us directly at JohnDeere.com/warranty.

Equipment operators can't afford downtime or unexpected repairs. That's why we offer a 2-year/2,000-hour warranty, with unlimited hours in the first year, on our OEM industrial and marine engines. This warranty takes effect the date that the engine is delivered to the first retail purchaser. In addition, extended warranties are available under certain conditions. John Deere offers a variety of purchased warranties to extend the warranty period for your engine. You'll be given the option to extend your coverage before your standard warranty term expires. Be sure to register your engine or drivetrain product and take full advantage of the John Deere service and support network.

Obtaining Warranty Service

Warranty service must be requested through an authorized John Deere service outlet before the expiration of the warranty. Evidence of the engine's or drivetrain product's delivery date to the first retail purchaser must be presented when requesting warranty service. Authorized service outlets include:

- John Deere distributor
- John Deere OEM service dealer
- John Deere equipment dealer
- John Deere marine dealer

Worldwide Support Network

Visit JohnDeere.com/dealer to find the authorized engine or drivetrain service location nearest you. For complete warranty details visit JohnDeere.com/warrantystatements to view, download, or print the warranty statement for your engine or drivetrain product.

ZE59858,000025E -19-02DEC13-1/1

OEM Engine and Drivetrain Warranty Registration			
Register your OEM engine or drivetrain product online at JohnDeer	e.com/warranty or fax this from t	to John Deere at 319-292-5844.	
PURCHASER INFORMATION*: Type or print in BLOCK letters	PURCHASER TYPE:	EQUIPMENT TYPE:	
Company Name:			
First Name:	 Federal Government State / Province 	□ Earth Moving □ Forestry	
_ast Name:		□ Generator Set (Industrial / Marine)	
Email:	City / Town / Village	Industrial Moveable	
Telephone:	□ Armed Forces □ National Account	 Marine Propulsion Material Handling 	
Country:	□ Residential	Municipal / Utility Commercial	
Street Address:	□ Farm □ Very Large Fleet (>74)	□ On-Highway □ Road and Miscellaneous Construction	
City / State / Prov:		 Road and Miscellaneous Construction Rail Maintenance 	
Zip / Postal Code:		□ Other	
	Purchase's Signature:		
PRODUCT AND EQUIPMENT INFORMATION	* Use of Information: All pe	rsonal information obtained with this	
Product Serial Number:	_ registration is subject to the	John Deere privacy policy. It will be used	
Date Delivered:		ment and may be used to provide you with	
Amount of Use: (Hours / Miles)	 additional information about John Deere products and services. For complete details on your privacy rights and to obtain a copy of the John 		
New or Used:			

Cut out to mail in registration card

BL90236,0000028 -19-19NOV13-1/1

Mail-In Registration

MAILING INFORMATION (Return Address)

> John Deere Power Systems P.O. Box 5100 Waterloo, IA 50704-5100 USA

> > BL90236,0000029 -19-19NOV13-1/1





Axial Piston Pumps and Motors Service Manual



Introduction

1. Introduction

1.1 Use of This Manual

This manual includes information for the normal operation, maintenance, and servicing of the Series 90 family of hydrostatic pumps and motors. The manual includes the description of the units and their individual components, troubleshooting information, adjustment instructions, and minor repair procedures. Unit warranty obligations should not be affected if maintenance, adjustment, and minor repairs are performed according to the procedures described in this manual.

Many service and adjustment activities can be performed without removing the unit from the vehicle or machine. However, adequate access to the unit must be available, and the unit must be thoroughly cleaned before beginning maintenance, adjustment, or repair activities. Since dirt and contamination are the greatest enemies of any type of hydraulic equipment, cleanliness requirements must be strictly adhered to. This is especially important when changing the system filter and during adjustment and repair activities.

A worldwide network of Sauer-Sundstrand Authorized Service Centers is available should repairs be needed. Contact any Sauer-Sundstrand Authorized Service Center for details. A list of all Service Centers can be found in bulletin BLN-2-40527, or in brochure SAW (Ident. No. 698266).

1.2 Safety Precautions

Observe the following safety precautions when using and servicing hydrostatic products.

Loss of Hydrostatic Braking Ability

WARNING

When Series 90 units are used in vehicular hydrostatic drive systems, the loss of hydrostatic drive line power in any mode of operation (e.g. acceleration, deceleration or "neutral" mode) may cause a loss of hydrostatic braking capacity. A braking system which is independent of the hydrostatic transmission must, therefore, be provided which is adequate to stop and hold the system should the condition develop.

Disable Work Function

WARNING

Certain service procedures may require the vehicle/machine to be disabled (wheels raised off the ground, work function disconnected, etc.) while performing them in order to prevent injury to the technician and bystanders.

Fluid Under High Pressure

WARNING

Use caution when dealing with hydraulic fluid under pressure. Escaping hydraulic fluid under pressure can have sufficient force to penetrate your skin causing serious injury. This fluid may also be hot enough to burn. Serious infection or reactions can develop if proper medical treatment is not administered immediately.

Flammable Cleaning Solvents

WARNING

Some cleaning solvents are flammable. To avoid possible fire, do not use cleaning solvents in an area where a source of ignition may be present.



Introduction

Contents

1. Introd	duction	2
	Use of This Manual	
	Safety Precautions	
2. Funct	tional Description	5
2.1	General Description and Cross Sectional Views	
	2.1.1 Variable Displacement Pumps	
	2.1.2 Fixed Displacement Motor	
	2.1.3 Variable Displacement Motor	
	The System Circuit	
2.3	Common Features of Pumps and Motors	
	2.3.1 End Caps and Shafts	
2.4	2.3.2 Speed Sensors Pump Features	
2.4	2.4.1 Charge Pump	
	2.4.1 Charge Pump 2.4.2 Charge Relief Valve	
	2.4.2 Charge Check Valves	
	2.4.4 Multi-Function Valves	
	2.4.5 Pressure Limiter and High Pressure Relief Valves	10
	2.4.6 Bypass Valves	
	2.4.7 Displacement Limiters	
	2.4.8 Auxiliary Mounting Pads	
	2.4.9 Filtration Options	
	2.4.10 Pressure Override (POR) - 180 Frame Size Only	
2.5	Pump Control Options	
	2.5.1 Manual Displacement Control (MDC)	
	2.5.2 Hydraulic Displacement Control (HDC)	
	2.5.3 Electric Displacement Control (EDC)	
	2.5.4 Automotive Control (AC and AC II)	
	2.5.5 3-Position (FNR) Electric Control	
2.6	Motor Features	
	2.6.1 Motor Loop Flushing Valve and Charge Relief Valve2.6.2 Variable Motor Displacement Limiters	
27	Variable Motor Controls	
2.1	2.7.1 Hydraulic 2-Position Control	
	2.7.2 Electric 2-Position Control	
3. Techr	nical Specifications	
	General Specifications	
	Circuit Diagrams	
	Hydraulic Parameters	
3.4	Technical Data	19
4. Press	sure Measurement	20
	Required Tools	
4.2	Port Locations and Pressure Gauge Installation	
	4.2.1 Variable Pump	
	4.2.2 Fixed Motor	
5 1	4.2.3 Variable Motor	
	Start-Up Procedure	
	and Filter Maintenance	
7. Iroud 7.1	"Neutral" Difficult or Impossible to Find	
	System Operating Hot	
	Transmission Operates Normally in One Direction Only	
	System Will Not Operate in Either Direction	
	Low Motor Output Torque	
7.6	Improper Motor Output Speed	
-	Excessive Noise and/or Vibration	
	System Response is Sluggish	
(co	ntinued)	



Introduction

8. Inspe	ctions a	Ind Adjustments	31
8.1	Pump A	Adjustments	. 31
	8.1.1	Charge Relief Valve Adjustment	31
	8.1.2	Multi-Function Valve Pressure Adjustment	
	8.1.3	Engaging the Bypass Function	
	8.1.4	Pressure Override (POR) Valve Pressure Adjustment (Option for 180 Frame Size)	
	-	Displacement Limiter Adjustment	
82		Control Adjustments	
0.2	8.2.1	Standard Manual Displacement Control (MDC) Adjustment	
	-	Non-Linear Manual Displacement Control (MDC)	
		MDC Neutral Start Switch (NSS) Adjustments	
		Hydraulic Displacement Control (HDC) and Electric Displacement Control (EDC) Adjustment	
83		Adjustments	
0.5	8.3.1	Charge Relief Valve Adjustment	
		Displacement Limiter Adjustment (MV)	
		Displacement Control Adjustments	
8.4		Sensor Adjustment	
		Instructions	
		and Motor Minor Repair	
9.1	•	Plug / Fitting Torques	
	9.1.1 9.1.2		
0.0		Shaft Seal and Shaft Replacement /linor Repairs	
9.2			
		Multi-Function Valve Cartridges	
	9.2.2	Pressure Over-Ride Valve (Option for 180 Frame Size)	
		Charge Relief Valve	
		Charge Pump	
		Auxiliary Pad Installation	
	9.2.6	Filtration Options	
9.3	•	Controls	
		Cover Plate	
		Manual Displacement Control (MDC)	
	9.3.3	Solenoid Override Valve for MDC	
	9.3.4	Solenoid Override Valve for MDC with Pressure Released Brake	
	9.3.5	Hydraulic and Electric Displacement Controls	
	9.3.6	Pressure Control Pilot (PCP) for Electric Displacement Control	
	9.3.7	3-Position (FNR) Electric Control	69
		Displacement Control Components	
9.4	Minor F	Repairs - Motor	
	9.4.1	Loop Flushing and Charge Relief Valves	71
		Variable Motor Displacement Limiters	
9.5	Variable	e Motor Controls	74
	9.5.1	Electrohydraulic 2-Position Control (Types NA, NB, NC, and ND)	
	9.5.2	Hydraulic 2-Position Control (Type PT)	74
	9.5.3	Housing Plugs	
	9.5.4	Variable Motor Control Orifices	75
9.6	Speed	Sensor	.77
10. Expl	oded Vi	ew Parts Drawings	78
10.1	I Variable	e Pumps	78
	10.1.1	Name Plates	78
	10.1.2	Minor Repair Parts	78
		Controls	
		Filtration Options, Charge Pump Options, Auxiliary Pad Options	
		Pump Parts List	
10.2		Aotor	
		Name Plates	
		Minor Repair Parts	
		Fixed Motor Parts List	
10.3		e Motor	
		Name Plate	
		Minor Repair Parts	
		Variable Motor Parts List	



Functional Description

2. Functional Description


This section describes the operation of pumps, motors, and their various serviceable features. It is a useful reference for readers unfamiliar with the functioning of a specific system.

2.1 General Description and Cross Sectional Views


2.1.1 Variable Displacement Pumps

The Variable Displacement Pump (PV) is designed to convert an input torque into hydraulic power. The input shaft turns the pump cylinder which contains a ring of pistons. The pistons run against a tilted plate, called the swashplate. This causes the pistons to compress the hydraulic fluid which imparts the input energy into the hydraulic fluid. The high pressure fluid is then ported out to provide power to a remote function.

The swashplate angle can be varied by the control piston. Altering the swashplate angle varies the displacement of fluid in a given revolution of the input shaft. A larger angle causes greater displacement which yields greater output torque for a given input. A smaller angle reduces the displacement per revolution and yields greater speed for a given input.



Series 90 Variable Displacement Pump (PV)



Series 90 PV Cross Section

90000189

2



The Fixed Displacement Motor (MF) is designed to convert an input of hydraulic power into an output torque. It operates in the reverse manner of the pump. The high pressure hydraulic fluid enters through the input port. The fluid pressure builds behind the pistons causing them to move down the swashplate (the path of least resistance). As the piston returns up the swashplate again, the fluid is allowed to exit through the exit port. The spinning pistons are housed in a cylinder which is connected to the output shaft. The output torque can be applied to a mechanical function.




Series 90 Fixed Displacement Motor (MF)

90000347



Functional Description



Series 90 MF Cross Section


In the Fixed Displacement Motor the "swashplate" is fixed, so any variation in motor speed and torque must be made by the input mechanism, i.e. the pump.



Series 90 Variable Displacement Motor (MV)

2.1.3 Variable Displacement Motor

The Variable Displacement Motor (MV) operates in the same manner as the fixed motor. However, its swashplate is not fixed; it can be switched between minimum and maximum angle to amplify torque or speed like the Variable Displacement Pump.




90000234

Series 90 MV Cross Section



2.2 The System Circuit




Circuit Diagram for Series 90 PV and Series 90 MF

The Basic Closed Circuit

The main ports of the pump are connected by hydraulic lines to the main ports of the motor. Fluid flows, in either direction, from the pump to the motor then back to the pump in this closed circuit. Either of the hydraulic lines can be under high pressure. The position of the pump swashplate determines which line is high pressure as well as the direction of fluid flow.

Case Drain and Heat Exchanger

The pump and motor require case drain lines to remove hot fluid from the system. The motor should be drained from its topmost drain port to ensure the case remains full of fluid. The motor case drain can then be connected to the lower drain port on the pump housing and out the top most port. A heat exchanger, with a bypass valve, is required to cool the case drain fluid before it returns to the reservoir.



Basic Closed Circuit



2.3 Common Features of Pumps and Motors

Speed Sensor

2.3.1 End Caps and Shafts

Series 90 pumps and motors can be supplied with a variety of end caps and shafts to allow for almost any configuration. For pumps, end caps are available with system ports on either side ("side ports") or both ports on one side ("twin ports"). Motors have end caps with ports on the face of the end cap ("axial ports") or both ports on one side ("twin ports"). See the Series 90 Technical Information manuals (BLN-10029 and BLN-10030) or the Series 90 Price Book (BLN-2-40588) for information on available options. **Removing the end cap will void the warranty on a Series 90 pump or motor.**

2

2.3.2 Speed Sensors

An optional speed sensor can be installed on Series 90 pumps and motors to provide unit speed information. The sensor reads a magnetic ring wrapped about the unit's cylinder. See Sec. 4 to locate the speed sensor port. See Sec. 8.4 and 9.6 to adjust and install the sensor.

Series 90

2.4 Pump Features

2.4.1 Charge Pump

The charge pump is necessary to supply cool fluid to the system, to maintain positive pressure in the main system loop, to provide pressure to operate the control system, and to make up for internal leakage. Charge pressure must be at its specified pressure under all conditions of driving and braking to prevent damage to the transmission.

The charge pump is a fixed-displacement, gerotor type pump installed in the variable displacement pump and driven off the main pump shaft. Charge pressure is limited by a relief valve (Sec. 2.4.2).

The standard charge pump will be satisfactory for most applications. However, if the charge pump sizes available for the given main pump size are not adequate, a gear pump may be mounted to the auxiliary mounting pad (Sec. 2.4.8) and supply the required additional charge flow. For repairs to the charge pump see Sec. 9.2.4.

2.4.2 Charge Relief Valve

The charge relief valve on the pump serves to maintain charge pressure at a designated level. A directacting poppet valve relieves charge pressure whenever it surpasses a certain level. This level is nominally set referencing case pressure at 1775 rpm. This nominal setting assumes the pump is in neutral (zero flow); in forward or reverse charge pressure will be lower. The charge relief valve setting is specified on the model code of the pump (Sec. 8.1.1). For repairs to the pump charge relief valve see Sec. 9.2.3.

2.4.3 System Check Valves


The system check valves allow pressurized flow from the charge pump to enter the low pressure side of the loop whenever system pressure dips below a certain level. This is needed as the pump will generally lose system pressure due to leakage and other factors. Since the pump can operate in either direction, two system check valves are used to direct the charge supply into the low pressure lines. The system check valves are poppet valves located in the multi-function valve assembly (next section).



PV with Charge Pump




Charge Pump Components




Pump Charge System


Functional Description



PV showing location of Multi-Function Valves



Cross Section of Multi-Function Valve



Circuit Diagram Showing Pressure Control Mechanisms

2.4.4 Multi-Function Valves

All Series 90 pumps include two multi-function valves. The multi-function valve incorporates the system check valve, the pressure limiter valve, the high pressure relief valve, and the bypass valve in a replaceable cartridge. These functions are described separately. There are two multi-function valve cartridges in each Series 90 pump to handle functions in either direction. See Secs. 8.1.2 and 9.2.1 for adjustments and repairs.

NOTE: Some multi-function valves do not include a pressure limiter valve.

2.4.5 Pressure Limiter and High Pressure Relief Valves

Series 90 pumps are designed with a sequenced pressure limiting system and high pressure relief valves. When the preset pressure is reached, the pressure limiter system acts to rapidly destroke the pump so as to limit the system pressure. For unusually rapid load application, the high pressure relief valve acts to immediately limit system pressure by cross-porting system flow to the low pressure side of the loop. The pressure limiter valve acts as the pilot for the high pressure relief valve spool. The high pressure relief valve is sequenced to operate at approximately 35 bar (500 psi) above the level that initiates the pressure limiter valve.

Both the pressure limiter sensing valves and relief valves are built into the multi-function valves (see above).

NOTE: For some applications, such as dual path vehicles, the pressure limiter function may be defeated so that only the high pressure relief valve function remains.

2.4.6 Bypass Valves

The bypass valves ("tow") can be operated when it is desired to move the vehicle or mechanical function when the pump is not running. The valve is opened by manually resetting the valve position (Sec. 8.1.3).

The bypass valves are built into the multi-function valves (see above).




Functional Description

2.4.7 **Displacement Limiters**

Series 90 pumps sizes 042 - 250 are designed for optional mechanical displacement (stroke) limiters. The maximum displacement of the pump can be limited in either direction.

The setting can be set as low as 0° in either direction.

For instructions on adjustment see Sec. 8.1.5.




2

PV with Displacement Limiters

2.4.8 **Auxiliary Mounting Pads**

Auxiliary mounting pads are available on all Series 90 pumps. SAE A through E and H mounts are available (availability varies by pump size). This pad is used for mounting auxiliary hydraulic pumps and for mounting additional Series 90 pumps to make tandem pumps. The pads allow for full through-torque capability.



PV with Auxiliary Mounting Pad

2.4.9 **Filtration Options**

All Series 90 pumps are available with provisions for either suction or charge pressure filtration (integral or remote mounted) to filter the fluid entering the charge circuit. (See Sec. 6 for more information.)


Suction Filtration

The suction filter is placed in the circuit between the reservoir and the inlet to the charge pump. When suction filtration is used, a reducer fitting is placed in the charge pressure gauge port (M3). Filtration devices of this type are provided by the user.

Charge Pressure Filtration

The pressure filter may be integrally mounted directly on the pump or a filter may be remotely mounted for ease of servicing.

A 200 mesh screen, located in the reservoir or the charge inlet line, is recommended when using this filtration option. A non-bypass filter is preferred on all types of filtration.




PV with Suction Filtration (No filtration device attached)



PV with Integral Charge Pressure Filtration (left) PV with Remote Charge Pressure Filtration (right, filter attached remotely)



Functional Description



Pressure Override - 180 Frame Size Only

2.4.10 Pressure Override (POR) - 180 Frame Size Only

The pressure override valve (POR) modulates the control pressure to the displacement control to maintain a pump displacement which will produce a system pressure level less than or equal to the POR setting. For unusually rapid load application, the high pressure relief valve function of the multifunction valves is available to also limit the pressure level.

2

The pressure override consists of a three-way normally open valve which operates in series with the pump displacement control. Control supply pressure is normally ported through the pressure override valve to the displacement control valve for controlling the pump's displacement. If the system demands a pressure above the override setting, the POR valve will override the control by reducing the control pressure supplied to the displacement control. As the control pressure reduces, the internal forces tending to rotate the swashplate overcome the force of the servo pistons and allow the pump's displacement to decrease.



Functional Description

2.5 **Pump Control Options**

2.5.1 Manual Displacement Control (MDC)

The manual displacement control converts a mechanical input signal to a hydraulic signal using a springcentered four-way servo valve. This valve ports hydraulic pressure to either side of a dual-acting servo piston. The servo piston rotates the cradle swashplate through an angular rotation of $\pm 17^{\circ}$, thus varying the pump's displacement from full displacement in one direction to full displacement in the opposite direction. The MDC is designed so the angular position of the pump swashplate is proportional to the rotation of the control input shaft. For adjustments see 8.2.1; for repairs see 9.3.2, 9.3.8.

Non-Linear MDC

The non-linear manual displacement control (photo in Sec. 8.2.2) operates in the same manner as the regular MDC except that it is designed so the change in the angular position of the pump swashplate *progressively* increases as the control input shaft is rotated toward its maximum displacement position. For adjustments see Sec. 8.2.2; for repairs see 9.3.2.

Solenoid Override Valve

A solenoid override valve option (not shown here) is available for MDC. This safety feature will return the swashplate to zero displacement position when activated. The valve may be set in either a normally open or normally closed mode. For repairs see 9.3.3, 9.3.4.

Neutral Start Switch (NSS)


The neutral start switch is an optional feature available with MDC. When connected properly with the vehicle's electrical system, the neutral start switch ensures that the prime mover can be started only when the control is in a neutral position. For adjustments see Sec. 8.2.3.

2.5.2 Hydraulic Displacement Control (HDC)

The hydraulic displacement control uses a hydraulic input signal to operate a spring-centered four-way servo valve. This valve ports hydraulic pressure to either side of a dual-acting servo piston. The servo piston rotates the cradle swashplate through an angular rotation of $\pm 17^{\circ}$, thus varying the pump's displacement from full displacement in one direction to full displacement in the opposite direction. The HDC is designed so the angular position of the pump swashplate is proportional to input pressure. For adjustments see 8.2.4; for repairs see 9.3.5, 9.3.8.



PV with Manual Displacement Control



PV with Manual Displacement Control and Neutral Start Switch



PV with Hydraulic Displacement Control

Functional Description



SAUER SUNDSTRAND

Series 90


PV with Electric Displacement Control



PV with Automotive Control (AC)



F000645 PV with Automotive Control Type II (AC II)



PV with 3-Position (FNR) Electric Control

2.5.3 Electric Displacement Control (EDC)

The electric displacement control is similar to the hydraulic displacement control with the input signal pressure controlled by a pressure control pilot (PCP) valve. The PCP valve converts a DC electrical input signal to a hydraulic signal which operates a spring-centered four-way servo valve. This valve ports hydraulic pressure to either side of a dual-acting servo piston. The servo piston rotates the cradle swash-plate through an angular rotation of $\pm 17^{\circ}$, thus varying the pump's displacement from full displacement in one direction to full displacement in the opposite direction. The swashplate is proportional to the EDC input. For neutral adjustment see Sec. 8.2.4; for repairs see Sec. 9.3.5, 9.3.6, and 9.3.8.

2.5.4 Automotive Control (AC and AC II)

Automotive Control (AC) allows a vehicle to be driven in a manner similar to an automobile with an automatic transmission.

The AC control includes a three-position electric control to provide direction control.

The AC II control can be combined with a manual, hydraulic, or electric displacement control to provide both direction control and control over maximum vehicle speed. It may also be combined with a 3position electric control to provide direction control.

2.5.5 3-Position (FNR) Electric Control

This control utilizes a 12 or 24 VDC electrically operated spool valve to port pressure to either side of the pump displacement control piston. Energizing one of the solenoids will cause the pump to go to its maximum displacement in the corresponding direction.

All functions of the three-position (FNR) electric control are preset at the factory. For repairs, see Sec. 9.3.7.

SAUER SUNDSTRAND

Series 90

2.6 Motor Features


2.6.1 Motor Loop Flushing Valve and Charge Relief Valve

All Series 90 motors are designed to accommodate a loop flushing valve. The loop flushing valve is used in installations which require additional fluid to be removed from the main hydraulic circuit because of transmission cooling requirements, or unusual circuits requiring additional loop flushing to remove excessive contamination in the high pressure circuit.


A shuttle valve and charge relief valve are installed in the motor end cap to provide the loop flushing function. The shuttle valve provides a circuit between the low pressure side of the closed loop and the charge relief valve in the motor end cap.

The motor charge relief valve regulates the charge pressure level only when there is a pressure differential in the main loop. The shuttle valve is spring centered to the closed position so that no high pressure fluid is lost from the circuit when reversing pressures.

For charge relief valve adjustment see Sec. 8.3.1, for repairs see Sec. 9.4.1.



MF showing location of Loop Flushing Valve



Motor Charge Relief Valve and Loop Flushing Shuttle Valve


2.6.2 Variable Motor Displacement Limiters

All Series 90 variable motors include mechanical displacement (stroke) limiters. Both the maximum and minimum displacement of the motor can be limited.

The range of the settings is as follows:

	055 MV Frame	075 MV Frame
Minimum Displacement	19 - 40 cm³ 1.2 - 2.4 in³	26 - 54 cm³ 1.6 - 3.3 in³
Maximum Displacement	65 - 100%	65 - 100%


For adjustments see Sec. 8.3.2.



MV Maximum Displacement Limiter (Minimum Displacement Limiters on Opposite Side)



2.7 Variable Motor Controls




MV with Hydraulic 2-Position Control

2.7.1 Hydraulic 2-Position Control

This control utilizes a hydraulically operated threeway hydraulic valve to port system pressure to either of the motor displacement control pistons. The motor is normally held at its maximum displacement. Supplying pilot hydraulic pressure to the valve will cause the motor to go to its minimum displacement.

All functions of the hydraulic two-position control are preset at the factory. For repairs see Sec. 9.5.2 and 9.5.4.



90000351

MV with Electric 2-Position Control

2.7.2 Electric 2-Position Control

This control utilizes an electric solenoid operated three-way hydraulic valve to port system pressure to either of the motor displacement control pistons. The motor is normally held at its maximum displacement. Energizing the solenoid will cause the motor to go to its minimum displacement.

All functions of the electric two-position control are preset at the factory. For repairs see Sec. 9.5.1 and 9.5.4.



3. Technical Specifications

3.1 General Specifications

Design

Variable Pumps and Motors: Axial piston pump of variable displacement, cradle swashplate design. Fixed Motors: Axial piston motor with fixed displacement, fixed swashplate design.

Type of Mounting (per SAE J744)

SAE flange, Size "B" mounting pad, 2 bolts SAE flange, Size "C" mounting pad, 4 bolts Cartridge flange, 2 bolts (for motor only) **Port Connections** (See Sec. 4.2 for exact specs.) Main pressure ports: SAE flange, Code 62 Remaining ports: SAE straight thread O-ring boss

3


Direction of Rotation

Clockwise or counterclockwise (motors are bidirectional)


Installation Position

Installation position is discretionary. The housing must always be filled with hydraulic fluid, so note position of drain ports.


3.2 Circuit Diagrams



PV with charge pump and manual displacement control



MV with electrohydraulic twoposition control



MF



Technical Specifications

3.3 Hydraulic Parameters

System Pressure Range

Maximum Pressure	480 bar	[6960 psi]
Rated Pressure	420 bar	[6000 psi]

Charge Pump Inlet Vacuum (on pumps only)

Maximum Vacuum, Continuous	0.7 bar abs	[10 in Hg]
Maximum Vacuum, Cold Start	0.2 bar abs	[25 in Hg]

Case Pressure

Maximum, Continuous	3 bar	[44 psi]
Maximum, Intermittent or Cold Start	5 bar	[73 psi]

Hydraulic Fluid

Refer to SAS publication BLN 9887 or Publication SDF (Id. No. 697581). Also refer to publication ATI-E 9101 for information relating to biodegradable fluids

Temperature Range¹

Minimum, Intermittent or Cold Start	-40°C	[-40°F]
Maximum, Continuous	104°C	[220°F]
Maximum, Intermittent	115°C	[240°F]

Fluid Viscosity Limits

Minimum, Intermittent	5 mm²/s	[42 SUS]
Minimum, Continuous	6.4 mm²/s	[47 SUS]
Minimum, Optimum	13 mm²/s	[70 SUS]
Maximum, Continuous	110 mm²/s	[510 SUS]
Maximum, Intermittent or Cold Start	1600 mm²/s	[7400 SUS]

Filtration

Required cleanliness level: ISO 4406 Class 18/13 or better. Refer to SAS publications BLN 9887 or Publication SDF (Id. No. 697581) and ATI-E 9201.

^{1.} At hottest point in system, normally the case drain port. Temperature and viscosity limits must be met simultaneously.

SAUER SUNDSTRAND

Series 90

Technical Specifications

3.4 Technical Data

Table 1 - Variable Displacement Pumps

	Dimension	030 PV	042 PV	055 PV	075 PV	100 PV	130 PV	180 PV	250 PV
Displacement (maximum)	cm³ in³	30.0 1.83	42.0 2.56	55.0 3.35	75.0 4.57	100.0 6.10	130.0 7.93	180.0 10.98	250.0 15.25
Minimum speed	min ⁻¹ (rpm)	500	500	500	500	500	500	500	500
Rated speed*	min ⁻¹ (rpm)	4200	4200	3900	3600	3300	3100	2600	2300
Maximum speed*	min ⁻¹ (rpm)	4600	4600	4250	3950	3650	3400	2850	2500
Max. attainable speed* at max. disp.	min ⁻¹ (rpm)	5000	5000	4700	4300	4000	3700	3150	2750
Theoretical torque at max. disp.	Nm / bar lbf•in/1000 psi	0.48 290	0.67 380	0.88 530	1.19 730	1.59 970	2.07 1260	2.87 1750	3.97 2433
Weight (Base Unit)	kg Ib	28 62	34 75	40 88	49 108	68 150	88 195	136 300	154 340

Table 2 - Fixed and Variable Displacement Motors

		Dimension	030 MF	042 MF	055 MF	075 MF	100 MF	130 MF	055 MV	075 MV
Displacement (maximum)		cm ³ in ³	30.0 1.83	42.0 2.56	55.0 3.35	75.0 4.57	100.0 6.10	130.0 7.93	55.0 3.35	75.0 4.57
Displaceme	ent (minimum)	cm³ in³		_	_	_	_	_	19.0 1.16	26.0 1.59
Rated	at max. disp.	min ⁻¹ (rpm)	4200	4200	3900	3600	3300	3100	3900	3600
speed*	at min. disp.	min ⁻¹ (rpm)	_	_		_			4600	4250
Maximum	at max. disp.	min ⁻¹ (rpm)	4600	4600	4250	3950	3650	3400	4250	3950
speed*	at min. disp.	min ⁻¹ (rpm)	_	_	_	—		_	5100	4700
Max. attaina at max. disp	able speed* o.	min ⁻¹ (rpm)	5000	5000	4700	4300	4000	3700	4700	4300
Theoretical at max. disp		Nm / bar lbf•in/1000 psi	0.48 290	0.67 380	0.88 530	1.19 730	1.59 970	2.07 1260	0.88 530	1.19 730
Maximum fl at max. dis		l / min gal / min	138 36.5	193 51	234 62	296 78	365 96	442 117	234 62	296 78
Max. corne	r power	kW hp	111 149	155 208	187 251	237 318	292 392	354 475	224 300	282 378
Weight (SAE Flange)		kg Ib	11 24	15 34	20 45	26 57	34 74	45 99	39 86	44 98
Weight (Cartridge N	Motor)	kg Ib	_	17 37	26 57	33 72	_	_	40 88	46 101

* = Refer to Series 90 Technical Information manual for definitions



Pressure Measurement

4. Pressure Measurement

4.1 Required Tools

The service procedures described in this manual for Series 90 pumps and motors can be performed using common mechanic's tools. Special tools, if required are shown. Pressure gauges should be calibrated frequently to ensure accuracy. Snubbers are recommended to protect pressure gauges.

4

4.2 Port Locations and Pressure Gauge Installation

The following sections list the ports for each type of hydraulic unit. The recommended pressure gauge and fitting are also specified.


Outline drawings showing port locations follow the tables.

4.2.1 Variable Pump

Port	Function	Recommended Gauge Size and Fitting
M1	System Pressure Port "A"	1000 bar or 10 000 psi Gauge 9/16—18 O-Ring Fitting
M2	System Pressure Port "B"	1000 bar or 10 000 psi Gauge 9/16—18 O-Ring Fitting
M3 (M6)	Charge Pressure	50 bar or 1000 psi Gauge 9/16—18 O-Ring Fitting
M4 M5	Servo Pressure	50 bar or 500 psi Gauge 9/16—18 O-Ring Fitting

Port	Function	Recommended Gauge Size and Fitting				
L1	Case	10 bar or	100 psi Gauge			
L2	Pressure	SAE O-Ri	ng Fitting:			
		030, 042	7/8—14			
		055, 075, 100	1-1/16—12			
		130	1-5/16—12			
		180, 250	1-5/8—12			
X1 X2	HDC / EDC Pressure	50 bar or 1000 psi Gauge 7/16 — 20 O-Ring Fitting or 9/16 — 18 O-Ring Fitting				
X3	Ext. Control Pressure		1000 psi Gauge 3 O-Ring Fitting			
S	Charge Pump Inlet	Vacuum Gauge, Tee into Inlet Line				
		SAE O-Ri	ng Fitting:			
		030, 042	1-1/16 — 12			
		055, 075	1-5/16 — 12			
		100, 130, 180	1-5/8 — 12			
		250	1-1/2 SAE Split Flange			







Top View



4



PV with Side Port End Cap and Manual Displacement Control








4.2.2 Fixed Motor

Port	Function	Recommended Gauge Size and Fitting
M1	System Pressure Port "A"	1000 bar or 10 000 psi Gauge 9/16—18 O-Ring Fitting
M2	System Pressure Port "B"	1000 bar or 10 000 psi Gauge 9/16—18 O-Ring Fitting
M3	Charge Pressure Port M3	50 bar or 1000 psi Gauge 9/16—18 O-Ring Fitting

Port	Function		Recommended Gauge Size and Fitting		
L1 L2	Case Pressure	10 bar	or 100 psi Gauge		
		SAE O	-Ring Fitting:		
		030, 042, 055	7/8—14		
		075, 100, 130	1-1/16—12		



MF with Cartridge Flange




Pressure Measurement

4.2.3 Variable Motor


Port	Function	Recommended Gauge Size and Fitting
M1	System Pressure Port "A"	1000 bar or 10 000 psi Gauge 9/16—18 O-Ring Fitting
M2	System Pressure Port "B"	1000 bar or 10 000 psi Gauge 9/16—18 O-Ring Fitting
M3	Charge Pressure	50 bar or 1000 psi Gauge 9/16—18 O-Ring Fitting

Port	Function	Recommended Gauge Size and Fitting
M3		1000 bar or 10 000 psi Gauge 7/16—20 O-Ring Fitting
M4		1000 bar or 10 000 psi Gauge 7/16—20 O-Ring Fitting
L1 L2	Case Pressure	10 bar or 100 psi Gauge 1-1/16—12 O-Ring Fitting

4



MV with Cartridge Flange and Hydraulic 2-Position Control (SAE Flange Version Similar)



MV with SAE Flange (Cartridge Flange Version Similar)

Start-Up



5. Initial Start-Up Procedure

The following start-up procedure should always be followed when starting-up a new Series 90 installation or when restarting an installation in which either the pump or motor had been removed.

WARNING

The following procedure may require the vehicle/machine to be disabled (wheels raised off the ground, work function disconnected, etc.) while performing the procedure in order to prevent injury to the technician and bystanders. Take necessary safety precautions before moving the vehicle/machine.

Prior to installing the pump and/or motor, inspect the units for damage incurred during shipping and handling. Make certain all system components (reservoir, hoses, valves, fittings, heat exchanger, etc.) are clean prior to filling with fluid.

Fill the reservoir with recommended hydraulic fluid. This fluid should be passed through a 10 micron (nominal, no bypass) filter prior to entering the reservoir. The use of contaminated fluid will cause damage to the components, which may result in unexpected vehicle/machine movement. See the publications BLN-9887 and SDF 697581 for further related information.

The inlet line leading from the reservoir to the pump must be filled prior to start-up. Check inlet line for properly tightened fittings and make sure it is free of restrictions and air leaks.

Be certain to fill the pump and/or motor housing with clean hydraulic fluid prior to start up. Fill the housing by pouring filtered oil into the upper case drain port.

Install a 50 bar (or 1000 psi) pressure gauge in the charge pressure gauge port (see Sec. 4.2 for location) to monitor the charge pressure during start-up.

It is recommended that the external control input signal (linkage for MDC, hydraulic lines for HDC, or

electrical connections for EDC) be disconnected at the pump control until after initial start-up. This will ensure that the pump remains in its neutral position.

WARNING

Do not start prime mover unless pump is in neutral position (0° swashplate angle). Take precautions to prevent machine movement in case pump is actuated during initial start up.

"Jog" or slowly rotate prime mover until charge pressure starts to rise. Start the prime mover and run at the lowest possible RPM until charge pressure has been established. Excess air may be bled from the high pressure lines through the high pressure system gauge port.

Once charge pressure has been established, increase speed to normal operating RPM. Charge pressure should be as indicated in the pump model code (see Sec. 8.1.1). If charge pressure is inadequate, shut down and determine cause for improper pressure. Refer to Troubleshooting Sec. 7.

WARNING

Inadequate charge pressure will affect the operator's ability to control the machine.

Shut down the prime mover and connect the external control input signal. Also reconnect the machine function if disconnected earlier. Start the prime mover, checking to be certain the pump remains in neutral. With the prime mover at normal operating speed, slowly check for forward and reverse machine operation.


Charge pressure may slightly decrease during forward or reverse operation. Continue to cycle slowly between forward and reverse for at least five minutes.

Shut down prime mover, remove gauges, and plug ports. Check reservoir level and add filtered fluid if needed.


The transmission is now ready for operation.

Fluid and Filter Maintenance

6. Fluid and Filter Maintenance



Suction Filtration Schematic



Charge Pressure Filtration Schematic (Partial Flow)

To ensure optimum service life of Series 90 products, regular maintenance of the fluid and filter must be performed. Contaminated fluid is the main cause of unit failure. Care should be taken to maintain fluid cleanliness while performing any service procedure.

6

Check the reservoir daily for proper fluid level, the presence of water (noted by a cloudy to milky appearance, or free water in bottom of reservoir), and rancid fluid odor (indicating excessive heat). If either of these conditions occur, change the fluid and filter immediately.

It is recommended that the fluid and filter be changed per the vehicle/machine manufacturer's recommendations or at the following intervals:

System with a sealed-type reservoir	2000 hours
System with a breathing- type reservoir	500 hours

It may be necessary to change the fluid more frequently than the above intervals if the fluid becomes contaminated with foreign matter (dirt, water, grease, etc.) or if the fluid has been subjected to temperature levels greater than the recommended maximum. Never reuse fluid.

The filter should be changed whenever the fluid is changed or whenever the filter indicator shows that it is necessary to change the filter.

Filters can be in either pressure filtration or suction filtration configurations. For suction filtration, filters should have a Beta-ratio of β_{10} >2. For charge pressure filtration, filters should have a Beta-ratio of β_{10} >10. See Sauer-Sundstrand publication BLN-9887 or 697581 and ATI-E 9201 for more information on filtration.



Troubleshooting

7. Troubleshooting

This section provides general steps to follow if certain undesirable system conditions are observed. Follow the steps in a section until the problem is solved. Some of the items will be system specific. For areas covered in this manual, a section is referenced. Always observe the safety precautions listed in Sec. 1.2 and related to your specific equipment.

7.1 "Neutral" Difficult or Impossible to Find

Item	Description	Action
 Check input to pump control. 	Input to control module is operating improperly.	Check control input and repair or replace as necessary.
2. Check pump displace- ment control.	Control linkages are not secure, con- trol orifices are blocked, etc.	Adjust, repair, or replace control module as necessary (8.2 and 9.3).
3. Repair or replace pump.		Consult a Sauer-Sundstrand Authorized Service Center.

7.2 System Operating Hot

Item	Description	Action
1. Check oil level in reservoir.	Insufficient hydraulic fluid will not meet cooling demands of system.	Fill reservoir to proper level.
2. Inspect heat ex- changer.	Heat exchanger not sufficiently cool- ing the system.	Check air flow and input air temperature for heat exchanger. Clean, repair or replace heat exchanger.
3. Check charge pres- sure.	Low charge pressure will overwork system.	Measure charge pressure (4.2). Inspect and adjust or replace charge relief valve (8.1.1 and 9.2.3). Or repair leaky charge pump (9.2.4).
 Check charge pump inlet vacuum. 	High inlet vacuum will overwork sys- tem. A dirty filter will increase the inlet vacuum. Inadequate line size will restrict flow.	Check charge inlet vacuum (4.2). If high, inspect inlet filter and replace as neces- sary. Check for adequate line size, length or other restrictions.
 Check system relief pressure settings. 	If the system relief settings are too low, the relief valves will be over- worked.	Verify settings of pressure limiters and high pressure relief valves and adjust or replace multi-function valves as necessary (8.1.2, 9.2.1)
 Check for internal leak- age in motor. 	Leakage will reduce low side system pressure and overwork the system.	Monitor motor case flow without loop flush- ing in the circuit (use defeat spool 9.4.1.3). If flow is excessive, replace motor.
7. Check system pres- sure.	High system pressure will overheat system.	Measure system pressure (4.2). If pres- sure is high reduce loads.
8. Replace transmission.		Replace pump and motor.

27



Troubleshooting

7

7.3 Transmission Operates Normally in One Direction Only

Item	Description	Action
1. Check input to pump control.	Input to control module is operating improperly.	Check control input and repair or replace as necessary.
2. Check pump displace- ment control.	Control linkages are not secure, con- trol orifices are blocked, etc.	Repair or replace control module as neces- sary (8.2 and 9.3).
 Interchange system pressure limiters, high pressure relief valves, and system check valves. 	Interchanging the multi-function valves will show if the problem is related to the valve functions con- tained in the multi-function valves.	Interchange multi-function valves. If the problem changes direction, repair or replace the valve on the side that does not operate (8.1.2 and 9.2.1).
 Check charge pres- sure. 	If charge pressure decays in one direction the loop flushing valve may be "sticking" in one direction.	Measure charge pressure in forward and reverse (4.2). If pressure decays in one direction, inspect and repair the motor loop flushing valve (9.4.1.1).

7.4 System Will Not Operate in Either Direction

	Item	Description	Action
1.	Check oil level in reservoir.	Insufficient hydraulic fluid to supply system loop.	Fill reservoir to proper level.
2.	Check input to pump control.	Input to control module is operating improperly.	Check control input and repair or replace as necessary.
3.	Check pump displace- ment control.	Control linkages are not secure, con- trol orifices are blocked, etc.	Repair or replace control module as neces- sary (8.2 and 9.3).
4.	Ensure bypass valve(s) are closed.	If bypass valve(s) is open, the sys- tem loop will be depressurized.	Close bypass valves (8.1.3). Replace multi- function valve if defective (9.2.1).
5.	Check charge pressure with pump in neutral.	Low charge pressure insufficient to recharge system loop.	Measure charge pressure with the pump in neutral (4.2). If pressure is low, go to step 6; otherwise continue with step 5.
6.	Check charge pressure with pump in stroke.	Low charge pressure with the pump in stroke indicates a motor charge relief valve or system pressure relief valve may be improperly set.	Measure charge pressure with pump in stroke (4.2). If pressure is low, adjust or replace motor charge relief valve (8.3.1 and 9.4.1.2), otherwise go to step 9.
7.	Inspect pump charge relief valve.	A pump charge relief valve that is leaky or set too low will depressurize the system.	Adjust or replace pump charge relief valve as necessary (8.1.1, 9.2.3)
8.	Check charge pump inlet filter.	A clogged filter will undersupply sys- tem loop.	Inspect filter and replace if necessary.
	(continued)		

-

-

Series 90	Troubleshooting	g 7
9. Check charge pump.	A malfunctioning charge pump will provide insufficient charge flow.	Repair or replace the charge pump (9.2.4). If OK go to last step.
10. Check pump displace- ment control.	Control linkages are not secure, con- trol orifices are blocked, etc.	Repair or replace control module as neces- sary (8.2 and 9.3).
11. Check system pres- sure.	Low system pressure will not pro- vide power necessary to move load.	Measure system pressure (4.2). Continue with next step.
12. Check system multi- function valves.	Defective multi-function valves will cause system pressure to be low.	Repair or replace multi-function valve(s) (9.2.1).
13. Replace transmission.		Replace pump and motor.
	 9. Check charge pump. 10. Check pump displacement control. 11. Check system pressure. 12. Check system multifunction valves. 	 9. Check charge pump. A malfunctioning charge pump will provide insufficient charge flow. 10. Check pump displacement control. 11. Check system pressure. 12. Check system multifunction valves. Check system multifunction valves. Defective multifunction valves will cause system pressure to be low.

7.5 Low Motor Output Torque

Item	Description	Action
 Check system pressure at motor. 	Low system pressure at the motor will reduce torque.	Measure system pressure at motor (4.2). If pressure limiter setting is low, increase setting.
 Variable motor stuck at minimum displace- ment. 	Minimum motor displacement yields low output torque.	Check control supply pressure (4.2.3) or repair displacement control (9.5). Check motor control orifices (9.5.4).
3. Check for internal leak- age.	Internal leakage will reduce system pressure.	Check for leakage in O-rings, gaskets, and other fittings (9.1.1 and others). Repair unit as required, or replace leaky unit.
4. Replace transmission.		Replace pump and motor.

7.6 Improper Motor Output Speed

Item	Description	Action
1. Check oil level in reservoir.	Insufficient hydraulic fluid will reduce motor speed.	Fill oil to proper level.
2. Check charge pres- sure.	Incorrect charge pressure can result in a low speed motor.	Measure charge pressure (8.1.1), adjust charge system as necessary (9.2.3 and 9.2.4).
 Check pump output flow. 	Incorrect outflow will affect output speed. Incorrect output flow indicates the swashplate is out of position.	Measure pump output flow by teeing into outflow hose. Check for proper pump speed and see that the pump is in full stroke.
 Check variable motor displacement control. 	If variable motor displacement con- trol is not functioning correctly, vari- able motor swashplate may be in wrong position.	See if variable motor displacement control is responding. If not, repair or replace control (9.5).



Troubleshooting

7.7 Excessive Noise and/or Vibration

Item	Description	Action
1. Check oil in reservoir.	Insufficient hydraulic fluid will lead to cavitation.	Fill reservoir to proper level.
2. Air in system.	Air bubbles will lead to cavitation.	Look for foam in reservoir. Check for leaks on inlet side of system loop. Afterwards, let reservoir settle until bubbles are gone. Run system at low speed to move system fluid to reservoir. Repeat.
 Check pump inlet vacuum. 	High inlet vacuum will create noise. A dirty filter will increase the inlet vacuum.	Inspect and replace filter as necessary. Check for proper suction line size.
4. Inspect shaft couplings.	A loose shaft coupling will cause excessive noise.	Replace loose shaft coupling in charge pump (Sec. 9.2.4) or replace pump or motor.
5. Inspect shaft align- ment.	Unaligned shafts will create exces- sive frictional noise.	Align shafts.

7.8 System Response is Sluggish

	Item	Description	Action
1.	Check oil level in reservoir.	Insufficient hydraulic fluid will reduce output pressure.	Fill reservoir to proper level.
2.	Check multi-function valves' pressure set- tings.	Incorrect pressure settings will affect system reaction time.	Adjust or replace multi-function valves (8.1.2 and 9.2.1).
3.	Check pump inlet vacuum.	High pump inlet vacuum will reduce system pressure.	Measure charge inlet vacuum (4.2). If high replace inlet filter.
4.	Check prime mover speed.	Low engine speed will reduce sys- tem performance.	Adjust engine speed.
5.	Check charge and con- trol pressures.	Incorrect charge or control pressures will affect system performance.	Measure charge and control pressures and correct if necessary (4.2 and others).
6.	Check system internal leakage.	Internal leakage will reduce system pressure.	Check for leakage in O-rings, gaskets, and other fittings (9.1.1 and others).
7.	Replace transmission.		Replace pump and motor.



Inspections and Adjustments

8. Inspections and Adjustments

This section offers instruction on how to perform inspections and adjustments on pump and motor components. Read through the entire related section before beginning a service activity. Refer to Sec. 4 for location of gauge ports and suggested gauge size.

8.1 Pump Adjustments

8.1.1 Charge Relief Valve Adjustment


The following procedure explains how to check and adjust the charge relief valve. (For description see Sec. 2.4.2.)

WARNING


The following procedure may require the vehicle/machine to be disabled (wheels raised off the ground, work function disconnected, etc.) in order to prevent injury to the technician and bystanders.

- To measure pump charge pressure, install a pressure gauge in the pump charge pressure gauge port (M3). Also install a gauge to measure case pressure (tee into L1 or L2 or use servo gauge port). Operate the system with the pump in "neutral" (zero displacement) when measuring pump charge pressure.
- 2. The table on the following page shows the acceptable pump charge pressure range for some nominal charge relief valve settings (see sample model code at right). These pressures assume 1775 pump rpm and a reservoir temperature of 49°C (120°F), and are referenced to case pressure (see footnote on next page). Smaller displacement charge pumps will produce charge pressure readings in the lower portion of the range, while larger displacement charge pumps will produce readings in the higher portion of the range.

(continued)



Charge Pressure Gauge Port (Reducer fitting shown - if filtration device attached, see Sec. 4.2.1 for alternate location of this port)



Model Code on Unit Name Plate ("24 bar")

Inspections and Adjustments

Model Code Setting	Measured Charge Pressure* (stated range ±1.7 bar [±25 psi])
20 bar	20.1 to 21.2 bar [291 to 308 psi]
24 bar	24.0 to 25.2 bar [348 to 365 psi]
28 bar	27.8 to 29.0 bar [403 to 420 psi]

NOTE: These pressures assume a pump speed of 1775 rpm. At higher pump input speeds (with higher charge flows) the charge pressure will rise over the rated setting.

3. Earlier production Series 90 pumps are equipped with a shim adjustable charge relief valve. Shim kits are available from Sauer-Sundstrand. Adjustment of charge pressure is accomplished by removing the plug [1 inch Hex] and changing the shim thickness behind the spring. The plug for this type of charge relief valve should be torqued to 68 Nm (50 lbf•ft).

Later production Series 90 pumps are equipped with an external screw adjustable charge relief valve. Adjustment of the charge pressure is accomplished by loosening the lock nut (with a 1-1/ 16 inch hex wrench for 030 through 100 units, or a 1-5/8 inch hex wrench for 130 through 250 units), and turning the adjustment plug with a large screwdriver or a 1/2 inch hex wrench. Clockwise rotation of the plug increases the setting, and counterclockwise rotation decreases the setting (at a rate of approximately 3.4 bar (50 psi) per turn). The lock nut for this type of charge relief valve should be torqued to 52 Nm (38 lbf•ft).

4. Once the desired charge pressure setting is achieved, remove the gauges.



Shim Adjustable Charge Pressure Relief Valve (Pump)



90000264 Screw Adjustable Charge Pressure Relief Valve (Pump)



Inspections and Adjustments

8.1.2 Multi-Function Valve Pressure Adjustment

Adjustment of the pressure limiter setting and the high pressure relief valve setting is accomplished simultaneously. The latter is automatically set approximately 35 bar (500 psi) above the former. For description of multi-function valve see Sec. 2.4.4.

In order to adjust the pressure limiter setting, the motor output shaft must be locked so it does not rotate. This may be accomplished by locking the vehicle's brakes or rigidly fixing the work function so it cannot rotate.

WARNING


Take necessary precautions that the motor shaft remains stationary during the adjustment procedure.

- Install two 1000 bar (or 10,000 psi) pressure gauges in the high pressure gauge ports (M1 and M2). Install a 50 bar (or 1000 psi) pressure gauge in the pump charge pressure gauge port (M3).
- 2. Start the prime mover and operate at normal speed.
- Loosen locking nut (smallest hex on multi-function valve) with a 10 mm wrench for earlier 042 through 100 frame size units, a 19 mm wrench for 030 and later 042 through 100 frame size units, or a 13 mm wrench for earlier 130 frame size units.
- Insert a 3 mm (early 042 through 100 units), 5 mm 030 and (late 042 through 100 units), or 4 mm (earlier 130 units) internal hex wrench into the pressure adjusting screw.

NOTE: A plastic dust plug is installed in the adjusting screw on 030 and late 042 through 250 units.


5. The factory preset pressure limiter setting is shown on the model code as at right. It is referenced to charge pressure, so the pressure limiter setting is the difference between the high and low pressure sides of the system loop. Activate or move the control input so that pressure increases in the high pressure side of the closed circuit to the pressure limiter pressure setting. The pressure limiter setting is reached when the pressure stops increasing and remains steady at a given pressure level (as shown on the gauges).

(continued)




Multi-Function Valves on PV

90000258




Loosen Pressure Adjusting Screw Lock Nut






Inspections and Adjustments



Rotate Pressure Adjusting Screw



Tighten Lock Nut

6. Return the pump to its "neutral" (zero flow) position and adjust the pressure limiter setting by rotating the pressure adjusting screw with the internal hex wrench.

Clockwise rotation of the pressure adjustment screw will increase the pressure setting, and counterclockwise rotation will decrease the pressure setting. Each complete rotation of the pressure adjusting screw changes the pressure setting by approximately 83 bar (1200 psi) on earlier 042 through 100 units, or by approximately 93 bar (1350 psi) on 030 and later 042 through 100 units.

- 7. To verify the actual pressure setting, actuate or move the control input so that the pump again develops pressure in the high pressure circuit to the newly adjusted pressure limiter pressure setting, and read the high pressure gauge. Then allow the pump to return to its "neutral" position. The pressure in the high pressure circuit should return to the charge pressure setting.
- 8. While holding the pressure adjusting screw stationary, tighten the pressure adjusting screw lock nut to 3 Nm (26 in•lbf) on early production units, or 16 Nm (12 ft•lbf) on late production units. **Do not over-torque.**
- 9. Shut down the prime mover, remove the gauges and install the gauge port plugs. Replace the plastic dust plugs (if used).

The same procedure is used for setting the pressure limit of the other multi-function valve, but the control input signal must be activated or moved in the opposite direction so that high pressure develops in the opposite side of the closed circuit.



Inspections and Adjustments

8.1.3 Engaging the Bypass Function

The bypass function (see Sec. 2.4.6 for description) is performed by the multi-function valve cartridges. The prime mover should be shut down when opening or closing the bypass valves.


The bypass valves on both of the multi-function valves must be opened to engaged the bypass function.

- Using a 1-1/16 inch (030 through 100) or 1-3/8 inch (130 through 250) wrench on the middle sized hex of the multi-function valve cartridge, and a 1-1/4 inch (030 through 100) or 1-5/8 inch (130 through 250) wrench on the large hex to prevent rotation of the cartridge assembly, rotate the middle hex three revolutions counterclockwise to open the bypass valve. Do not rotate more than 3-1/2 revolutions, as additional rotation will permit external leakage.
- For units with an MDC-type control, prior to moving the vehicle or otherwise causing the motor shaft to turn, move the control handle of the manual displacement control on the pump to the maximum full forward position. Hold the handle in this position during bypass valve operation.


WARNING

"Tow" at extremely low speeds and for short distances only.

 To close the bypass valve, rotate the middle hex clockwise until it is seated. Then torque the middle hex to 41 Nm (30 lbf•ft).




Loosening and Rotating Bypass Hex on Multi-Function Valve



Multi-Function Valve with Bypass Function Engaged



Inspections and Adjustments



90000828

Pressure Over-Ride Valve for 180 Frame Size

8.1.4 Pressure Override (POR) Valve Pressure Adjustment (Option for 180 Frame Size)

The Pressure Override Valve is explained in Sec. 2.4.10.

- Install two 1000 bar (or 10,000 psi) pressure gauges in the high pressure gauge ports (M1 and M2). Install a 50 bar (or 1000 psi) pressure gauge in the pump charge pressure gauge port (M3).
- 2. Start the prime mover and operate at normal speed.
- 3. With the pump operating at approximately 20% displacement, load the work function and note the pressure as the POR valve operates (pump displacement reduces to "zero").
- 4. Adjustment of the pressure override setting is made by loosening the lock nut with a 9/16 inch hex wrench and turning the adjustment screw with a 3/16 inch internal hex wrench. The POR setting should be at least 50 bar (750 psi) below the high pressure relief valve setting of the multi-function valves for proper operation.
- Following the adjustment, torque the lock nut to 43 Nm (32 lbf•ft).
- 6. Shut down the prime mover and remove the gauges and install the gauge port plugs.



Inspections and Adjustments

8.1.5 Displacement Limiter Adjustment

The maximum displacement can be limited in either direction (see Sec. 2.4.7).

1. Loosen the seal lock nut retaining the displacement limiter adjusting screw.

Frame Size	Wrench Size
042 - 100	13 mm
130	17 mm
180 - 250	19 mm

2. Rotate the adjusting screw.

Frame Size	Internal Hex Wrench Size
042 - 100	4 mm
130	5 mm
180 - 250	6 mm

Rotating the adjusting screw clockwise will decrease the maximum displacement of the pump while rotating the adjusting screw counterclockwise will increase the maximum displacement.

WARNINGS

Care should be taken in adjusting displacement limiters to avoid undesirable flow or speed conditions. See Sec. 3 for speed and pressure limits.


The seal lock nut must be retorqued after every adjustment to prevent an unexpected change in operating conditions and to prevent external leakage during unit operation.

 After establishing the desired maximum displacement setting, tighten the lock nut on the adjusting screw as follows.


Frame Size	Torque
042 - 100	24 Nm [18 lbf•ft]
130	48 Nm [35 lbf•ft]
180 - 250	125 Nm [92 lbf•ft]

4. One turn of the adjusting screw will change the maximum displacement approximately as follows.


-	
Frame Size	Approx Change in Disp per Rev of Adjusting Screw
030	2.8 cm ³ /rev (0.17 in ³ /rev)
042	3.4 cm ³ /rev (0.21 in ³ /rev)
055	4.0 cm ³ /rev (0.25 in ³ /rev)
075	5.0 cm ³ /rev (0.31 in ³ /rev)
100	6.0 cm ³ /rev (0.37 in ³ /rev)
130	9.0 cm ³ /rev (0.55 in ³ /rev)
180	12.5 cm ³ /rev (0.76 in ³ /rev)
250	17.3 cm ³ /rev (1.06 in ³ /rev)



Loosen Displacement Limiter Lock Nut



Rotate Adjusting Screw




Tighten Lock Nut



Inspections and Adjustments

8.2 Pump Control Adjustments



9000023 Variable Displacement Pump with Standard Manual Displacement Control

8.2.1 Standard Manual Displacement Control (MDC) Adjustment

8

There are no adjustable elements in the manual displacement control. The control spool is held in its "neutral" position by centering springs and washers on each end of the spool. Since there is no centering spring on the control input shaft, the shaft will automatically assume the appropriate position when the control is installed on the pump.

For a functional description see Sec. 2.5.1.



Inspections and Adjustments

8.2.2 Non-Linear Manual Displacement Control (MDC)

A centering spring, located on the control input shaft, locates the control shaft in its "neutral" position. A bias spring on the control spool maintains a force on the spool and the control linkage to eliminate looseness ("free-play") in the linkage.


The "neutral" adjustment is the only adjustment that can be made on the nonlinear manual displacement control. All other functions are preset at the factory.

This adjustment must be made on a test stand or on the vehicle/machine with the prime mover operating.

WARNING

The following procedure requires the vehicle/ machine to be disabled (wheels raised off the ground, work function disconnected, etc.) in order to prevent injury to the technician and bystanders.

- 1. Install two 50 bar (or 1000 psi) gauges in each of the displacement control cylinder gauge ports (M4 and M5). Disconnect the external control linkage from the control handle and make certain the control shaft is in its "neutral" position. Start the prime mover and operate at normal speed.
- 2. Loosen the lock nut on the neutral adjusting screw with a 13 mm hex wrench.
- 3. Using a 4 mm internal hex wrench, rotate the neutral adjusting screw clockwise until the pressure increases on one of the pressure gauges. Note the angular position of the wrench.
- 4. Rotate the adjusting screw counterclockwise until the pressure increases by an equal amount on the other gauge. Note the angular position of the wrench.
- 5. Rotate the adjusting screw clockwise half the distance between the locations noted above. The gauges should read the same pressure (case pressure), indicating that the control is in its "neutral" position.
- 6. Hold the adjusting screw stationary and tighten the lock nut to 13.6 Nm (10 in•lbf). Do not overtorque the nut.
- 7. Once the neutral position is set, stop the prime mover, remove the gauges, and install the gauge port plugs. Reconnect the external control linkage.



Variable Displacement Pump with Non-Linear **Manual Displacement Control**






Screw

Rotate Neutral Adjusting Tighten Neutral Adjusting Screw Lock Nut



Inspections and Adjustments



The neutral start switch (NSS) provides a means to prevent the system prime mover from starting while the pump control handle and control input shaft are in a position which would command the pump to go "instroke" in either the "forward" or "reverse" direction.

When the control input shaft is in its "neutral" position, the inner end of the switch pin moves into a slot on the eccentric cam attached to the control shaft. This allows the spring loaded NSS to close, completing the electrical starting circuit for the prime mover.

When the control input shaft is NOT in its "neutral" position, the eccentric cam moves the switch pin out of the slot. This forces the NSS to open, breaking the electrical starting circuit for the prime mover.

(continued)



Inspections and Adjustments

The NSS must be adjusted to meet the following three requirements:


i. The distance the control handle can be turned without opening the NSS is called the "NSS deadband." The distance the control handle can be moved without moving the control spool enough to port hydraulic fluid to the pump displacement control cylinders is called the "control deadband." These deadbands **must** be centered in relation to each other.

Since the position of the control deadband cannot be adjusted, the position of the NSS deadband must be adjusted to match it. The switch pin is located in an eccentric plug which is turned to move the center of the NSS deadband.

- ii. The NSS deadband must be wide enough so the NSS will not open within the loose area of control handle movement caused by normal operating clearances in the control linkage (control shaft "free-play"). By setting the NSS to open outside this area, the control spool springs or control shaft centering spring can always act to return the handle to "neutral" and re-close the NSS.
- iii. The NSS deadband must be narrow enough so the NSS will open before the unit builds 7 bar (100 psi) differential system pressure in either direction.

The neutral start switch is threaded into the special lock nut for the eccentric plug. Turning the NSS clockwise (CW) into the special nut will move the NSS closer to the switch cam on the control shaft, and will narrow the NSS deadband. Turning the NSS counterclockwise (CCW) out of the special nut will move the NSS farther from the switch cam on the control shaft, and will widen the NSS deadband.


(continued)




Neutral Start Switch Adjustment Requirements




Inspections and Adjustments



Loosening the NSS Lock Nut



NSS Details



Checking Continuity of NSS

NSS Deadband Adjustment (Conditions ii & iii)

The NSS deadband must be wide enough so the NSS **will not** open within the control shaft "free-play" area, and it must be narrow enough so the NSS **will** open before the unit builds 7 bar (100 psi) differential system pressure in either direction.

- 1. Using two 1-1/8 inch wrenches, hold the neutral start switch from turning and loosen the locknut.
- 2. Disconnect the external control linkage and make certain the control shaft is in its "neutral" position.
- Attach a continuity checker to the terminals of the switch. With the control shaft in its "neutral" position, turn the switch clockwise (CW) until electrical continuity is broken, then turn the switch counterclockwise (CCW) until electrical continuity is obtained. Turn the switch counterclockwise (CCW) an additional 1/4 turn (90°) after continuity has been obtained.
- 4. Hold the switch in place and tighten the locknut to 27 Nm (20 ft•lbf) torque.
- 5. With the continuity checker attached to the switch, rotate the control handle (or the control shaft) in each direction to assure continuity is broken when the control is not in the "neutral" position.
- 6. If continuity is obtained in "neutral" and satisfactorily interrupted in each direction, proceed to check the switch with the prime mover running. The switch must open **before** the unit builds 7 bar (100 psi) differential system pressure in either direction.

If the switch opens **after** the unit builds system pressure in either direction, loosen the switch lock nut and turn the switch clockwise (CW) 1/12 turn (30°). Tighten the switch lock nut and recheck the switch operation. Repeat this procedure if necessary.

- 7. If neutral start switch operation is satisfactory, reconnect the external control linkage.
- 8. If continuity is not interrupted with an **equal** movement of the control handle in each direction, continue with the next section.



Inspections and Adjustments

Neutral Start Switch Eccentric Plug Adjustment (Condition i)

The NSS deadband and the control deadband **must** be centered in relation to each other.

Since the position of the control deadband cannot be adjusted, the position of the NSS deadband must be adjusted to match it. The switch pin is located in an eccentric plug which is turned to move the center of the NSS deadband.


The MDC should be installed on the pump and be in its "neutral" position when adjusting the neutral start switch eccentric plug.


The accompanying drawing provides dimensions for an Eccentric Plug Adjustment Tool.

1. Hold the switch and eccentric plug from turning and use two 1-1/8 inch wrenches to loosen the locknut. Remove the neutral start switch.

CAUTION

Do not start the prime mover while the neutral start switch is removed from the control. Case pressure will force the pin out of the eccentric plug, causing oil loss.





Eccentric Plug Adjustment Tool

2. Note the slots on the eccentric plug for the adjustment tool. Hold the eccentric plug in place with the adjustment tool, and loosen the lock nut with a 1-1/8 inch wrench.

(continued)




Loosen Eccentric Lock Nut







Inspections and Adjustments



Eccentric Plug Adjustment



Adjust Eccentric Plug



3. Position the eccentric plug so the switch pin is offset toward the control mounting surface. This will provide the best contact between the pin and the cam on the control shaft.

- 4. Hold the control shaft in its "neutral" position (in the center of the control shaft "free-play" area). Locate the switch pin in the slot of the switch cam by turning the eccentric plug while checking the pin position (depth) in the plug. When the pin engages the cam slot, the pin will be at its maximum depth in the plug. Hand tighten the plug lock nut to hold the eccentric plug in position.
- 5. Turn the control shaft an equal amount in either direction from "neutral." The switch pin should move out of the eccentric plug an equal distance when the control shaft is turned. Turn the eccentric plug to center the switch pin with the cam slot. Only a small amount of adjustment in either direction should be needed to center the pin.
- While holding the eccentric plug in place, tighten the eccentric plug lock nut to 27 Nm (20 ft•lbf). Reinstall and adjust the switch as outlined in the previous section.

NOTE: The eccentric plug normally requires between 5-1/2 and 6-1/2 turns to install into the control housing .

CAUTION

Do not turn the eccentric plug into or out of the housing beyond specifications.

 Once the switch is correctly adjusted, hold the switch in place and tighten the locknut to 27 Nm (20 ft•lbf) torque.

(continued)



Inspections and Adjustments

Checking Switch Continuity

Recheck switch continuity to determine whether additional adjustment of the eccentric plug is necessary.

WARNING

The following procedure requires the vehicle/ machine to be disabled (wheels raised off the ground, work function disconnected, etc.) in the event the pump should go into stroke during this adjustment.


- Install two 50 bar (or 1000 psi) gauges in each of the displacement control cylinder gauge ports (M4 and M5). Attach a continuity checker to the terminals of the neutral start switch.
- 2. Energize the starter circuit, and start the prime mover.
- 3. While operating at normal speed and with the pump in its "neutral" (zero flow) position, note the pressure reading on the gauges. This reading should be noted as the base pressure.
- 4. Slowly move the control handle in one direction while observing the pressure gauges and the continuity checker. Continuity **must** be broken before the pressure on either gauge increases more than 0.9 bar (12 psi) from the base pressure obtained at "neutral."
- Slowly move the control handle in the opposite direction. Again, continuity must be broken before the gauge pressure increases more than 0.9 bar (12 psi) from base pressure.
- 6. Continuity must again be verified when the control is returned to neutral.
- 7. If continuity is not broken at base pressure plus 0 to 0.9 bar (0 to 12 psi) in either direction, stop the prime mover and readjust the eccentric plug as described in the previous section. If the pressure difference is equal in each direction but greater than 0.9 bar (12 psi), loosen the switch locknut and turn the switch clockwise 1/12 turn (30°) to increase the sensitivity. Retighten the locknut and recheck pressure differences and continuity.
- 8. After verifying proper control and switch operation, stop the prime mover. Remove the continuity checker and pressure gauges. Reinstall the servo pressure port plugs and reconnect the electrical leads from the machine starter circuit to the neutral start switch. Install and adjust, if necessary, the external control linkage.




Checking Continuity of NSS (Gauges Installed in Servo Gauge Ports)



Inspections and Adjustments



PV with Hydraulic Displacement Control



PV with Electric Displacement Control

8.2.4 Hydraulic Displacement Control (HDC) and Electric Displacement Control (EDC) Adjustment

8

The "neutral" adjustment is the only adjustment that can be made on hydraulic and electric displacement controls. All other functions are preset at the factory. For functional descriptions see Sec. 2.5.2 and 2.5.3.

This adjustment must be made on a test stand or on the vehicle/machine with the prime mover operating.


The neutral adjustment is performed by adjusting a neutral adjusting shaft (earlier production EDCs) or a neutral adjusting screw (HDCs and current production EDCs).

WARNING

The following procedure requires the vehicle/ machine to be disabled (wheels raised off the ground, work function disconnected, etc.) in order to prevent injury to the technician and bystanders.

- 1. Install two 50 bar (or 1000 psi) gauges in each of the two displacement control cylinder gauge ports (M4 and M5). Disconnect the external control input (hydraulic or electronic) from the control. Start the prime mover and operate at normal speed.
- Loosen the lock nut with a 17 mm hex wrench for the neutral adjusting shaft or with a 10 mm or 13 mm hex wrench for the neutral adjusting screw.

(continued)



Install Gauges in Displacement Control Cylinder **Gauge Ports**



Inspections and Adjustments

- 3. Using a 5 mm internal hex wrench for the neutral adjusting shaft or a 3 mm or 4 mm internal hex wrench for the neutral adjusting screw, rotate clockwise until the pressure increases in one of the pressure gauges. Note the angular position of the wrench. Then rotate the neutral adjusting shaft or screw counterclockwise until the pressure increases by an equal amount on the other gauge. Again note the angular position of the wrench.
- 4. Rotate the neutral shaft or adjusting screw clockwise half the distance between the locations noted above. The gauges should read the same pressure (case pressure), indicating that the control is in its "neutral" position.
- Hold the neutral adjusting shaft or screw stationary. Tighten the neutral shaft lock nut (early production controls) to 22 Nm (195 in•lbf). Tighten the neutral adjusting screw lock nut (later production controls) to 7 Nm (62 in•lbf) for the 6 mm screw or 13.6 Nm (120 in•lbf) for the 8 mm screw. Do not overtorque the nut.
- Once the neutral position is set, stop the prime mover, remove the gauges, and install the gauge port plugs. Reconnect the external control input.




Rotate Neutral Adjusting Shaft (Early Production)



Tighten Neutral Adjusting Shaft Lock Nut (Early Production)



Rotate Neutral Adjusting Screw (Later Production)



Tighten Neutral Adjusting Screw Lock Nut (Later Production)



Rotate Neutral Adjusting Screw (Current Production HDC)




Tighten Neutral Adjusting Screw Lock Nut (Current Production HDC)



Inspections and Adjustments

8.3 Motor Adjustments



Charge Pressure Gauge Port (MF)

90M055	5 N	C () N	•
8 N	0 0	C6 W	00	Pressure Setting
NNN	00	00	24	

e.g. "24" = 24 bar



Shim Adjustable Charge Pressure Relief Valve (Motor)



Screw Adjustable Charge Pressure Relief Valve (Motor)

8.3.1 Charge Relief Valve Adjustment

Motor charge relief is explained in Sec. 2.6.1.

- To measure motor charge pressure, install a 50 bar (or 1000 psi) pressure gauge in the motor charge pressure gauge port (M3). Also install a gauge to measure case pressure. Operate the system with the pump in stroke (forward or reverse) when measuring motor charge pressure.
- The following table shows acceptable motor charge pressures for some nominal charge relief valve settings (see model code at right). These pressures assume a reservoir temperature of 49°C (120°F). They are referenced to case pressure and assume a one pump/one motor system.

Model Code Setting	Motor Charge Pressure (Acceptable Range) (±1.4 bar [±20 psi])
10 bar	8.1 bar (117 psi)
18 bar	16.1 bar (233 psi)
20 bar	18.1 bar (262 psi)
24 bar	22.1 bar (320 psi)
28 bar	26.1 bar (378 psi)
30 bar	30.0 bar (435 psi)

3. Earlier production Series 90 motors are equipped with a shim adjustable charge relief valve. Shim kits are available as service items. Adjustment of the charge pressure is accomplished by removing the plug (7/8 inch hex) and changing the shim thickness behind the spring. The plug for this type charge relief port should be torqued to 68 Nm (50 ft•lbf).

Later production Series 90 motors are equipped with an external screw adjustable charge relief valve. Adjustment of charge pressure is accomplished by loosening the lock nut (with a 1-1/16 inch hex wrench for 030 through 100 units, or a 1-5/8 inch hex wrench for 130 through 250 units), and turning the adjustment plug with a large screwdriver or a 1/2 inch hex wrench. Clockwise rotation of the plug increases the setting, and counterclockwise rotation decreases the setting (at a rate of approximately 3.4 bar [50 psi] per turn). The lock nut for this type charge relief valve should be torqued to 52 Nm (38 ft•lbf).

4. Once the desired charge pressure setting is achieved, remove the gauges.



Inspections and Adjustments

8.3.2 Displacement Limiter Adjustment (MV)

Both the maximum and minimum displacement may be limited. For description see Sec. 2.6.2.

- 1. Remove the tamper resistant cap from the displacement limiter screw. Loosen the seal lock nut retaining the displacement limiter adjusting screw with a 19 mm wrench.
- Rotate the adjusting screw with a 6 mm internal hex wrench. Rotating the maximum displacement adjusting screw clockwise will decrease the maximum displacement of the motor. Rotating the minimum displacement adjusting screw clockwise will increase the minimum displacement of the motor.

WARNINGS

Care should be taken in adjusting displacement limiters to avoid undesirable flow or speed conditions. See Sec. 3 for speed and pressure limits.

The seal lock nut must be retorqued after every adjustment to prevent an unexpected change in operating conditions and to prevent external leakage during unit operation.

- After establishing the desired displacement setting, tighten the lock nut on the adjusting screw to 54 Nm (40 ft•lbf). Install a new tamper resistant cap.
- 4. One turn of the adjusting screw will change the maximum or minimum displacement according to the following chart.


Frame Size	Approx Change in Disp per Rev of Adjusting Screw
055	5.6 cm ³ / Rev (0.34 in ³ / Rev)
075	7.1 cm ³ / Rev (0.43 in ³ / Rev)

CAUTION

The displacement limiters act as travel stops for the swashplate. Do not turn the limiter screws counterclockwise beyond the point of contact with the swashplate for either the maximum or minimum displacement position.

8.3.3 Displacement Control Adjustments

All variable motor displacement control settings do not require adjusting.



SAE Flange Version shown (Cartridge Version similar)

90000837


MV Displacement Limiters





Rotate Adjusting Screw for Minimum Displacement Limiter

Tighten Lock Nut for Minimum Displacement Limiter




Maximum Displacement Limiter



Inspections and Adjustments

8

8.4 Speed Sensor Adjustment



Positioning Speed Sensor Relative to Pump or Motor Shaft When installing or adjusting the speed sensor on a pump or motor, it must be set at a specific distance from the speed ring on the unit's cylinder. To locate the position of the speed sensor on the unit, see Sec. 4. For a description see Sec. 2.3.2.

- 1. Loosen the sensor lock nut with an 11/16 inch hex wrench.
- 2. Turn the sensor clockwise (CW) by hand until it contacts the speed ring.

- 3. Turn the sensor counterclockwise (CCW) 1/2 turn (180°) to establish the nominal gap of 0.71 mm (0.028 in).
- Then turn the sensor clockwise (CW) until the wrench flats on sensor body are positioned at a 22° angle to the pump shaft center line.

NOTE: Many adjustable wrenches have a 22° handle offset.

- 5. The final sensor position should be between 1/2 (180°) and 1/4 turn (90°) counterclockwise (CCW) from the point where the sensor contacts the speed ring.
- Hold sensor in position with a 1/2 inch hex wrench while tightening the lock nut to 13 Nm (10 ft•lbf).



Minor Repair Instructions

9

9. Minor Repair Instructions

Minor repairs may be performed, following the procedures in this section, without voiding the unit warranty. Although specific models are shown, these procedures apply to all series and types of units in the Series 90 Family.

Cleanliness is a primary means of ensuring satisfactory transmission life, on either new or repaired units. Cleaning parts by using a solvent wash and air drying is adequate, providing clean solvent is used. As with any precision equipment, the internal mechanism and related items must be kept free of foreign materials and chemicals.

Protect all exposed sealing surfaces and open cavities from damage and foreign material.


It is recommended that all gaskets and O-rings be replaced when servicing. All gasket sealing surfaces must be cleaned prior to installing new gaskets. Lightly lubricate all O-rings with clean petroleum jelly prior to assembly.





Minor Repair Instructions

Hydrostatic Unit Outlines for Minor Repair Reference



Series 90

9.1 Pump and Motor Minor Repair

9.1.1 Plug / Fitting Torques

If any plugs or fittings are removed from the pump or motor during servicing, they should be torqued as indicated in the accompanying table.

Always install new O-rings before reinstalling the plugs or fittings.

CAUTION

Plugs or fittings installed into aluminum housings should always be torqued to the lower values specified for internal hex plugs of the same size.

Description	Torque
7/16 — 20 O-Ring	20 Nm
9/16 inch Hex Wrench	(15 lbf•ft)
7/16 — 20 O-Ring	12 Nm
3/16 inch Internal Hex Wrench	(9 lbf•ft)
9/16 — 18 O-Ring	37 Nm
11/16 inch Hex Wrench	(27 lbf•ft)
9/16 — 18 O-Ring	23 Nm
1/4 inch Internal Hex Wrench	(17 lbf•ft)
3/4 — 16 O-Ring	68 Nm
7/8 inch Hex Wrench	(50 lbf•ft)
3/4 — 16 O-Ring	68 Nm
5/16 inch Internal Hex Wrench	(50 lbf•ft)
7/8 — 14 O-Ring	95 Nm
1 inch Hex Wrench	(70 lbf•ft)
7/8 — 14 O-Ring	68 Nm
3/8 inch Internal Hex Wrench	(50 lbf•ft)
1-1/16 — 12 O-Ring	163 Nm
1-1/4 inch Hex Wrench	(120 lbf•ft)
1-1/16 — 12 O-Ring	115 Nm
9/16 inch Internal Hex Wrench	(85 lbf•ft)
1-5/16 — 12 O-Ring	190 Nm
1-1/2 inch Hex Wrench	(140 lbf•ft)
1-5/16 — 12 O-Ring	129 Nm
5/8 inch Internal Hex Wrench	(95 lbf•ft)
1-5/8 — 12 O-Ring	224 Nm
1-7/8 inch Hex Wrench	(165 lbf•ft)



Minor Repair Instructions

9.1.2 Shaft Seal and Shaft Replacement





Remove Seal Carrier


90000271

Remove Screws Holding Retainer Plate and Seal Carrier



90000272 Press Out Old Seal

New Seal Installed in Carrier



Series 90 Shaft Seal Components

Lip type shaft seals are used on Series 90 pumps and motors. These seals and/or the shafts can be replaced without major disassembly of the unit. However, replacement usually requires removal of the pump or motor from the machine.

1. Position the pump with the shaft facing up.

NOTE: If the unit is positioned horizontally when the shaft is removed, the cylinder block could move out of place, making shaft installation difficult.

2. Remove the three or four screws holding the retainer plate and seal carrier to the housing, using a 10 mm hex wrench (030 and 042 units), a 5 mm internal hex wrench (055 through 100 units), or a 6 mm internal hex wrench (130 through 250 units). Remove the retainer plate.

NOTE: Certain earlier production units use a one piece retainer plate and seal carrier.

- 3. After removing the screws, the spring force on the shaft may move the seal carrier out of its bore by approximately 5 mm (1/4 inch). If the seal carrier does not move from its bore after removing the screws, pry it from its bore as shown and/or lightly tap the end of the shaft with a soft mallet.
- 4. Remove the O-ring from the seal carrier.
- 5. Place seal carrier and seal in an arbor press and press out old seal.
- 6. Inspect the seal carrier, the new seal and the Oring for any damage or nicks.
- 7. Using the arbor press, press the new seal into seal carrier. Be careful not to damage the seal.


The outside diameter of the seal may be lightly coated with a sealant (such as Loctite High Performance Sealant #59231) prior to installation. This aids in preventing leaks caused by damage to the seal bore in the seal carrier.



Minor Repair Instructions

- 8. Inspect the sealing area on the shaft for rust, wear, or contamination. If the shaft is not being replaced proceed to step 12.
- 9. Remove shaft and roller bearing assembly from pump or motor. The bearing assembly can be transferred to the new shaft.
- 10. Remove the retaining ring that secures roller bearing assembly with a snap ring pliers. Remove the roller bearing assembly.
- 11. Place roller bearing assembly on new shaft and secure with the retaining ring.
- 12. Wrap spline or key end of shaft with plastic film to prevent damage to the sealing lip on the seal during installation.
- 13. Prior to assembly, lubricate the O-ring on the O.D. of the seal carrier and the I.D. of the seal with clean petroleum jelly.
- 14. Assemble the seal carrier and seal over the shaft and into the housing bore. Install the retainer plate (if used).
- 15. Install the screws and torque to 16 Nm (12 ft•lbf) for 030 through 100 pumps, 32 Nm (24 ft•lbf) for 130 through 250 pumps, 9.5 Nm (7 ft•lbf) for 055 through 100 motors, and 22.5 Nm (16.6 ft•lbf) for 130 motors.

NOTE: Torque the screws in a sequenced pattern then recheck.








90000274 Install Seal Carrier

Torque Retainer Screws



Minor Repair Instructions

9.2 Pump Minor Repairs





Remove Multi-Function Valve Cartridge


Install and Torque Cartridge



Multi-Function Valve Cartridge Components (Earlier Production)



Multi-Function Valve Cartridge Components (Later Production)



Multi-Function Valve Cartridge Sectional View

9.2.1 Multi-Function Valve Cartridges

9

- 1. The multi-function valve cartridge is removed with a 1-1/4 inch (030 through 100 pumps) or a 1-5/8 inch (130 through 250 pumps) hex wrench on the largest hex on the cartridge.
- 2. Inspect cartridge for damage to parts and Orings.

The multi-function valve cartridge may be disassembled for cleaning. However, if the pressure limiter housing assembly is disassembled, the pressure settings must be readjusted. Usually, if there is contamination problem, it will be in the valve seat assembly. If it is not necessary to clean the interior of the cartridge, proceed to step 7.

NOTE: Multi-function valve components are not sold separately as service parts (except O-rings).

3. On early versions of the multi-function valves, the valve seat assembly is held by a retaining ring. Remove retaining ring with a snap ring pliers.

On late versions, the valve seat section is pressed over a lip. Place the cartridge in a vise and pry the lower section off with an appropriate tool. Maintain sufficient control to prevent the contents from flying loose.

- 4. Remove pressure limiter lock nut and bypass actuator.
- 5. Unscrew the pressure limiter adjustment screw from the bypass actuator.
- 6. Clean and inspect all disassembled parts.
- 7. Reassemble with new, lightly lubricated O-rings by reversing the above procedure. For early versions assemble with the retaining ring. For late versions, place the cartridge in a vise and press on lower assembly.

CAUTION

The pressure settings must be readjusted after disassembling the pressure limiter housing of the multi-function valve cartridge (see Sec. 8.2.1)


8. Install cartridge in multi-function valve cavity and torque to 89 Nm (66 ft•lbf) for 030 through 100 pumps and 279 Nm (206 ft•lbf) for 130 through 250 pumps. **Do not overtorque the multi-func-tion valve cartridge.**



Minor Repair Instructions

9.2.2 Pressure Override Valve (Option for 180 Frame Size)

- 1. Remove the four screws attaching the pressure override valve to the pump end cap with a 5 mm internal hex wrench. Remove the O-rings.
- 2. Inspect valve for damage to parts.
- Install new O-rings. Install the valve onto the pump end cap and torque the screws to 16 Nm (12 ft•lbf).



9.2.3 Charge Relief Valve

The pump charge relief valve may be shim adjustable (early models) or screw adjustable (late models).

1. Remove the shim adjustable charge relief valve plug with a 1 inch hex wrench.

Before removing the screw adjustable relief valve plug, mark the plug, lock nut, and housing so as to approximately maintain the original adjustment when assembling. Remove the screw adjustable charge relief valve plug by loosening the lock nut with a 1-1/16 inch wrench for 030 through 100 units or a 1-5/8 inch for 130 through 250 units. Unscrew the plug with a large screwdriver or 1/2 inch hex wrench.

- 2. Remove the spring and relief valve poppet.
- 3. Inspect the poppet and mating seat in the end cap for damage or foreign material.

When inspecting shim adjustable valves, do not alter the shims or interchange parts with another valve.

Install the poppet and spring. For shim adjustable valves, install the plug and torque to 68 Nm (50 ft•lbf). For screw adjustable valves, install the plug with its lock nut, aligning the marks made at disassembly, and torque the lock nut to 52 Nm (38 ft•lbf).

Check the charge pressure and adjust, if necessary (8.1.1).

90000870

Pressure Override Valve Components





Remove Charge Relief Valve (Shim Adjustable)

Shim Adjustable Charge Relief Valve



Remove Charge Relief Valve (Screw Adjustable)




Screw Adjustable Charge Relief Valve




Minor Repair Instructions





Remove Retainer Screws



Left Hand Rotation (Outside Looking Into Pump)

Orienting Gerotor Outer Ring and Alignment Pin (CCW Rotation)

Discharge

Remove Charge Pump

Cover

Outer Eccentric Ring

Right Hand Rotation (Outside Looking Into Pump) 90000871 Orienting Gerotor Outer

Ring and Alignment Pin (CW Rotation)

9.2.4 Charge Pump

The following procedure shows how to remove and install a charge pump.

1. For pumps with an auxiliary mounting pad, remove the four screws holding the pad to the end cap and remove the pad. Refer to the Auxiliary Mounting Pad Installation instructions (next section) for details.

NOTE: Late production pumps may not have the smaller screws installed to secure the end cap to the pump housing when the large screws are removed. On these pumps, secure the end cap to the pump housing with a clamp to avoid gasket damage.

CAUTION

Do not allow the force of the cylinder block spring and swashplate leveler springs to separate the end cap from the pump housing. Gasket damage and external leakage may result.

- 2. Using a 10 mm (030 through 100 pumps) or a 13 mm (130 through 250 pumps) hex wrench, remove the six screws holding the charge pump cover retainer.
- 3. Remove the retainer and the charge pump cover. For pumps with an auxiliary mounting pad, remove the auxiliary drive coupling. Note the orientation of the gerotor.

(continued)



Minor Repair Instructions


- 4. Remove the charge pump shaft and charge pump drive key.
- 5. Remove the spacer plate(s), if present (intermediate production pumps only).

Remove the charge pump outer port plate, if present (early and intermediate production pumps).


Remove the charge pump gerotor assembly.

- Remove the outer eccentric ring and alignment pin.
- 7. Remove the inner port plate.
- 8. Inspect all parts for abnormal wear or damage.


NOTE: If a different displacement charge pump is being installed, the gerotor assembly, gerotor outer eccentric ring, and inner port plate (early and late production pumps) or outer spacer plate(s) (intermediate production pumps) must be replaced together. If different thickness port plates are used in an early production charge pump assembly, the thicker plate is the inner port plate (installed next to the pump end cap).




9



arge Pump Components (Intermediat Production)



Charge Pump Components (Late Production)





Minor Repair Instructions

Oute

Orienting Gerotor Outer

Ring and Alignment Pin


Right Hand Rotation

(Outside Looking Into Pump)

Eccentric Ring


9000087

Discharge



Left Hand Rotation (Outside Looking Into Pump)

Orienting Gerotor Outer Ring and Alignment Pin (CCW Rotation)



Install Inner Port Plate





Install Alignment Pin



Install Outer Port Plate (Early and Intermediate Production Only)



Install Gerotor Assembly



Install Spacer Plate (Intermediate Production Only)

Installing the Charge Pump

Be sure to install the charge pump in the proper orientation. If unsure of charge pump rotation, refer to the model code.

9

NOTE: The charge pump rotation is determined by the orientation of the gerotor assembly outer eccentric ring and the location of the alignment pin in the end cap.

NOTE: Do not mix charge pump piece parts from different production periods. Always install as a complete assembly.

- 1. Install the inner port plate and the gerotor assembly outer ring.
- 2. Install the alignment pin to properly orient the port plates and outer eccentric ring for corresponding pump rotation.
- 3. Prior to installation, apply a small quantity of petroleum jelly to the I.D., O.D., and side faces of the gerotor assembly to provide initial lubrication.
- 4. Install the gerotor assembly.
- Install the outer port plate (early production and 5. intermediate production pumps only).
- 6. Install the spacer plate, if present (intermediate production pumps).

(continued)





Minor Repair Instructions

7. Install the charge pump drive key into the charge pump shaft and retain with petroleum jelly.

NOTE: Intermediate production 75 cc and 100 cc pumps use the same charge pump drive shaft. Two keyways are provided in the drive shaft for the charge pumps used in these units. The rear keyway (with identifier groove) is used in 75 cc pumps. The front keyway (closest to the internally splined end of the shaft) is used in 100 cc pumps.

8. Install the charge pump shaft. The internally splined end of the shaft must engage the main pump shaft.

NOTE: The outside diameter of the internally splined end of some early production charge pump shafts was chamfered. Early production end caps may not be machined to accept a nonchamfered shaft. Always use a chamfered charge pump shaft in pumps with the early end cap.

- 9. For pumps with an auxiliary mounting pad, install the auxiliary drive coupling.
- 10. Install a new O-ring onto the non-auxiliary pad charge pump cover. (If an auxiliary pad is installed, an O-ring is not used on the cover.)
- 11. Carefully remove the alignment pin from the charge pump parts. Install the pin in its hole in the charge pump cover (see previous page for correct orientation) and retain with petroleum jelly. Install the cover (with alignment pin) into the end cap and aligned charge pump parts. (Take care not to damage the cover O-ring, if used.)

CAUTION

In order to avoid loss of charge pressure in pumps with an auxiliary mounting pad, always install the charge pump cover with the pad drain hole located on the same side of the end cap as the charge inlet port. Refer to Sec. 9.2.5 Auxiliary Pad Installation for details.

- 12. Install the charge pump cover retainer and the six hex screws and torque the screws to 13.5 Nm (10 ft•lbf) for 030 through 100 pumps, and 32 Nm (24 ft•lbf) for 130 through 250 pumps.
- For pumps with auxiliary mounting pads, install the O-ring and auxiliary mounting pad adaptor onto the end cap. Refer to Sec. 9.2.5 for instructions on auxiliary pad installation.

100 cc 75 cc



Keyways in Charge Pump Shaft (Intermediate Production 075 and 100)



Install Charge Pump Shaft





Aligning Pin Installed in Cover

Install Charge Pump Cover



Install Cover Retainer




Torque Retainer Screws




Minor Repair Instructions






Remove Screws and Retainer

Remove Charge Pump Cover



Remove Large End Cap Screws



Auxiliary Pad Components (Typical)

9.2.5 Auxiliary Pad Installation

- Using a 10 mm (030 through 100 pumps) or a 13 mm (130 through 250 pumps) hex wrench, remove the six screws holding the charge pump cover retainer. Remove the retainer.
- 2. Remove the charge pump cover and its O-ring.

NOTE: The original charge pump cover will not be used when installing the auxiliary pad.

3. Remove the four large screws which fasten the end cap to the pump housing.

Frame Size	Hex Wrench Size			
Frame Size	Internal Hex	External Hex		
030 & 042 (early)	8 mm			
042 (late)	10 mm			
055		19 mm		
075 & 100		24 mm		
100 & 130	14 mm			
180 & 250	17 mm			

NOTE: Late production pumps may not have the smaller screws installed to secure the end cap to the pump housing when the large screws are removed. On these pumps, secure the end cap to the pump housing with a clamp to avoid gasket damage.

CAUTION

Do not allow the force of the cylinder block spring and swashplate leveler springs to separate the end cap from the pump housing. Gasket damage and external leakage may result.

4. Take care to assure the surfaces are clean and free of any foreign material or paint prior to installing the auxiliary pad.

(continued)



Minor Repair Instructions

- 5. Install the auxiliary drive coupling onto the pump drive shaft spline (auxiliary drive spline must be toward the rear of the pump).
- 6. Carefully remove the alignment pin from the charge pump parts. Install the pin in its hole in the new charge pump cover (with hole for the auxiliary coupling) and retain with petroleum jelly. Install the new charge pump cover with alignment pin into the end cap and the aligned charge pump parts.

CAUTION

In order to avoid loss of charge pressure, always install the charge pump cover with the pad drain hole located on the same side of the end cap as the charge inlet port.

- 7. Install the charge pump cover retainer and the six hex screws and torque the screws to 13.5 Nm (10 ft•lbf) for 030 through 100 pumps, and 32 Nm (24 ft•lbf) for 130 through 250 pumps.
- 8. Install O-ring on end cap pilot.
- 9. Install the auxiliary mounting pad adapter on external pilot on rear of end cap.
- 10. Install four new large screws and washers through the mounting pad and end cap into the housing. Torque per the accompanying table.

Frame Size	Wrench Size	Torque		
I fame Size	(Internal Hex)	Nm	lbf•ft	
030 & 042 (early)	8 mm	75	55	
042 (late) & 055	10 mm	122 90		
075	14 mm	256	189	
100 & 130	14 mm	298	220	
180 & 250	17 mm	580 429		

11. Install the O-ring and flange cover or auxiliary pump.

Auxiliary Pad Conversion

To convert an auxiliary mounting pad to a different size mounting pad, use the above procedure with the following additions:

After removing the charge pump cover (step 2), remove the old auxiliary drive coupling.

After removing the four end cap retaining screws (step 3), remove the old auxiliary mounting pad adapter.





Install Drive Coupling

Install Alignment Pin in **Cover (CCW Rotation** shown)





90000300

90000299 Install New Charge Pump Install Screws and Cover Cover



Install O-Ring on End Cap Pilot



Install Auxiliary Pad Adapter Screws



Retainer

90000303 Install Auxiliary Pad Adapter




Torque Pad Adapter Screws



Minor Repair






90000310 Charge Pump Inlet


90000243 **Reducer Fitting**



Remote Pressure Filter Manifold



90000312 **Install Remote Pressure Filter Manifold**



Tighten Remote Pressure Tighten Integral Pressure **Filter Manifold Lock Nut**



Integral Pressure Filter

Head

90000315 Install Integral Pressure **Filter Head**



90000316 **Filter Head Lock Nut**

9.2.6 Filtration Options

9.2.6.1 Suction Filtration Installation

1. Install the hydraulic fitting to connect the external suction filter to the charge pump inlet port.

9

2. The reducer fitting (placed on the charge pressure gauge port) is installed as follows.

Frame Size	Wrench Size	Torque	
042	1-1/4"	70 Nm	[52 lbf•ft]
055 - 130	1-1/2"	122 Nm	[90 lbf•ft]
180 & 250	1–1/2"	156 Nm	[115 lbf•ft]

The gauge port plug is torqued to 27 Nm (20 ft•lbf).

9.2.6.2 Remote Charge Pressure Filtration or Integral Charge Pressure Filtration

Install either of these two filtration devices as follows.

- 1. Remove the reducer fitting, located at charge pressure gauge port, from pump end cap (this part will not be used).
- 2. Install the filter manifold or filter head into the port. The hydraulic tube should enter its mating bore in the pump end cap with a low force.
- 3. After rotating the filter manifold or filter head clockwise so that the threads engage with the threads in the end cap, continue to rotate it clockwise between 6 and 7 revolutions. Face manifold or head to the desired position.

CAUTION

Failure to install the filter manifold or filter head to a sufficient depth in the end cap will result in insufficient engagement of the tube in the end cap bore. This may allow unfiltered oil to bypass the filter and enter the charge system.

4. While holding the filter manifold or filter head in the desired position, tighten the swivel lock nut.

Frame Size	Wrench Size	Torque	
042	1–3/8"	70 Nm	52 lbf•ft
055 - 130	1—5/8"	122 Nm	90 lbf•ft
180 & 250	1–5/8"	156 Nm	115 lbf•ft

5. After installing the integral pressure filter head assembly, install the filter canister per the instructions on the filter canister.



Minor Repair

9.3 Pump Controls

9.3.1 Cover Plate


- 1. Thoroughly clean external surfaces prior to removal of cover plate.
- 2. Using a 5 mm internal hex wrench, remove the eight cover plate mounting screws. Remove the cover plate and gasket from housing.

CAUTION

Protect exposed surfaces and cavities from damage and foreign material.

3. In preparation for installing the cover plate, place a new gasket on the housing. Place the cover plate into position and install the screws. Torque the screws to 16 Nm (12 ft•lbf).

NOTE: A sealing washer must be installed under the head of any mounting screws that are installed into "thru" holes in the housing.



Pump with Cover Plate

90000361



Minor Repair





Remove Mounting Screws

Remove Control



Inner Face of Control



Assemble Control to Linkage



Assemble Control to Pump



Torque Mounting Screws

9.3.2 Manual Displacement Control (MDC)

- 1. Thoroughly clean external surfaces prior to removal of control.
- 2. Using a 5 mm internal hex wrench, remove the eight control mounting screws. Remove the control (with orifice check valve and spring) and control gasket from housing.

CAUTION

Protect exposed surfaces and cavities from damage and foreign material.

- 3. In preparation for installing the control, place a new gasket on the housing. Inspect to assure that the control orifice check valve and spring are in their proper position in the control.
- 4. While setting the control into position, engage the pin on the control linkage into the mating hole in the link attached to the swashplate.
- 5. With the control in position, move control lever both directions to check proper engagement of control linkage pin. Proper engagement will be indicated by centering torque as the lever is moved from center. Non-engagement of control linkage pin is indicated by lack of centering torque as the lever is moved. In case of non-engagement remove the control and repeat the above procedure.
- Align the control gasket and install the screws. Torque the screws to 16 Nm (12 ft•lbf).

NOTE: A sealing washer must be installed under the head of any mounting screws that are installed into "thru" holes in the housing.

7. If the control is equipped with a neutral start switch, refer to the "MDC Neutral Start Switch Adjustment" instructions in Sec. 8.2.3.

WARNING

The neutral start switch "neutral" must be readjusted after reassembling the MDC module.




Minor Repair

9.3.3 Solenoid Override Valve for MDC


- Thoroughly clean external surfaces prior to removal of valve.
- 2. Using a 5 mm internal hex wrench, remove the two screws and remove solenoid manifold from housing. Remove the old gasket.
- 3. The solenoid may be removed from the valve by removing the nut with a 3/4 inch hex wrench. The solenoid valve may be removed from the manifold with a 7/8 inch hex wrench.
- When installing the solenoid valve into the manifold, the valve should be torqued to 18.6 Nm (13.8 ft•lbf). When installing the solenoid onto the valve, torque the nut to 2.8 Nm (25 in•lbf).
- In preparation for installing the solenoid manifold, place a new gasket on the control housing. Install the manifold onto the control housing, align the gasket, and install the screws. Torque screws to 13.5 Nm (10 ft•lbf).

9.3.4 Solenoid Override Valve for MDC with Pressure Released Brake

- 1. Thoroughly clean external surfaces prior to removal of valve.
- 2. Using a 4 mm internal hex wrench, remove the four solenoid valve mounting screws. Remove the solenoid valve (with O-rings) from the adapter plate.
- Using a 4 mm internal hex wrench, remove the four adapter plate mounting screws. Remove the adapter plate and O-rings from the control housing.
- 4. Remove the check valve seat and O-ring from the control side of the adapter plate. Remove the check ball and spring.
- 5. Install a new O-ring on the check valve seat and reassemble the check valve spring, ball, and seat into the adapter plate.
- Install new O-rings on the adapter plate. Place the adapter plate into position and install the screws. Torque the screws to 5.4 Nm (48 in•lbf).
- Install new O-rings onto the solenoid valve assembly and install the solenoid valve onto the adapter plate. Install the screws and torque to 5.4 Nm (48 in•lbf).



Components of Solenoid Override for MDC



Components of Solenoid Override with Brake Pressure Defeat for MDC



Minor Repair





Remove Mounting Screws

Remove Control





Linkage

Inner Face of Control



90000329 Install Mounting Screws



29 Torque Mounting Screws



PCP Components



Torque PCP Valve Screws

9.3.5 Hydraulic and Electric Displacement Controls

1. Thoroughly clean external surfaces prior to removal of control.

9

2. Using a 5 mm internal hex wrench, remove the eight control mounting screws. Remove the control (with orifice check valve and spring) and control gasket from housing.

CAUTION

Protect exposed surfaces and cavities from damage and foreign material.

- 3. In preparation for installing the control, place a new gasket on the housing. Inspect to ensure that the control orifice check valve and spring are in their proper position in the control.
- 4. While setting the control into position, engage the pin on the control linkage into the mating hole in the link attached to the swashplate.
- 5. With the control in position, move control assembly left and right to check engagement of pin in the link. Proper engagement will be indicated by an increasing resistance as the control is moved away from center position. Non-engagement of pin will be indicated by lack of spring force. In case of non-engagement, remove control and repeat the above procedure.
- Align the control gasket and install the screws. Torque the screws to 16 Nm (12 ft•lbf).

NOTE: A sealing washer must be installed under the head of any mounting screws that are installed into "through" holes in the housing.

9.3.6 Pressure Control Pilot (PCP) for Electric Displacement Control

- 1. Thoroughly clean external surfaces of control.
- 2. Using a 4 mm internal hex wrench, remove the four screws and remove the PCP.
- 3. Check surfaces for nicks or damage. Clean internal screens.
- 4. Install new O-rings in PCP Housing. Place PCP against EDC housing and install the screws. Torque to 5.4 Nm (48 in•lbf).

NOTE: Do not remove black plastic cover from the aluminum plate. This is not a serviceable item and will void the product warranty.



Minor Repair

9.3.7 3-Position (FNR) Electric Control

- Thoroughly clean external surfaces prior to removal of control.
- Using a 4 mm internal hex wrench, remove the four solenoid valve mounting screws. Remove the solenoid valve (with O-rings and orifice) from the adapter plate.
- 3. Using a 5 mm internal hex wrench, remove the eight adapter plate mounting screws. Remove the adapter plate and gasket from housing.


CAUTION

Protect exposed surfaces and cavities from damage and foreign material.


- Inspect the orifice installed between the valve and adapter plate. This orifice MUST be installed in the case drain passage for proper pressure limiter operation.
- In preparation for installing the adapter plate, place a new gasket on the housing. Place the adapter plate into position and install the screws. Torque the screws to 16 Nm (12 ft•lbf).


NOTE: A sealing washer must be installed under the head of any mounting screws that are installed into "thru" holes in the housing.

 Install new O-rings and the orifice onto the solenoid valve assembly and install the solenoid valve onto the adapter plate. Install the screws and torque to 5.4 Nm (48 in•lbf).




3-Position Electric Control Components






Displacement Control Adapter Plate (Early Production 130cc Pumps Only)







The Underside of an HDC/EDC Module Showing Orifice Locations

9.3.8 Displacement Control Components

9.3.8.1 Displacement Control Adapter Plate (Early Production 130 Pumps Only)

The screws fastening the control adapter plate to the housing have retaining compound on the threads. They are removed with a 6 mm internal hex wrench.

When installing the adapter plate, ensure the O-rings are in the proper position and torque the screws to 32 Nm (24 ft•lbf).

9.3.8.2 Displacement Control Filter Screens

If the pump is equipped with control filter screens in the pump housing (late production), they should be pressed into position (with the rounded edge of the filter screens facing the control) until they are flush to 2.0 mm (0.08 inch) below the surface of the housing.

9.3.8.3 Displacement Control Orifice Check Valve

- 1. Remove the control assembly as described in the instructions for the specific displacement control (9.3.2, 9.3.6, or 9.3.7).
- 2. The orifice check valve is located in the control assembly, at the surface of the pump housing face. Remove the spring retainer and spring from the orifice check valve cavity and then remove the orifice check valve.
- 3. Install the desired orifice check valve in the cavity and then install the spring and spring retainer to hold the orifice check valve in position.
- 4. Assemble the control onto the pump. Refer to the instructions for the specific control (9.3.2, 9.3.6, or 9.3.7).

9.3.8.4 Displacement Control Orifices

- 1. Remove the control assembly as described in the instructions for the specific displacement control (9.3.2, 9.3.6, or 9.3.7).
- 2. Orifice plugs may be located in the control assembly, at the pump housing face surface. Remove the orifice plugs with a 4 mm internal hex wrench. Note the location of each plug, do not interchange plugs. Torque the orifice plugs to 3 Nm (32 in•lbf).
- 3. Assemble the control onto the pump. Refer to the instructions for the specific control.

Series 90

Minor Repair

9.4 Minor Repairs - Motor

9.4.1 Loop Flushing and Charge Relief Valves

9.4.1.1 Loop Flushing Valve

- Using an 11/16 inch wrench, remove the hex plugs and O-rings from both sides of the valve. Remove the springs, shoulder washers, and flushing valve shuttle spool. Note orientation of the washers. Remove the flushing valve spool.
- 2. Inspect parts for damage or foreign material.

NOTE: Early production motors used a small diameter shuttle valve spool. Late production motors use a larger diameter spool.

3. Install flushing valve spool in end cap, then install the shoulder washers (with shoulders facing "out") and springs on each end of the spool. Install the hex plugs with O-rings, and torque to 41 Nm (30 ft•lbf) on 030 through 100 motors or 68 Nm (50 ft•lbf) on 130 motors.

9.4.1.2 Motor Charge Relief Valve

- Remove the shim adjustable charge relief valve plug with a 7/8 inch hex wrench. Before removing the screw adjustable relief valve plug, mark the plug, lock nut, and housing so as to be able to maintain the original adjustment when assembling. Remove the screw adjustable charge relief valve plug by loosening the lock nut with a 1-1/16 inch hex wrench for 030 through 100 units, or a 1-5/8 inch hex wrench for 130 units, and unscrewing the plug with a large screwdriver or 1/2 inch hex wrench.
- 2. Remove the spring and valve poppet.
- 3. Inspect the poppet and mating seat in the end cap for damage or foreign material. When inspecting shim adjustable valves, do not alter the shims or interchange parts with another valve.
- Install the poppet and spring. For shim adjustable valves, install the plug and torque to 68 Nm (50 ft•lbf). For screw adjustable valves, install the plug with its lock nut, aligning the marks made at disassembly, and torque the lock nut to 52 Nm (38 ft•lbf).
- 5. Check and adjust the charge pressure.





Remove Plugs and Springs

Remove Flushing Shuttle Spool





Install Flushing Shuttle Spool

Torque Plugs





Remove Shim Charge Relief



Shim Adjustable Charge Relief Valve


Remove Screw Charge Relief



Screw Adjustable Charge Relief Valve



Minor Repair



Motor Charge Relief Valve and Loop Flushing Valve Parts

9.4.1.3 Defeating the Loop Flushing Valve

- 1. Remove loop flushing valve components (these parts will not be used).
- 2. Install defeating spool into spool bore in end cap.
- 3. Install hex plugs provided and torque to 41 Nm (30 ft•lbf) on 030 through 100 motors, or 68 Nm (50 ft•lbf) on 130 motors.
- 4. Remove charge relief valve components (these parts are not necessary).
- 5. Replace with the hex plug provided and torque to 41 Nm (30 ft•lbf) on 030 through 100 motors, or 68 Nm (50 ft•lbf) on 130 motors.



Minor Repair

9.4.2 Variable Motor Displacement Limiters

- Remove the tamper-resistant cap from the displacement limiter. Using a 19 mm hex wrench, loosen the seal lock nut and remove the nut. Remove the limiter screw from the motor housing with a 6 mm internal hex wrench.
- Install the limiter screw and seal lock nut. Do not install a new tamper-resistant cap until the limiter has been adjusted.
- The displacement limiter should be initially adjusted so the motor swashplate contacts the limiter screws BEFORE it contacts the internal stops. Hold the swashplate in its maximum or minimum angle position and turn the appropriate limiter screw clockwise until it contacts the swashplate. Then turn the screw an additional 1/4 turn clockwise and torque the seal lock nut to 54 Nm (40 ft•lbf).
- 4. Final adjustment of the displacement limiters should be performed on a test stand. Do not turn the limiter screws counterclockwise beyond their initial adjustment positions.


WARNING

Care should be taken in adjusting displacement limiters to avoid undesirable speed conditions. The seal lock nut must be retorqued after every adjustment to prevent an unexpected change in operating conditions and to prevent external leakage during unit operation.

One full turn of the displacement limiter adjustment screw will change the displacement as follows:

Frame Size	Approx Change in Disp per Rev of Adjusting Screw
055	5.6 cm ³ / Rev (0.34 in ³ / Rev)
075	7.1 cm ³ / Rev (0.43 in ³ / Rev)

5. Following the final adjustment, install new tamper resistant caps.




90000851

9


MV Displacement Limiters



9.5 Variable Motor Controls



MV Control Components



MV Control Plugs

9.5.1 Electrohydraulic 2-Position Control (Types NA, NB, NC, and ND)

- 1. Thoroughly clean external surfaces prior to removal of the control.
- 2. Disconnect the external electrical signal connection.
- 3. Remove the hex nut and solenoid from the control valve.
- 4. Remove the orifice check valve for the maximum angle control cylinder, if equipped.
- 5. Remove the control valve from the motor housing.
- 6. Remove O-rings from the valve.
- 7. Install new O-rings on the control valve.
- Install the valve into the motor housing and torque to 47 Nm (35 ft•lbf). Do not overtorque the control valve. Over-torquing may result in the valve spool sticking.
- 9. Install the solenoid onto the valve and torque the hex nut to 5 Nm (44 in•lbf). Do not overtorque the nut.
- 10. If previously removed, reinstall the orifice check valve. Reconnect the external electrical signal connection.

9.5.2 Hydraulic 2-Position Control (Type PT)

Follow the steps above, except that in step 2 a *hydraulic* signal line will be disconnected, and step 3 is not applicable.

9.5.3 Control Plugs

Remove the control plugs from the housings of earlier production motors, if necessary. Install new O-rings, reinstall, and torque.



Minor Repair


9.5.4 Variable Motor Control Orifices

9.5.4.1 Control Supply Orifice

- 1. Remove the control supply orifice from the motor housing with an 11/16 inch hex wrench.
- Remove the O-rings and the backup washers. Check that the filter screen is secure in the orifice body and that the screen and the orifice are not plugged.
- 3. Install new backup washers and O-rings onto the orifice body. Install the orifice into the motor housing and torque to 37 Nm (27 ft•lbf).

CAUTION

Do not interchange the control supply orifice with the minimum displacement orifice (next section).




MV Control Supply Orifice

9.5.4.2 Minimum Displacement Cylinder Orifice or Orifice Check Valve

- 1. Remove the minimum displacement cylinder drain orifice or the orifice check valve from the motor housing with an 11/16 inch hex wrench.
- 2. Remove the O-rings and the backup washers. Check that the orifice is not plugged. Check that the check valve seat is secure in the body and that the check ball is free.
- 3. Install new backup washers and O-rings onto the orifice body. Install the orifice into the motor housing and torque to 37 Nm (27 ft•lbf).

CAUTION


Do not interchange the control supply orifice (previous section) with the minimum displacement orifice.



MV Minimum Displacement Orifice



Minor Repair



90000856

MV Maximum Displacement Orifice

9.5.4.3 Maximum Displacement Cylinder Orifice Check Valve


- 1. Remove the seal lock nut with a 3/4 inch hex wrench. Remove the maximum displacement cylinder orifice check valve from the motor housing with a 1/4 inch end wrench. Remove the O-ring. The check ball in the valve must be free.
- 2. Reinstall the check valve and torque to 15 Nm (11 ft•lbf). Install a new O-ring. Install the seal lock nut with the seal toward the motor housing. Hold the check valve from turning while torquing the seal lock nut to 34 Nm (25 ft•lbf).
- 3. If no orifice check valve is installed, the housing plug may be removed with a 9/16 inch hex wrench. Always install a new O-ring. Reinstall the plug and torque to 20 Nm (15 ft•lbf).




Minor Repair

9.6 Speed Sensor


- Remove the speed sensor by disconnecting the electrical connector, loosening the lock nut, and unscrewing the speed sensor from the pump or motor housing.
- 2. Always install a new O-ring before installing the sensor.
- 3. Reinstall the speed sensor (with lock nut and Oring) into the housing. Adjust the gap between the sensor and the magnetic speed ring as instructed in Sec. 8.4 and torgue the sensor lock nut.
- 4. If a speed sensor is not installed, the housing plug should be torqued as indicated in the accompany-ing figure.



Typical Location of Speed Sensor - PV



Typical Location of Speed Sensor - MF



Typical Location of Speed Sensor - MV




Exploded View Parts Drawings

10. Exploded View Parts Drawings


10

10.1 Variable Pumps

10.1.1 Name Plates




10.1.2 Minor Repair Parts





10.1.3 Controls




90000861



Exploded View Parts Drawings

10.1.4 Filtration Options, Charge Pump Options, Auxiliary Pad Options





Exploded View Parts Drawings

10.1.5 Pump Parts List

Item	Description	Qty	ltem	Description	Qty
B70	Plug	2	J50A-V	O ring	1
B71	Plug	1	J60A/T	Flange adaptor	1
B80	Plug	1	J60B/V	Flange adaptor	1
B82	Plug	1	J60C	Flange adaptor	1
B90	Control Filter Screen	3	J60D	Flange adaptor	1
			J70A-V	Washer	4
G63	Split Clamp	4	J80A-V	Screw	4
G64	Screw - Shipping Cover	4	J80N	Screw	4
			J90A-V	O ring	1
G172	Plug	1	J92A-V	Cover plate	1
G176	Plug	1	J95A-V	Screw	2/4
G501	Plug	3			
G502	Plug	3	K10	Plug Assembly	1
G506	Plug	3	K50	O ring	1
G508	Plug	3	K70	Spring	1
G511	Plug	1	K80	Poppet	1
G512	Plug	1	K90	Nut	1
G516	Plug	1			
G518	Plug	1	L30	Seal carrier	1
G521	Plug	1	L35	Seal carrier	1
G522	Plug	1	L40	Lip seal	1
G526	Plug	1	L50	O ring	1
G528	Plug	1	L60	Retainer	1
G531	Plug	1	L70	Screw	3
G532	Plug	1			
G536	Plug	1	L8	Кеу	1
G538	Plug	1	L9	Slotted nut	1
G541	Plug	1			
G542	Plug	1	MOCA	Control - Cover Plate Kit	1
G546	Plug	1	M1CA	Cover plate	1
G548	Plug	1	M11C	Control gasket	1
			M87C	Washer, seal (042)	1
H05B-H	Kit - Charge pump	1	M90C	Screw	6
H05L	Spacer (No Charge pump)	1			
H30	Port plate	2	MODC	Control kit 3 position FNR 12v	1
H40	Pin	1	MODD	Control kit 3 position FNR 24v	1
H50	Charge pump shaft	1	M1DC	Control 3 position FNR 12v	1
H60	Key	1	M1DD	Control 3 position FNR 24v	1
H70	Retaining plate	1	M80	Control gasket	1
H80	Screw	6	M87D	Washer, seal (042)	1
H90L	Plug	1	M90D	Screw	6
J00A	Aux. mtg. 'A' flange	1	MOEA	EDC kit w/MS connector	1
J00B	Aux. mtg. 'B' flange	1	M0EP	EDC kit w/Packard connector	1
JOOC	Aux. mtg. 'C' flange	1	M1EA	EDC w/MS connector	1
JOOD	Aux. mtg. 'D' flange	1	M1EP	EDC w/Packard connector	1
JOOT	Aux. mtg. 'A' flange (11T)	1	M9EA	PCP type 3 oil filled (MS)	1
JOOV	Aux. mtg. 'B-B flange	1	M9EA	PCP type 3 oil filled (Packard)	1
JOON	Aux. mtg. flange - none	1	M80	Control gasket	1
J10A-V	Coupling	1	M87E	Washer, seal (042)	1
J15	Charge pump cover assembly	1	M90E	Screw (MO)	6
J15N	Charge pump cover assembly	1	M91E	Plastic cap (MS)	1
J30	Bushing	1	M95E	O ring	2



Exploded View Parts Drawings


Item	Description	Qty	ltem	Description	Qty
M96E	O ring	1	M810	Adapter Plate - Control (130 cc)	1
M97E	Oring	1	M820	O-ring (130 cc)	1
M98E	Screw	4	M830	O-ring (130 cc)	1
			M840	O-ring (130 cc)	2
MOHA	HDC kit	1	M850	Plug (130 cc)	1
MOHC	HDC kit	1	M860	Screw (130 cc)	6
M1HA	HDC	1	M870	Plug (130 cc)	1
M1HC	HDC	1			
M80	Control gasket	1	NOOM	Filtration manifold kit (Int)	1
M87H	Washer, seal (042)	1	N10M	Manifold	1
M90H	Screw	6	N15M	Oring	2
			N20M	Nut	1
MOMA	MDC w/o neutral start switch	1	N25M	Tube	1
M7M	Control handle	1	N30M	Plug	2
M71M	Washer	1	N40L	Filter	1
M72M	Nut Control gooket	1	N40P	Filter	1
M80 M87M	Control gasket	1	NOOD	Filtration monifold kit (Dmt)	4
M90M	Washer, seal (042) Screw	1 6	N00R N10R	Filtration manifold kit (Rmt) Manifold	1
INISOIN	Sciew	0	N15R	O ring	1
MOMB	MDC w/neutral start switch	1	N20R	Nut	1
M7M	Control handle	1	N25R	Tube	1
M71M	Washer	1	N30R	Plastic plug	2
M72M	Nut	1	NOOR	Plug	1
M80	Control gasket	1	Noon	1 109	
M87M	Washer, seal (042)	1	N00S	Filtration kit (Suction Flt)	1
M90M	Screw	6	N10S	Reducer fitting (Suction Flt)	1
S40	Neutral start switch kit	1	N30S	Plug	1
MOMC	MDC w/sol. valve	1	P2A	Multi-function valve assembly	1
M7M	Control handle	1	P2B	Multi-function valve assembly	1
M71M	Washer	1	P6	O ring	2
M72M	Nut	1	P13	O ring	2
M74M	Solenoid valve	1	P30	Plastic plug	2
M75M	Control manifold	1			
M77M	Manifold gasket	1	T001-9	Control orifice kit	1
M78M	Screw	2	T201-9	Orificed check valve	1
M80	Control gasket	1	T301-9	Spring	1
M87M	Washer, seal (042)	1	T401-9	Spring retainer	1
M90M	Screw	6			
MOMD	MDC w/sol. valve, nss	1			
M7M	Control handle	1			
M71M	Washer	1			
M72M	Nut	1			
M75M	Control manifold	1			
M76M	Solenoid valve	1			
M77M	Manifold gasket	1			
M78M	Screw	2			
M80	Control gasket	1			
M87M	Washer, seal (042)	1			
M90M	Screw	6			
S40	Neutral start switch kit	1			



Exploded View Parts Drawings

10.2 Fixed Motor


10.2.1 Name Plates





Name Plate (German Production)

10.2.2 Minor Repair Parts





Exploded View Parts Drawings


10.2.3 Fixed Motor Parts List

Item	Description	Qty	ltem	Description	Qty
B80	Plug	2	L30	Seal carrier	1
B83	Plug	1	L35	Seal carrier	1
B83	Speed sensor	1	L40	Lip seal	1
			L50	Oring	1
G50	Plug	2	L60	Retainer	1
G70	Plug	1	L70	Metric screw	3
G63	Split Clamp	4			
G64	Screw - Shipping Cover	4	L8	Key	1
			L9	Slotted nut	1
H10N	Loop flushing spool - defeat	1			
H50N	Plug	2			
H10W	Shuttle valve spool	1			
H20W	Spring guide	2			
H30W	Spring	2			
H40W	O-ring	2			
H50W	Special plug	2			
H60W	Charge relief valve plug	1			
H62W	O-ring	1			
H64W	Spring	1			
H66W	Charge relief poppet	1			
H68W	Lock nut	1			




10.3 Variable Motor

10.3.1 Name Plate



Name Plate (U.S.A. Production)

10.3.2 Minor Repair Parts





Series 90

Exploded View Parts Drawings

10.3.3 Variable Motor Parts List

Item	Description	Qty	ltem	Description	Qty
B74	Plug	4	L30	Seal carrier	1
B76	Plug	1	L35	Seal carrier	1
B80	Plug	2	L40	Lip seal	1
B83	Plug	1	L50	O-ring	1
B83	Speed sensor	1	L60	Retainer	1
			L70	Screw	3
E15	Сар	1			
E25	Set screw	1	M1N	Control valve - electric	1
E35	Nut - Seal Lock	1	M1P	Control valve - hydraulic	1
G50	Plug	2	P400	Plug	2
G63	Split flange clamp	4	P600	Plug	1
G64	Shipping cover screw	4	P601	Press compensator valve	1
G70	Plug	1	P700	Special plug	1
			P800	O-ring	1
H10N	Loop flushing spool - defeat	1			
H50N	Plug	2	T30	Filter screen	1
H60N	Plug	1	T40	O-ring	1
			T50	Back up ring	2
H10W	Shuttle valve spool	1	T60	O-ring	1
H20W	Spring guide	2	T100	Orifice plug	1
H30W	Spring	2			
H40W	O-ring	2	Y40	O-ring	1
H50W	Special plug	2	Y50	Back up ring	2
H60W	Charge relief valve plug	1	Y60	O-ring	1
H62W	O-ring	1	Y70	Orifice check valve	1
H64W	Spring	1	Y71	Nut - Seal lock	1
H66W	Charge relief poppet	1	Y72	O-ring	
H68W	Lock nut	1	Y80 Y100	Plug Orifice plug	1 1
L8	Key	1	Y102	Orifice check valve	1
L9	Slotted nut	1			



Series 90

Notes

Hydraulic Power Systems

SAUER-SUNDSTRAND Hydraulic Power Systems - Market Leaders Worldwide

SAUER-SUNDSTRAND is a world leader in the design and manufacture of Hydraulic Power Systems. Research and development resources in both North America and Europe enable SAUER-SUNDSTRAND to offer a wide range of design solutions utilizing hydraulic power system technology. SAUER-SUNDSTRAND specializes in integrating a full range of system components to provide vehicle designers with the most advanced total-design system.

SAUER-SUNDSTRAND is Your World Source for Controlled Hydraulic Power Systems.







SAUER-SUNDSTRAND COMPANY 2800 East 13th Street Ames IA 50010 • U.S.A. Phone: (515) 239-6000 • FAX: (515) 239-6618 SAUER-SUNDSTRAND GMBH & CO. Postfach 2460 • D-24531 Neumünster Krokamp 35 • D-24539 Neumünster • Germany Phone: (04321) 871-0 • Fax: (04321) 871 465


SM-S90 • 06/96 • 300947F BLN-09947 • Rev. F • June 1996 **Eaton[®]** Medium Duty Piston Motors No. 06-161 May 1999



Parts Information







Model 74624 and 74644,

82,6 cm3/r [5.04 in3/r] Displacement

design code ${f B}$





Identification and Tools Required

Identification Numbers

Stamped on each unit.

A - Product Number Descriptions


74624 = Fixed Motor 82,6 cm³/r [5.04 in³/r]

74644 = Fixed Motor thru Shaft for Brake Mount 82,6 cm³/r [5.04 in³/r]

B - Rotation,

D = Dual

- C Sequential Letters
- D Design Code Number



Required Tools

- 1/2 in. Socket, w/ Ratchet Wrench
- External Retaining Ring Pliers (straight .090 tip)
- Internal Retaining Ring Pliers (straight .090 tip)
- O-ring Pick
- Torque Wrench (54 N m [40 lbf ft] capacity)
- Hammer (soft face)
- Light Petroleum Jelly
- Seal Driver

Parts List

	Item	Part No.	Qty.	Description
	1	Refer to List	1	Drive Shaft
	2	Refer to List	1	Backplate Assembly
	3	Refer to List	1	Housing Assembly
	4	74614-50	1	Rotating Kit Assembly - Refer to specific parts list
	4a	74614-52	1	Rotating Kit Assembly - Heat Treated - Refer to specific parts list
+~	5	16009-118	1	Retaining Ring
+~	6	160015-57	1	O-ring, 2,37 mm Dia. x 114,3 mm ID. [.0937 in. Dia. x 4.5 in. ID.]
	7	74600-102	1	Thrust Bearing
	8	74600-600	2	Pivot
	9	74600-601	1	Spider
	10	74600-603	1	Key
	11	74604-5	9	Piston
	12	74604-10	9	Piston Assembly
	13	74604-59	1	Connector Plate
	14	74600-605	1	Spacer
+~	15	16232-16	1	Shaft Seal
	16	74600-100	1	Bearing Race
	17	74600-110	1	Piston Race S/A
	18	17140-1	1	Spring - Refer to specific parts list
	18a	17141-10	1	Spring - Refer to specific parts list
	18b	17142-1	1	Spring - Refer to specific parts list
	19	74600-614	1	Pilot - Refer to specific parts list
	19a	74600-620	1	Pilot - Refer to specific parts list
	20	74600-104	1	Thrust Bearing
	21	16241-D916	1	Bearing Race
	22	16032-510	6	Cap Screws, 5/16-18, 25,4 mm [1 in.] Long - Refer to specific parts list
	22a	16032-514	4	Cap Screws, 5/16-18, 38,1 mm [1.5 in.] Long - Refer to specific parts list
+~	23	16077-26	1	Retaining Ring
	24	74600-103	A/R	Trust Race
	25	24500-628	1	Key - 74624-204, 74644-210 & 74644-215
~	26	16078-16	2	Retaining Ring
	27	16241-1625	1	Thrust Bearing
	28	16241-C1625	2	Bearing Race
~	29	16232-16	1	Shaft Seal
~	30	16048-336	1	Washer
~	• •	16077-26	1	Retaining Ring
	32	16032-520	2	Cap Screws, 5/16-18, 50,8 mm [2 in.] Long
+~	33	16078-16	1	Retaining Ring
	34	24500-619	1	Key - Used with Shaft 74644-214 - Refer to specific parts list
	34a	16246-430	1	Key - Used with Shaft 74644-209 & 74644-210 - Refer to specific parts list
	35	16103-106	1	Plug S/A
	35-1	16133-6	1	O-ring, 1,98 mm Dia. x 11,89 mm ID. [.078 in. Dia. x .468 in. ID.]
	36	16048-616	A/R	Washer
	37	74600-115	A/R	Washer
	38	74640-600	1	Spring Collar

F_T•N

Seal Repair Kit

+ 74640-904	Seal Repair Kit for 74624 rear or same side ported motor.
~ 74640-910	Seal Repair Kit for 74644 Through shaft motor.

Drive Shaft S/A - Item #1

	Part Number 74624-200	Description 15 Tooth 16/32 Spline with Snap	1k	74644-2
1b	74624-201	Ring Groove with Snap Ring, .375- 16 UNC-2B Thread, 18.3 [.72] Min Full Thread, Shaft Ext 39.6 [1.56] 15 Tooth 16/32 Spline with Snap		
		Ring Groove, Shaft Ext 46 [1.81]		
1c	74624-202	Taper 1:8, Dia 25.4 [1.00], Woodruff Keyway Dia 25.4 [1.00] X 6.35 [.250], .625-18 UNC-2A Thread, Shaft Ext 69 [2.72]	11	74644-2
1d	74624-203	13 Tooth 16/32 Spline, Shaft Ext 41.1[1.62]		
1e	74624-204	Straight Shaft , Dia. 25,4 [1.00], Keyway 6,35 x 38,1 [.250 x 1.50], Shaft Ext. 63,5 [2.50]		
1f	74624-206	15 Tooth 16/32 Spline Tapered 1:8 with .375-16 UNC-2B Thread, 18.3 [.72] Min Full Thread, Shaft Ext 46 [1.81]	1m	74644-2
	gh Shaft (74644)			
Item # 1g	Part Number 74644-206	Description Front - 15 Tooth 16/32 Spline with		
iy	74044-200	Snap Ring Groove with Snap Ring, .375-16 UNC-2B Thread, 18.3 [.72]		
		Min Full Thread, Shaft Ext 39.6		plate \$
		[1.56]	Item # 2a	Part Nu 74624-3
		Rear - 15 Tooth 16/32 Spline, Shaft Length From Mounting Flange 258.6		
		[10.18]	2b	74624-3
1h	74644-209	Front - 15 Tooth 16/32 Spline Tapered 1:8 with .375-16 UNC-2B Thread, 18.3 [.72] Min Full Thread,	2c	74624-3
		Shaft Ext 46 [1.81] Rear - Straight Shaft Dia 25.4 [1.00], Keyway 6.3 X 25.4 [.250 X	2d	74624-3
		1.00], Shaft Length from Mounting	Housir	ng for Thr
1i	74644-210	Flange 274.3 [10.80] Front - Straight Shaft , Dia. 25,4		Part Nu
		[1.00], Keyway 6,35 x 38,1 [.250 x 1.50], Shaft Ext. 63,5 [2.50] (Key Included)	2e	74644-3
		Rear - Straight Shaft Dia 25.4		sing S/
		[1.00], Keyway 6.3 X 25.4 [.250 X 1.00], Shaft Length from Mounting	Item # 3a	Part Nui 74624-3
		Flange 274.3 [10.80]	3b	74624-3
1j	74644-212	Front - 15 Tooth 16/32 Spline Tapered 1:8 with .375-16 UNC-2B Thread, 18.3 [.72] Min Full Thread, Shaft Ext 46 [1.81]	3c	74624-3
		Rear - 15 Tooth 16/32 Spline, with .375-16 UNC-2B Thread, 18.3 [.72] Min Full Thread, Shaft Length from		
		Mounting Flange 274.3 [10.80]		



214	Front - 15 Tooth 16/32 Spline, Shaft Ext 46 [1.81]
	Rear - Straight Shaft Dia 22.22
	[.875], Keyway 6.35 X 26.9 [.250 X
	1.06], Shaft Length from Mounting
	Flange 271.5 [10.69] (Short Key Included)
215	Front - Taper .125:1 Dia 22.22
	[.875], Woodruff Keyway Dia 15.75
	[.620] X 3.96 [.156], .500-20 UNF-
	2A Thread, Shaft Ext 57.9 [2.28]
	Rear - Straight Shaft Dia 25.4
	[1.00], Keyway 6.35 X 38.4 [.250 X
	1.51], Shaft Length from Mounting
	Flange 292.1 [11.50]
216	Front - Taper .125:1 Dia 22.22
	[.875], Woodruff Keyway Dia 15.75
	[.620] X 3.96 [.156], .500-20 UNF-
	2A Thread, Shaft Ext 57.9 [2.28]
	Rear - Straight Shaft Dia 25.4
	[1.00], Shaft Length from Mounting
	Flange 254 [10.00], Shaft End Hole
	Internal 6.40 [.252] X 14 [.55] Deep

Backplate S/A - Item #2

Item #	Part Number	Description
2a	74624-301	Rear porting, through drain into mounting flange
2b	74624-305	Rear porting, drain port Horizontal top rear of unit
2c	74624-315	Same side porting, drain port vertical top rear of unit, two mounting holes bottom rear
2d	74624-317	Same side porting, drain port vertical top rear of unit

Housing for Through Shaft (74644)


Item #	Part Number	Description
2e	74644-308	Same side porting, drain port
		vertical top rear of unit

Housing S/A - Item #3

Item #	Part Number	Description
3a	74624-303	Through drain into mounting flange
3b	74624-307	No drain in housing
3c	74624-309	Special housing used with item 18
		#17141-10 and item 19 #74600-
		620. Also has slotted 2 bolt B flange.



Parts Drawing




Specific Parts List

						Pr	oduct	Numbe	rs 746	24				
		- DAA	- DAB	- DAD	- DAE	- DAG	- DAH	- DAJ	- DAL	- DAM	- DAN	- DAP	- DAR	- DAS
Item	1	1a	1b	1c	1d	1d	1e	1a	1e	1f	1f	1b	1b	1f
#'s	2	2a	2b	2b	2b	2b	2b	2b	2c	2c	2d	2b	2b	2d
	3	3a	3b	3b	3c	3b	3b	3b	3b	3b	3b	3b	3b	3b
	4	4	4	4	4	4	4	4	4	4	4	4	4a	4
	5	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	6	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	7	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	8	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	9	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	10	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	11	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	12	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	13	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	14	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	15		Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	16	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	17	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	18	18	18b	18b	18a	18b	18b	18b	18b	18	18	18b	18b	
	19	19	19	19	19a	19	19	19	19	19a	19a	19	19	
	20	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	21	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	22	22	22	22	22	22	22	22	22a	22a	22a	22	22	22a
	23		Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х	Х
	24	X	Х	Х		Х	Х	Х	Х	Х	Х	Х	Х	Х
	25						Х		Х					<u> </u>
	32								Х	Х	Х			Х
	33	Х						Х						<u> </u>
	36									Х	Х			<u> </u>
	37									Х	Х			
	38				Х					Х	Х			<u> </u>
Seal Re 726	epair Kit 640	-904	-904	-904	-904	-904	-904	-904	-904	-904	-904	-904	-904	-904



Parts Drawing - Through Shaft



Specific Parts List

				Pr	oduct	Numbe	rs 746	44		
		- DAE	- DAG	- DAJ	- DAK	- DAM	- DAN	- DAP	- DAR	- DAS
Item	1	1g	1h	1i	1j	1k	11	1m	1j	1j
#'s	2	2e	2e	2e	2e	2e	2e	2e	2e	2e
	3	3b	3a	3b	3a	3b	3b	3b	3a	3b
	4	4	4	4	4	4	4	4	4	4
	5	Х	Х	Х	Х	Х	Х	Х	Х	Х
	6	Х	Х	Х	Х	Х	Х	Х	Х	Х
	7	Х	Х	Х	Х	Х	Х	Х	Х	Х
	8	Х	Х	Х	Х	Х	Х	Х	Х	Х
	9	Х	Х	Х	Х	Х	Х	Х	Х	Х
	10	Х	Х	Х	Х	Х	Х	Х	Х	Х
	11	Х	Х	Х	Х	Х	Х	Х	Х	Х
	12	Х	Х	Х	Х	Х	Х	Х	Х	Х
	13	Х	Х	Х	Х	Х	Х	Х	Х	Х
	14	Х	Х	Х	Х	Х	Х	Х	Х	Х
	15	Х		Х		Х	Х	Х		Х
	16	Х	Х	Х	Х	Х	Х	Х	Х	Х
	17	Х	Х	Х	Х	Х	Х	Х	Х	Х
	18	18	18	18	18	18	18	18	18	18
	19	19	19a	19	19a	19a	19	19	19a	19a
	22	22a	22a	22a	22a	22a	22a	22a	22a	22a
	23	Х		Х			Х	Х		Х
	25			Х						
	26	Х	Х	Х	Х	Х	Х	Х	Х	Х
	27	Х	Х	Х	Х	Х	Х	Х	Х	Х
	28	Х	Х	Х	Х	Х	Х	Х	Х	Х
	29	Х	Х	Х	Х	Х	Х	Х	Х	Х
	30	Х	Х	Х	Х	Х	Х	Х	Х	Х
	31	Х	Х	Х	Х	Х	Х	Х	Х	Х
	32	Х	Х	Х	Х	Х	Х	Х	Х	Х
	33	Х								
	34		34	34		34a				
	35		Х		Х				Х	
	36		Х		Х	Х			Х	
	37		Х		Х	Х			Х	
	38	Х	Х	Х	Х	Х	Х	Х	Х	Х
	epair Kit 540	-910	-910	-910	-910	-910	-910	-910	-910	-910

Notes



Notes



Eaton Corporation Hydraulics Division 15151 Hwy. 5 Eden Prairie, MN 55344 Telephone: 612/937-7254 Fax: 612/937-7130

Sumitomo Eaton Hydraulic Company Ltd. Ooi-Cho Kameoka-Shi 621-0017 Kyoto Japan Telephone: [+81] 771-22-9601 Fax: [+81] 771-29-2020 Eaton Ltd. **Hydraulics Division** Glenrothes, Fife Scotland, KY7 4NW Telephone: [+44] (0)1592-771-771 Fax: [+44] (0)1592-773-184

Eaton Ltd. 7th Floor, Woo Duk Building 832-2 Yeoksam-Dong, Kangnam-Ku Soeul 135-750 Korea Telephone: [+82] 2-557-0595 Fax: [+82] 2-557-1634

Eaton B.V. Boeing Avenue 11 1119 PC Schiphol-Rijk The Netherlands Telephone: [+31] (0)20-655 6776 Fax: [+31] (0)20-655 6800

Eaton Hydraulics (Shanghai) Co. Ltd. 388 Aidu Road, Waigaogiao FTZ Pudong New Area Shanghai 200137 Peoples Republic of China Telephone: [+86] 21-5046 0758 Fax: [+86] 21-5046 0767 Sumitomo Eaton Hydraulic Co. 8 Temasek Blvd. 42-01 Suntec Tower Three Singapore 03988 Telephone: [+65] 832-7727 Fax: [+65] 832-7733

Jining Eaton Hydraulic Co. Ltd. 6 Ji Da Road Jining City Shandong Province 272131 Peoples Republic of China Telephone: [+86] 537-2221288 Fax: [+86] 537-2221557




Qualitiy System Certified Products in this catalog are manufactured in an ISO-9001-certified site.

www.eatonhydraulics.com

Form No. 06-161 May, 1999 Copyright Eaton Corporation, 1999 All Rights Reserved Printed in USA





THIS DRAWING REPRESENTS A GENERAL ASEMBLY ALIGNMENT. CONSULT PARTS LIST FOR EXACT PARTS AND QUANTITIES FOR EACH BRAKE

GEAR REDUCER

TEM	PART NAME		RAKE 5800		RAKE 5805		RAKE 5815		RAKE 5820		RAKE 5825		RAKE 6470	FIG
=		REO	PART	REO	PART	REQ	PART A	REO	PARI #	REO	PART	REO	PART	SPRING OR
1	HOUSING	1	75821	1	75822	1	75822	1	75822	1	75822	1	75822	
2	GASKET	1	75093	1	75093	1	75093	1	75093	1	75093	1	75093	D° a
3	TORQUE PIN	2	37914	2	35875	2	35875	2	35875	2	35875	2	35875	000
4	BEARING - BALL	1	34574	1	34574	1	34574	1	34574	1	34574	1	34574	
5	RETAINING RING	1	75540	1	75540	1	75540	1	75540	1	75540	1	75540	
	SEAL	1	37144	1	37144	1	37144	1	37144	1	37144	1	37144	
7	SPRING RETAINER	1	74554	1	74554	1	74554	1	74554	1	74554	1	74554	
8	COMPRESSION SPRING	7	28962	5	28962	9	28962	9	28962	9	28962	7	28962	
9	COMPRESSION SPRING	8	28963	5	28963	8	28963	8	28963	10	28963	7	28963	a convert analy from the
	SHAFT	1	74577	1	74579	1	74579	1	75124	1	74579	1	74579	7 SPRINGS 28962 (SMALL) B SPRINGS 28963 (LARCE)
11	PRIMARY DISC	1	74553	1	74553	1	74553	1	74553	1	74553	1	74553	75800
12	ROTATING DISC	2	74771	4	74771	4	74771	4	74771	4	74771	4	74771	
13	WAVE SPRING	4	75672	8	75672	8	75672	8	75672	8	75672	8	75672	
14	STATIONARY DISC	2	74552	4	74552	4	74552	4	74552	4	74552	4	74552	
	PISTON	1	75104	1	75109	1	75109	1	75109	1	75109	1	75109	000
16	BACKUP RING	1	27967	1	27967	1	27967	1	27967	1	27967	1	27967	
	O-RING	1	27808	1	27808	1	27808	1	27808	1	27808	1	27808	
	BACKUP RING	1	27966	1	27966	1	27966	1	27966	1	27966	1	27966	
	0-RING	1	27777	1	27777	1	27777	1	27777	1	27777	1	27777	0.00
	BLEEDER SCREW	1	29035	1	29035	1	29035	1	29035	1	29035	1	29035	00
	POWER PLATE	1	75499	1	75499	1	75499	1	75499	1	75499	1	75499	
	PROTECTIVE PLUG	1	28435	1	28435	1	28435	1	28435	1	28435	1	28435	9 SPRINGS 28962 (SMALL)
- Colores	WASHER	4	74877	4	74877	4	74877	4	74877	4	74877	4	74877	8 SPRINGS 28963 (LARGE) 75820
	1/2-13 BOLT	4	73594	4	73594	4	73594	4	73594	4	73594	4	73594	1 3620
	GASKET	2	28426	2	28426	2	28426	2	28426	2	28426	2	28426	

FIG. 2 SPRING ORIENTATION





9 SPRINGS 28962 (SWALL) 10 SPRINGS 28963 (LARGE) 75825

5 SPRINGS 28962 (SMALL) 5 SPRINGS 28963 (LARCE) 75805

9 SPRINCS 28962 (SMALL) 8 SPRINCS 28963 (LARCE) 75815

1



7 SPRINCS 28952 (SMALL) 7 SPRINCS 28953 (LARGE) 76470 F76060 FCO#10969

THE NEXT GENERATION MULTI-DISC DRY B MOUNT BRAKE 75800 75805 75815 75820 75825 76470

BRAKE FUNCTION

**All the following procedures refer to the drawing on the next page.

The Fail-safe Brake is spring loaded to apply the brake and hydraulic pressure is required to release or "hold off" the brake. Normal operation is to have the brake pressurized in the AS released position with the vehicle hydraulic system running. Any function which reduces the hydraulic system pressure below the release pressure of the brake, will cause the brake to be Ch applied. as The brake is designed to fit with a gear reducer and a hydraulic motor. The common *A mounting surfaces of the brake gear reducer, and the motor are machined to close tolerances and should be protected from damage during installation and removal. *U 1. INSTALLATION INSTRUCTIONS Place the gasket (25) on the mounting face of the brake (face with the shaft projecting 1. 2. out). Place the brake shaft (10) into the gear reducer. 2. 3. Move the brake into position with the gear reducer maintaining proper gasket location. 3. Align the mounting bolt holes by rotating the engaged brake into position, If this is not possible, the shaft may be rotated after pressure has been applied to the brake inlet. This will release the brake and allow it to be rotated into position. Similarly, place the gasket (25) on to the flange of the motor. 4. Insert the shaft of the motor into the brake and push into position, maintaining proper 5. 4. gasket alignment. Insert two 1/2 in. dia. bolts (grade 5) and lockwashers through the motor flange, the 6. gasket (25), the brake, the brake gasket (25), and into the threaded holes in the gear reducer. Make sure that the bolts are not too long so they do not bottom out in the gear 5. reducer threaded holes before clamping. To prevent binding, run the bolts in alternately until snug. Then, torque the bolts to 75-7. 6. 85 lb-ft. NOTE: the shafts must slide together freely-DO NOT use the bolts to force the unit together. With motor and brake bolted into position, remove protective plug (22) and connect 8. 7. inlet hydraulic line (if not during step 3) Brake inlet is 1/4" tubing, straight thread oring boss (7/16-20 UNF-2B). SE BRAKE DISASSEMBLY PROCEDURE (Ref Fig 1) OTI With shaft protrusion downward, disassemble in the following order: bolts (24) 1. alternately, washers (23), power plate (21), and gasket (2). DI Remove the following parts: stationary discs (14), rotating discs (12), primary disc (11), 2. torque pins (3), springs (8 & 9), wave springs (13), and the spring retainer (7). Bu Further disassembly is not recommended and should not be attempted unless necessary St 3. to replace the bearing (4), the seal (6), or the shaft (10). If further disassembly is (). Ga

4.

- ----

needed, proceed as follows: NOTE: if the bearing and seal are removed for any reason, both must be replaced. a) The shaft (10) may be removed by pressing on the end of the shaft with a shop press. b) Using an appropriate tool, pry the seal (6) out from the inside of the brake. Take care not to damage the bore. Remove the retaining ring (5). Tap the bearing (4) out with a plastic mallet.

4. Remove the Piston (15) from the Power Plate (21) by introducing low pressure air - 15 psi - into the hydraulic inlet and make sure piston is directed away form the operator. Remove O-rings (17 & 19) and Backup Rings (16 & 18) from the piston OD and ID grooves. Do not remove backup rings (16 & 18) unless replacement is necessary because they will be damaged.

ASSEMBLY PROCEDURE

- - 1

<u>IMPORTANT</u>: There may be more parts in a service kit than your brake requires. Check the parts list carefully for the exact quantity. In the case of springs, space the springs as seen on Figure 2.

*All parts must be thoroughly clean prior to reassembly.

*Use the reverse of the disassembly procedure with the following notes and additions:

- Worn O-rings and damaged or worn Teflon backup rings must be replaced prior to reassembly.
- Cylinder of the power plate, piston, and o-rings must be clean prior to assembly and pre-lubed with the system hydraulic fluid.
- 3. Assemble piston (15) into power plate (21) using a shop press, being careful not to damage the o-rings or Teflon back-up rings. Visually align the center of the cutouts in the piston with the torque pins (3) holes in the power plate (21). CAUTION: the depth the piston is installed into the power plate is critical. The surface of the piston at the cutouts must be flush to 0.120 in. below the surface of the power plate. DO NOT exceed the 0.120 depth or piston will cock resulting in a complete loss of braking.
- Replacement of seal (6): a)Use a shop press to press the bearing (4) into the housing. Press on the outer race of the bearing only. Install retaining ring (5) into groove.
 b)Press the seal (6) into the housing (1) until it is flush with the face of the housing. The lip of the seal must face towards the bearing.
- Press the shaft into the housing until it stops on the bearing. Support inner race of the bearing during press.
- Rotating discs must be clean and dry. The lining material and mating surfaces of the stationary discs must be thoroughly clean and free of debris. Worn or scored rotating discs must be replace.
- 7. Install bolts (24) with washers (23) in power plate (21). Tighten sequentially, one turn at a time, until power plate is properly seated. Torque to 105-115 lb-ft.

<u>SERVICE KITS</u> The following kits are available as service items. All other parts may be ordered individually.

Τ	ITEM	PART	DESCRIPTION	QTY
Ī	1	78362	HOUSING	1
Ī	2	35875	, TORQUE PIN	2
Ì	3	74553	PRIMARY DISC	1
Ī	4	74552	STATIONARY DISC	4
Î	5	74771	ROTATING DISC	4
Ī	6	27966	BACKUP RING	1
Ī	7	27777	O-RING	1
Ì	8	75109	PISTON	1
	9	78361	POWER PLATE	1
	10	27808	0-RING	1
	11	27967	BACKUP RING	1
	12	75093	GASKET	1
	13	28962	COMPRESSION SPRING	9
	14	28963	COMPRESSION SPRING	8
ľ	15	74554	SPRING RETAINER	1
Ì	16	37144	LIP SEAL	1
	17	74579	SHAFT	1
	18	75540	SNAP RING	1
1	19	34574	BALL BEARING	1
	20	28426	GASKET	2
	21	28435	PROTECTIVE PLUG	1
	22	73594	1/2-13 HEX HEAD BOLT	4
Ì	23	74877	WASHER	4
	24	29035	BLEEDER SCREW	1

MOBILE EQUIPMENT AND WIND ENERGY SOLUTIONS

INDUSTRY PROCESS AND AUTOMATION SOLUTIONS



Installation, use and service manual



010101001110101010101001101111 01010010101011101010 1001010101110







GO BONFIGL



USE, INSTALLATION AND MAINTENANCE MANUAL

1.0 - GENERAL INFORMATION	2
1.1 - PURPOSE OF THE MANUAL	
1.2 - PRODUCT IDENTIFICATION	
1.3 - GLOSSARY AND TERMINOLOGY	4
1.4 - REQUESTING TECHNICAL ASSISTANCE	4
1.5 - MANUFACTURER'S LIABILITY	4
1.6 - CONSIGNMENT CONDITIONS	
2.0 - TECHNICAL INFORMATION	5
2.1 - DESCRIPTION OF THE GEAR UNIT	
2.2 - CONFORMITY	
2.3 - OPERATING LIMITS AND CONDITIONS	
3.0 - SAFETY INFORMATION	6
3.1 - SAFETY STANDARDS	
4.0 - HANDLING AND TRANSPORT	7
4.1 - PACKAGING	
4.2 - HANDLING INSTRUCTIONS	
4.2.1 - Moving the packages	
4.2.2 - Moving the equipment	
4.3 - STORAGE	
5.0 - INSTALLATION	15
5.1 - INSTALLING THE GEAR UNIT	
5.1.1 - Flanged execution	
5.1.2 - Foot mounting	
5.1.3 - Shaft mounting	
5.1.4 - Installing accessories on solid input and output shafts	
5.2 - INSTALLING THE ELECTRIC MOTOR	
5.3 - INSTALLING THE HYDRAULIC MOTOR	
5.4 - CONNECTING THE HYDRAULIC BRAKE	
5.5 - LUBRICATION	
6.0 - TESTING THE GEAR UNIT	29
7.0 - USING THE EQUIPMENT	29
8.0 - MAINTENANCE	30
8.1 - ROUTINE MAINTENANCE	
8.2 - OIL CHANGES	
8.3 - CHECKING OPERATIONAL EFFICIENCY	
8.4 - CLEANING	
9.0 - REPLACING PARTS	33
9.1 - REMOVING THE MOTOR	
9.1 - REMOVING THE MOTOR 9.2 - DECOMMISSIONING THE GEAR UNIT	
10.0 - TROUBLESHOOTING	34
ANNEX 1 - CHECKING THE OIL LEVEL ON ATEX-SPECIFIED GEAR UNITS	35
ANNEX 2 - LUBRICANT CHARGE QUANTITY	36

Revisions

The catalogue revision list is given on page 38. The most recent versions of the catalogue are available at www.bonfiglioli.com.



1.0 - GENERAL INFORMATION

1.1 - PURPOSE OF THE MANUAL

This Manufacturer's manual provides information regarding the safe transport, handling, installation, maintenance, repair, disassembly and dismantling of the gear unit.

All information for users and designers is given in the Sales Catalogue. As well as adhering to established engineering practices, the information given in this manual must be read carefully and rigorously applied.

Failure to observe the information provided herein may result in risks to personal health and safety, as well as economic damages.

This information, provided in the Manufacturer's original language (Italian), is also available in other languages to meet legal and commercial requirements.

The documentation must be stored by a person charged to do so in a suitable location so as to be always available in good condition for consultation.

In case of loss or damage, replacement documentation must be requested directly from the Manufacturer, quoting the code of this manual.

This manual reflects the state of the art at the time of commercialisation of the gear unit.

The Manufacturer reserves the right to modify, supplement and improve the manual, without the present publication being for that reason considered inadequate.

Particularly significant sections of the manual and important specifications are highlighted by symbols whose meanings are explained below.

SYMBOLS:



DANGER - WARNING

This symbol indicates situations of danger, which if ignored, may result in serious injury to the operator.



CAUTION - ATTENTION

This symbol indicates the need to adopt specific precautions to avoid personal injury and damage, as well as economic damages.



IMPORTANT

This symbol indicates important technical information.



Instructions marked by these symbols and highlighted in yellow, apply exclusively to equipment complying with "ATEX" Directive 94/9/EC.

The operations identified by these symbols must be executed by professionally qualified operators specially trained in the safety precautions required for working in potentially explosive atmospheres.

Failure to observe these instructions may result in serious safety and environmental risks.





1.2 - PRODUCT IDENTIFICATION

The information identifying the product is shown on its nameplate. Gearmotors are equipped with two nameplates; one on the gear unit which bears the gear unit data, and one on the motor (electric or hydraulic), bearing the motor data.

The drawing below illustrates the layout of the data.


The gear unit's identifying code is explained in the Sales Catalogue. If the gear unit is supplied fitted with an electric motor (gearmotor), all information regarding the motor is supplied in the motor manual.

Nameplate data

	ONFIGLIOLI TRASMITAL	ଔହ	BONFIG	LIOLI
TY	PE			
В				
C				
RATIO 1/	D	SERIAL N°		
DRWG. N°	6		DATE G	
COD. N°	8		MADE	IN ITALY

- A Manufacturer
- B Product identification
- C Bonfiglioli Trasmital product code
- D Reduction ratio
- E Serial number
- F Installation drawing code.
- G Date of manufacture
- Client product code

Supplementary nameplate on ATEX-specified gear units



Readability of the nameplate

The nameplate and the information on it must be readable and, consequently must be cleaned from time to time.

Quote the nameplate data in all communications with the manufacturer, for example, when requesting spare parts, information and assistance.



1.3 - GLOSSARY AND TERMINOLOGY

Some of the frequently occurring terms used in this manual are described below to unequivocally define their meaning.

Routine maintenance

The set of operations required to preserve the functionality and efficiency of the gear unit. These operations are usually scheduled by the Manufacturer, who defines the qualifications and tasks involved.

Reactive maintenance

The set of operations required to preserve the functionality and efficiency of the gear unit. These operations are not scheduled by the Manufacturer and must be carried out by an expert maintenance technician.

Expert maintenance technician

An authorised technician with the qualifications, skills and mechanical and electrical training required to do repairs and non-routine maintenance work on the gear unit.

Overhaul

An overhaul consists in the replacement of bearings and other mechanical components which have worn to such an extent as to compromise the operation of the gear unit. An overhaul also includes verification of the condition of all gear unit components (keys, seals, gaskets, vents, etc). If any such components are damaged they must be replaced and the reason for the damage identified.

1.4 - REQUESTING TECHNICAL ASSISTANCE

For any technical service needs, contact the Manufacturer's sales network quoting the information indicated on the unit's nameplate, the approximate hours of service and the type of defect.

1.5 - MANUFACTURER'S LIABILITY

The Manufacturer declines all liability in the event of:

- use of the gear unit in contravention of local safety at work legislation
- incorrect installation, disregard or incorrect application of the instructions provided in this manual
- incorrect or defective electrical/hydraulic power supply (gearmotors)
- modifications or tampering
- work done on the unit by unqualified or unsuitable persons.

The safety of the gear unit also depends on scrupulous observance of the instructions given in this manual, and in particular:

- · always operate the unit within its operating limits
- · diligently observe the routine maintenance schedule
- · only allow trained operators to inspect and service the unit
- only use original spare parts
 - the configurations given in the gear unit catalogue are the only ones permitted
 - do not attempt to use the unit in any other way
 - the instructions given in this manual do not substitute but rather supplement the provisions of established safety legislation.

1.6 - CONSIGNMENT CONDITIONS

Gear units are supplied by BONFIGLIOLI TRASMITAL in the following conditions:

- Configured for installation in the mounting position specified in the purchase order.
- Not charged with lubricant and with internal components protected by a film of oil compatible with the recommended lubricant.
- All surfaces and mating parts are treated with rustproofing products.
- Mating surfaces are not painted while the unit's exterior is treated with a coat of grey water-based rustproofing primer (RAL 7042/C441). Application of a top coat is the responsibility of the Client.
- Tested to factory standards.
- Packaged suitably for the final destination.



2.0 - TECHNICAL INFORMATION

2.1 - DESCRIPTION OF THE GEAR UNIT

The gear unit, driven by an electric or hydraulic motor, has been designed and constructed for integration into an assembly of interlocking parts or mechanisms as part of a specific application.


Depending on the requirements of the application, the gear unit can be supplied in a variety of motor executions and configurations. It is capable of satisfying a range of specific requirements in the mechanical, chemical, agricultural and food industries, etc.

BONFIGLIOLI TRASMITAL supplies a range of accessories and optionals to make their products as versatile as possible. For further technical information and descriptions, refer to the corresponding Sales Catalogue.

The User is responsible for using the products recommended for installation and maintenance of

SAFETY SPECIFICATIONS OF GEAR UNITS COMPLYING WITH DIRECTIVE 94/9/EC

- unit selection must be made with a higher safety service factor
- use only synthetic lubricants (oil and grease)
- VITON[®] seal rings



- oil plugs with aluminium washer
- oil seals with dust trap
- no metal moving parts external to the gear unit
- no plastic parts capable of building up an electrostatic charge, or, if present, duly shielded
- for installations in zones 21 and 22 the User must schedule and implement a regular cleaning programme for all surfaces and recesses to avoid dust build ups of more than 5 mm in depth.

2.2 - CONFORMITY

All gear units or gearmotors (when supplied with electric motor) are designed in compliance with the provisions of applicable Essential Health and Safety Requirements, the "Machinery Directive" 98/37/EC and, if requested, can be supplied with a Manufacturer's Declaration - Annex IIB as provided by said Directive. All BONFIGLIOLI gearmotor electric motors conform to the provisions of the Low Voltage Directive 73/23/EEC and the Electromagnetic Compatibility Directive 89/336/EEC.



Furthermore, if specified for use in potentially explosive atmospheres, the gear units are designed and constructed to conform with the Essential Health and Safety Requirements (EHSR) of Annex II of the ATEX Directive 94/9/EC and conform to the following classification:

- Equipment group: II.
- Category: Gas 2G Dust 2D.
- Zone: Gas 1 Dust 21.
- Maximum surface temperature: temperature class T4 for 2G and 130°C for 2D.

2.3 - OPERATING LIMITS AND CONDITIONS



Modification of the motor execution or mounting position is only permitted if previously authorised by BONFIGLIOLI TRASMITAL's Technical Service.

Failure to obtain said authorisation renders the ATEX certification null and void.



Ambient conditions

- Ambient temperature: min. 20°C; max. + 40°C.
- Do not use the gear unit, if not explicitly intended for the purpose, in a potentially explosive atmosphere or where the use of explosion-proof equipment is specified.



The nameplate specifications regarding the maximum surface temperature, refer to readings taken in normal ambient and installation conditions.

Even minimal variations to said conditions (e.g. smaller mounting cabinet) may have a significant effect on the unit's heat output.

Lighting

 Δ If the unit is to be serviced in a poorly lit area, use additional lamps and ensure that the work is done in compliance with the safety requirements of established legislation.

3.0 - SAFETY INFORMATION

3.1 - SAFETY STANDARDS

- Carefully read the instructions given in this manual and those posted directly on the gear unit, especially those regarding safety.
- Persons charged with working on the gear unit at any time in its service life must be trained specifically for the purpose with special abilities and experience in the area as well as being equipped with the appropriate tools and individual safety equipment (as per Legislative Decree 626/94). Failure to meet these requirements constitutes a risk to personal health and safety.
- The gear unit must only be used for the applications permitted by the Manufacturer. Improper use can result in risks to personal health and safety and economic damages.



The applications permitted by the Manufacturer are the industrial applications for which the gear units have been designed.

- Keep the gear unit at its maximum efficiency by following the routine maintenance schedule. Good maintenance ensures the unit's maximum performance, extended service life and continued compliance with safety regulations.
- When working on the unit in areas which are difficult to access or hazardous, ensure that adequate safety precautions have been taken for the operator and others in compliance with established legislation on health and safety at work.
- All maintenance, inspection and repairs must only be carried out by an expert maintenance technician fully familiar with the attendant hazards. It is therefore essential to implement operating procedures that address potential hazards and their prevention for the entire machine. The expert maintenance technician must always work with caution in observance of applicable safety standards.
- During operation wear only the apparel and safety equipment indicated in the User Instructions provided by the Manufacturer or stipulated by legislation on safety at work.
- Replace worn components with original spare parts. Use the lubricants (oil and grease) recommended by the Manufacturer.
- Do not dump polluting materials into the environment. Dispose of all such materials as stipulated by applicable legislation.
- After replacing lubricants clean the gear unit's surfaces and the walk-on surfaces around the work area.







If the gear unit is to be serviced in a potentially explosive atmosphere, the operator must first switch off power to the gear unit and ensure that it is out of service, as well as taking all necessary precautions against it being accidentally switched on again or its parts moving without warning.

Furthermore, all additional environmental safety precautions must be taken (e.g. elimination of residual gas or dust, etc).


4.0 - HANDLING AND TRANSPORT

4.1 - PACKAGING

The standard packaging, if supplied and unless otherwise agreed, is not proofed against rainfall and is intended for shipping by ground and not sea, and for storage in areas which are under cover and not humid. The material can be stored in suitable conditions for a period of two years under cover at a temperature between -15 °C and +50 °C at a relative humidity not in excess of 80%. Storage in all other conditions requires specific packaging.

The most frequent types of packaging are shown in the figures below.

- Packaging on pallet with heat shrink film for ground shipping.
- Packaging in wooden crate for shipping by sea or air.





On receipt of the gear unit, make sure the delivery corresponds to the purchase order and that it is not damaged or faulty in any way.

^A Report any nonconformity to your BONFIGLIOLI TRASMITAL reseller.

Dispose of packaging materials as stipulated by applicable legislation.

4.2 - HANDLING INSTRUCTIONS

Handle packages as per the Manufacturer's instructions and those marked on the packages themselves. Since the weight and shape of the packages may make manual handling unfeasible, special equipment must be used to avoid damage and injury. Persons authorised for this purpose must be trained and experienced in the work in question to avoid risks to themselves and others.



The person authorised to handle the product must take all necessary precautions to safeguard his safety and that of all other persons involved.



4.2.1 - Moving the packages

- Prepare a suitable, delimited area with a level floor or surface for unloading the packages.
- Prepare the equipment required to handle the package. The lifting and handling equipment (e.g. crane or lift truck) must be of adequate capacity for the weight and size of the load, taking into account its attachment points and centre of gravity. If required, this information is indicated on the package itself. Harness heavy packages with chains, belts and steel ropes after checking that they are suitable for the weight of the load, which is always indicated.
- When handling the load keep it level to avoid tipping and instability.

4.2.2 - Moving the equipment



All the following operations must be carried out with care and caution and without sudden movements.



When lifting, use accessories such as eyebolts, screw clamps, snap hooks, straps, ropes and hooks etc. which are certified and adequate for the load in question.

The weight of the product to be lifted is given in the Sales Catalogue.

The following pages illustrate in detail the different attachment methods for the various product series, sizes and configurations described in this Manual.

The most suitable solution for lifting and handling the product in safety is indicated for each.


Symbols:

Type of lifting	Manual	With mechanical equipment			
Symbol	М	Α	В		
Approximate weight	≤ 15 Kg	> 15	> 15 Kg		
Instruction		Recommended method for po- sitioning	Recommended method for handling and positioning		
Warning		The load may be unstable	The load may sway or oscillate		
Solution		Slide the lifting ring to align it with the load's centre of gra- vity as shown in the diagrams below Lock the ropes below the ring with a cable clamp or similar device so as to prevent them sliding, and lift the load Observe all precautions regar- ding the handling of loads	Stabilise the moving load by hand Observe all precautions regar- ding the handling of loads		

The load must not be allowed to sway by more than 15° in any direction when being lifted. If swaying exceeds this amount, stop and repeat the lifting operation as instructed.









Identify the attachment points for lifting the gear unit. Refer to the diagrams given below.













BONFIGLIOLI TRASMITAL













- Prepare the gear unit for lifting by attaching straps, hooks and screw clamps etc. to its attachment points. Alternatively, use a pallet to move the load. If using a crane, first lift the gear unit vertically out of its packaging.
- If using a lift truck or pallet truck, remove the packaging and insert the truck's forks at the indicated positions.
- First lift the load very slowly to check that it is stable.
- Move the gear unit to the unloading area and lower it gently into position, taking care not to tip it suddenly in transit.



If the gear unit is already equipped with an electric motor, do not use the eyebolts on the motor casing for lifting, unless expressly specified.

4.3 - STORAGE

The following recommendations should be followed when storing the gear unit.

- 1. Do not store the unit in excessively humid conditions or where it is exposed to the weather (do not store outdoors).
- 2. Do not place the gear unit directly on the ground.
- 3. Place the gear unit on a stable base and make sure that it is not subject to accidental displacement.
- 4. Store the packaged gear unit (if allowed) in accordance with the instructions on the packaging itself.

If the gear unit is to be stored for more than 6 months, the following **additional** precautions must be taken:

- 5. Cover all machined external surfaces with a rustproofing product such as Shell Ensis or other product with similar properties and application range.
- 6. Fill the unit with lubricating oil and make sure the vent plug is positioned uppermost. Before putting the unit into service, the oil used for storage must be drained and replaced with the correct quantity of recommended operating lubricant.

PRECAUTIONS to be taken when returning the gear unit to service after storage.
 The output shafts and external surfaces must be thoroughly cleaned of all rustproofing product, contaminants and other impurities (use a standard commercial solvent). Do this outside the explosion hazard area.
 The solvent must not touch the seal rings as this may damage them, causing them to leak
 If the oil or protective material used during storage is not compatible with the synthetic oil used during the machine's operation, the interior of the unit must be thoroughly cleaned before filling with the operating oil.

The service life of the bearing grease is reduced if the unit is stored for more than 1 year. The bearing grease must be synthetic.





5.0 - INSTALLATION

5.1 - INSTALLING THE GEAR UNIT





The entire installation process must be planned as early as the general design phase of the machine. The person authorised to do the work must, if necessary, set out a safety plan to protect the health and safety of all persons directly involved and apply all applicable legislation.

- 1. Carefully remove all packaging and protective product residue from the gear unit.
- Pay particular attention to the mating surfaces.
- 2. Check that the data on the nameplate correspond to those specified in the purchase order.
- 3. Ensure that the structure to which the gear unit is to be mounted is sufficiently robust and rigid to support its weight and operating stresses.
- 4. Check that the machine to which the gear unit is to be installed is switched off and cannot be accidentally switched on again.
- 5. Make sure all mating surfaces are flat.
- 6. Make sure the shaft/shaft or shaft/ bore are perfectly aligned for coupling.
- 7. Fit suitable guards to protect against the gear unit's external moving parts.
- 8. If the work environment is corrosive for the gear unit or any of its parts, follow the special precautions required for aggressive environments. In this case, contact the BONFIGLIOLI TRASMITAL sales service.
- 9. We recommend applying a protective paste to all gear unit/motor mating surfaces and other parts (Klüberpaste 46 MR 401 or other product with similar properties and application range) to ensure optimal coupling and protection against fretting corrosion.
- 10. In the case of outdoor installations fitted with an electric motor, protect the latter from direct sunlight and the weather by means of guards or a casing. Also make sure that the assembly is properly ventilated.

5.1.1 - Flanged execution

Machine the coupling counterflange on the machine to which the gear unit is to be installed. The flanges must be plane and machined with machine tools. Connect the output shaft to the driven component as indicated in the drawings below.






	Loose c	oupling	Coupling with interference	
	Solid shaft	Hollow shaft	Solid shaft	Hollow shaft
	Ø d h6	Ø D G7	Ø d h6	Ø D P7
	Ø d k6	Ø D F7	Ø d k6	Ø D M7
	Ø d m6	Ø D F7	Ø d m6	Ø D K7
	Ø d r6	Ø D E7	Ø d r6	Ø D H7





For machining the spigot on the driven machine, refer to the diagrams below:

300...307 gear units - male output shaft motor execution




309...321 gear units - male output shaft motor execution

These gear units are fitted with two spigots. When machining the coupling flanges, one spigot may be sufficient if the output shaft is not subject to overhung loads or loads are less than 60% of the permissible load. For heavier loads, the mounting must use both spigots on the gear unit.

If the gear unit is instead required to transmit high torque or is subject to heavy shock loads and inversions in the direction of rotation, the counterflange must be drilled to accept the spigots.

At the time of installation, move the spigots mounted on the gear unit forward into the counterflange by an amount equal to their diameter. See diagram below:








Mounting with hollow splined shaft

Ensure that the gear unit and driven shaft are aligned and that the latter is not subject to flexing during operation. See diagram below:



Flanged gear unit mounting bolts

	300	301	303	305	306	307	309	310	311	313	315	316	317	318	319	321
Bolt	M10	M10	M12	M12	M14	M16	M16	M16	M16	M20	M20	M20	M30	M24	M30	M30
Quantity	8	8	10	10	12	10	12	15	24	30	20	30	24	32	30	36
Class	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8
Tightening torque (Nm)	50	50	85	85	135	200	200	200	200	400	400	400	1400	700	1400	1400


For maximum transmitted torques greater than or equal to 70% of the torque indicated as M_{2max} , and with frequent inversions of the direction of rotation, use at least class 10.9 bolts.

5.1.2 - Foot mounting

Foot-mounted motor execution

Gear units of this type must be mounted on a suitably rigid base, machined flat with a planarity error margin of no more than 0.2 mm / 100 mm.

See diagram below:



Foot-mounted gear unit mounting bolts

	300	301	303	305	306	307	309	310	311	313	315	316	317	318	319	321
Bolt	M16	M16	M16	M16	M20	M24	M24	M24	M30	M30	M30	M36	M30	M36	M48	M48
Quantity	4	4	4	4	4	4	4	4	4	4	8	8	8	8	4	8
Class	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8	8.8
Tightening torque (Nm)	200	200	200	200	400	700	700	700	1400	1400	1400	2500	1400	2500	6000	6000






5.1.3 - Shaft mounting

Mount the torque arm with bolts of at least class 8.8 tightened to a torque of 70% of their failure stress. Clean and degrease both the internal coupling surface of the gear unit shaft and the external coupling surface of the machine's driven shaft.


Mount the shrink disk to the gear unit's shaft after lightly lubricating its entire **outer surface**. Snug down a first set of 3 bolts located at the corners of an equilateral triangle (for example: bolts in pos. 1-5-9 of the diagram below). Fit the gear unit to the driven shaft.

Tighten down the bolts (following the triangular pattern) in a circular direction, repeating the operation several times until all bolts are tightened to the torque specified in chart 2, in accordance with the type of disk/gear unit.

N.B.: Do not tighten down diametrically opposed bolts in sequence.



Do not use molybdenum bisulphide or any other grease, which could reduce the friction of the mating surfaces and affect the performance of the shrink disk.



Shrink disk mounting bolts

	300	301	303	305	306	307	309	310	311	313	315	316	317	318	319	321
Bolt	M6	M6	M8	M8	M10	M10	M16	M16	M16	M16	M20	M20	M20	M20	M20	M24
Quantity	8	10	12	12	9	12	8	8	10	10	12	15	18	21	24	21
Class	10.9	10.9	10.9	10.9	10.9	10.9	10.9	10.9	10.9	10.9	10.9	10.9	10.9	10.9	10.9	10.9
Tightening torque (Nm)	12	12	30	30	58	58	250	250	250	250	490	490	490	490	490	840





Proceed with the installation as follows:

- 1. Place the gear unit in the vicinity of the installation area.
- 2. Mount the gear unit and secure it to the structure at the points provided. The gear unit should be secured to the structure at all the mounting points (bores) on the mount provided (feet or flange).
- 3. Tighten down the mounting bolts and check that the service plugs are screwed down to the torques given in the chart.




Locate the closed oil plug used during shipping and replace it with the vent plug supplied in the shipment.

5.1.4 - Installing accessories on solid input and output shafts





Do not use hammers or other tools that might damage the gear unit's shafts or bearings when mounting external parts. Instead, proceed as illustrated in the diagram below:



Bolt (1) and spacer (2) are not included in the consignment.

To minimise the loads on the shaft bearings, when mounting transmission mechanisms with asymmetrical hubs use the configuration shown in diagram (A) below:






Mounting pulleys


Clean all parts before installing them. When installing belt drive pulleys, the shafts must be parallel with their pulleys aligned.


Do not over tension the drive belt as this can damage the bearings.







Shaft end: threads









	300	301	303	305	306	307	309	310	311	313	315	316	317	318	319	321
MC	M12	M12	M20	M20	M20	M20	_	_	_	-	-	-	-	-	_	-
HC	M16	M16	M20	M20	M20	M20	M24	M24	M24	M24	M24	-	-	-	_	-
PC	M12	M16	M20	M20	M20	M20	M24	M24	M24	M24	M24	-	-	-	_	-
VK	_	_	M20	M20	M24	M24	M24	M24	M24	M30	M30	-	-	-	_	-






Installing accessories on splined shafts



Do not use hammers or other tools that might damage the gear unit's shafts or bearings when mounting external parts. Instead, proceed as illustrated in the diagram below:




Always use the stop end plate supplied with the gear unit.

5.2 - INSTALLING THE ELECTRIC MOTOR

Further to all the precautions indicated above, when installing a standard IEC 72-1 electric motor, the following precautions must also be observed:

- Do not force the coupling and do not use inappropriate tools during assembly. Take care not to damage the flat/cylindrical coupling surfaces.
- Do not force the rotary coupling mechanisms with heavy overhung or thrust loads.
- To facilitate assembly, use a lubricating synthetic oil paste such as Klüberpaste 46 MR 401 or another product with similar properties and application range.



 Provided all the above checks have been performed and passed and all other instructions in this manual have been strictly observed, an electric motor with ATEX rating equal to or greater than that of the gear unit may be installed, thus forming a gearmotor which itself complies with the provisions of Directive 94/9/EC.

If, instead, the assembly of the motor to the gear unit requires actions other than those prescribed in this Manual or one or more of the manual's prescriptions have not been satisfied, the User shall be responsible for analysing the risks attendant on this particular motor/gear unit combination. The risk analysis is in any case obligatory if the motor is powered by an inverter.

Only in this way, and subject to self-certification by the assembler, shall the assembly, including the gear unit itself, be compliant with the requirements of Directive 94/9/EC.




5.3 - INSTALLING THE HYDRAULIC MOTOR

Connecting the hydraulic motor

Remove the protective plug. Hydraulic motor mountings are available in two versions:

a) Version with O-ring oil gasket between motor flange and gear unit.

In this case, mount the gasket to ensure an oil tight seal between the motor and gear unit, taking care to fit it correctly in its seat without damaging it.




b) Version with gasket already mounted to the coupling.

In this case no special intervention is required to ensure an oil tight seal since this is already provided by the motor coupling. Merely smear the motor shaft with grease.

In both cases, clean the spigot and the coupling where the motor is to be fitted, fit the motor and tighten down the flange mounting bolts.

Always use bolts rated to at least class 8.8.








5.4 - CONNECTING THE HYDRAULIC BRAKE

On gear units designed for coupling to hydraulic motors and fitted with a brake, connect the brake control fitting to the hydraulic circuit at the time of assembly.

Start-up

The minimum pressure to release the brake (see chart) must be less than 320 bar.



Technical data

	Brake		4					5					6						
Characteristics		Α	в	D	F	н	κ	L	в	С	Е	G	κ	в	с	Е	G	κ	L
Braking torque	M _{bs} [daNm]	5	10	16	26	33	40	44	40	50	63	80	100	85	110	150	210	260	320
Minimum release pressure	bar	10	20	30	20	25	30	33	20	27	20	25	32	14	19	25	19	24	28
Max. pressure	bar									32	20								
Weight	kg				10						18					3	5		

NOTE: The static torque M_{bs} is the maximum torque the brake can exert.

Under dynamic loads the braking torque is reduced. The actual $M_{\rm bs}$ values can vary from -5% to +15% of the rating given in the chart.






Installing the gearmotor

If a gearmotor is supplied fully assembled, follow the precautions and instructions given above when mounting to the machine.

For the electrical and hydraulic connection, refer instead to the two sample diagrams below. These are generic only since each specific installation has its own special requirements, which must be evaluated on a per case basis by the Manufacturer.

Drive with electric motor.







Drive with TRASMITAL MG orbital hydraulic motor

In addition to the instructions governing installation of the gear unit, the following instructions should also be observed when installing a hydraulic motor.


a) Connecting to the hydraulic circuit

The motor can be installed on both a closed and open loop circuit.

In the case of an open circuit installation, the solenoid valve or control valve may be of either the closed centre or open type.


The circuit line corresponding to the hydraulic motor delivery port must always be equipped with a pressure relief valve calibrated to a pressure no greater than the motor's pmax. Refer to the hydraulic circuit diagrams below.

Closed loop circuit



RV = pressure relief valves calibrated to pRV < pmax.

If this is not possible because the circuit must also actuate other equipment at a higher pressure, or the control valve is of the closed centre type and the motor drives components with high inertia, auxiliary pressure relief valves must be installed as close as possible to the motor.



RV = pressure relief valves calibrated to pRV < pmax.




b) Connecting drain hole T

Standard motors are supplied without a drain hole. In this case the motor is equipped with internal drainage. This meets the requirements of the majority of applications with intermittent duty and an average drive pressure of less than 50% of the motor's maximum rated pressure.

When duty is continuous or intermittent with an operating percentage greater than 50% and the average drive pressure is greater than 50% of the rated maximum pressure, the motor must be ordered with external drainage and drain hole T must be connected to the tank. Refer to the diagrams below:

Internal drainage



c) Brake control

Gearmotors equipped with a brake, are available in two motor executions: B02P or P01S.


Brake control is internal on the B02P version, and is controlled directly by the motor.

The brake control pressure must instead be supplied by an auxiliary line of the brake control circuit on the P01S version.

Refer to the diagrams below:

Closed loop circuit

Open loop circuit



d) Type of hydraulic fluid

Use hydraulic mineral fluid with viscosity ISO VG 46 (46 Cst at t = 40°C). During operation, the fluid temperature should remain within the range +30°C to +70°C.





e) Filtering

To ensure the motor's reliable operation and long service life, the hydraulic circuit must be equipped with a filter capable of guaranteeing the following purity levels:


grade9 NAS 1638 grade6 SAE grade18/15 SO DIS 4406

Drive with hydraulic motor

All motors must be charged with hydraulic fluid before being operated and during installation.

Position the drain hole so that it is positioned uppermost for charging with fluid.

Make sure the hoses are routed in such a way as to prevent the motor casing from emptying and hence, prevent air pockets from forming which may affect pump suction during operation.



A - B = Supply lines T = Drainage



5.5 - LUBRICATION

Before starting up the gear unit, it must be charged with lubricant to the level corresponding to its specified mounting position.

The lubricant and its relative viscosity should be selected from the following chart, in accordance with the type of duty and ambient temperature.



If the gear unit is supplied ready charged with lubricant, replace the closed shipping plug with the vent plug included in the shipment before installing it.

(A1)

Plug thread	Pitch	Tightening torque [Nm]	Plug thread	Pitch	Tightening torque [Nm]
M14	1,5	15 - 20	1/8"	28	10 - 15
M16	1,5	15 - 20	4 / 4 !!	10	40.45
M18	1,5	15 - 20	1/4"	19	10 - 15
M20	1,5	20 - 30	3/8"	19	15 - 20
M22	1,5	20 - 30	1/2"	14	20 - 30
M24	1,5	20 - 30	0/48		00.00
M30	2	30 - 40	3/4"	14	20 - 30
M42	3	40 - 50	1"	11	30 - 40

(A2)

(AZ)					
	IND	USTRIAL INSTALLA	ATIONS	MOBILE N	IACHINES
	ISO sta	ndards with EP cha	aracteristics	SAE standards with /	API GL5 characteristics
Ambient temperature	-10°C / +30°C	+10°C / +45°C	-20°C / +60°C	-20°C / +30°C	+10°C / +45°C
	ISO VG 150	ISO VG 220	ISO VG 150-220	SAE 80W/90	SAE 85W/140
AGIP	BLASIA 150	BLASIA 220	BLASIA S220	ROTRA MP	ROTRA MP
ARAL	DEGOL BG 150	DEGOL BG 220	DEGOL GS 220	GETRIEBEOL HYP	GETRIEBEOL HYP
BP-MACH	ENERGOL GR XP 150	ENERGOL GR XP 220	ENERSYN HTX 220	HYPOGEAR EP	HYPOGEAR EP
CASTROL	ALPHA SP 150	ALPHA SP 220	ALPHASYN PG 150	HYPOY	HYPOY
CHEVRON	N.L. GEAR COMPOUND 150	N.L. GEAR COMPOUND 220		UNIVERSAL GEAR LUBRICANTE	UNIVERSAL GEAR LUBRICANTE
ELF	REDUCTELF SP150	REDUCTELF SP 220	ELF ORITIS 125 MS ELF SYNTHERMA P20	TRANSELF8	TRANSELF8
ESSO	SPARTAN EP 150	SPARTAN EP 220	GLYCOLUBE 220	GEAR OIL GX	GEAR OIL GX
				PONTONIC MP	PONTONIC MP
FINA	GIRAN 150	GIRAN 220			
I.P.	MELLANA150	MELLANA220	TELESIA OIL 150	PONTIAX HD	PONTIAX HD
KLUBER	KLUBEROIL GEM1-150	KLUBEROIL GEM1-320	KLUBERSYNT GH 6-220		
Q8	GOYA 150	GOYA 220	EL GRECO 220		
MOBIL	MOBILGEAR 629	MOBILGEAR 630	SHC 630	MOBILUBE HD	MOBILUBE HD
SHELL	OMALA EP150	OMALA EP220	TIVELA OIL SA	SPIRAXHD	SPIRAX HD
TOTAL	CARTER EP 150	CARTER EP 220		TRANSMISSION TM	TRANSMISSION TM

Synthetic oil.

Brake lubrication

The hydraulic multi-disk brakes are lubricated with the same oil as the gear unit.




Only synthetic lubricants may be used on gear units conforming to European Directive 94/9/EC. Refer to the above chart for the brand and type.



6.0 - TESTING THE GEAR UNIT

The gear unit has been factory tested by the Manufacturer. Before start-up, make sure that:

- the machine incorporating the gear unit complies with the provisions of the "Machinery Directive" 98/37/EC and any other applicable safety legislation
- the gear unit's mounting position in the installation corresponds to that prescribed and indicated on the nameplate
- the electrical power supply is suitable and operational as prescribed in EN 60204-1, and is grounded as per EN 50014
- the motor's electric power supply corresponds to that prescribed and is within +/-5% of the rated value
- the hydraulic system is suitable and operational, and the oil in the hydraulic motor's lubrication circuit conforms to ISO VG 46. It must be filtered with a maximum grade of 10 µm and contamination level less than or equal to class 9 as per NAS 1638 or 18/15 as per ISO/DIS 4406
- · there are no signs of lubricant leaks from the plugs or gaskets
- · the vent plug is not obstructed by dirt or paint
- the unit does not run noisily or with excessive vibration.



7.0 - USING THE EQUIPMENT

Before putting the gear unit into service, the User must ensure that the plant in which it is installed complies with all applicable directives, especially those regarding health and safety at work.

The gear unit may not be used in areas and environments:





• in direct contact with loose food products.

Danger zones and exposed persons:



The danger zone of the gear unit is the protrusion of the shaft which constitutes a hazard for exposed persons in direct contact with it (crushing, shearing, trapping). In particular, when the gear unit is operating in automatic mode in an accessible area, the shaft must be protected by a guard.



8.0 - MAINTENANCE



Maintenance and replacement work must be carried out by expert maintenance technicians trained in the observance of applicable laws on health and safety at work and the special ambient problems attendant on the installation.



Before doing any work on the unit, the operator must first switch off power to the gear unit and ensure that it is out of service, as well as taking all necessary precautions against it being accidentally switched on again or its parts moving without warning (due to suspended loads or similar external factors).

Furthermore, all additional environmental safety precautions must be taken (e.g. elimination of residual gas or dust, etc).


- Before doing any maintenance work, activate all the safety devices provided and, if necessary, inform persons working in the vicinity. Cordon off the area around the unit and prevent access to any equipment which, if activated, might be the cause of unexpected health and safety hazard.
- Replace worn components with original spare parts.
- Use the lubricants (oil and grease) recommended by the Manufacturer.
- When working on the gear unit always replace all gaskets and seals with original new ones.
- If a bearing requires replacement, it is good practice to also replace the other bearing supporting the same shaft.
- · We recommend replacing the lubricating oil after all maintenance work.

The above instructions are aimed at ensuring efficient and safe operation of the gear unit.

The Manufacturer declines all liability for injury to persons and damage to components due to the use of non-original spare parts and non-routine work that modifies the safety requirements without the Manufacturer's express prior authorisation.

Refer to the specific spare parts catalogue when ordering spare parts for the gear unit.

Do not dump polluting liquids, worn parts and maintenance waste into the environment. Dispose of all such materials as specified by applicable legislation.





8.1 - ROUTINE MAINTENANCE



Keep the gear unit at its maximum efficiency by following the routine maintenance schedule. Good maintenance ensures the unit's maximum performance, extended service life and continued compliance with safety regulations.

(A3)	-		
Frequency	Component	Type of check	Action
at start	Gear unit casing	Check that the external temperature does not exceed 75-80 °C	Stop the machine and contact Bonfiglioli Trasmital's Technical Service
ofter 200 bro	Original consignment lubricant	Replace	Replace with new lubricant
after 200 hrs	External fasteners	Check locking torque	Tighten down to specified torque
1000 hrs	External seals and gaskets	Check oil level Check for leaks by eye	Service or replace components as required
2500 hrs	Lubricant	Replace	Replace with new lubricant
5000 hrs	Gear unit seals and gaskets	Inspect carefully for wear/age- ing of external seals	Replace if aged/worn

For installations in zones 21 and 22 the User must schedule and implement a regular cleaning programme for all surfaces and recesses to avoid dust build-ups of more than 5 mm in depth.



(Ex

Every 1000 hrs. of operation or after 6 months:

• Measure the surface temperature at the coupling between the gear unit and motor, and at the points which are most shielded from the motor's cooling fan. The maximum temperature must not be more than 75-80°C, nor may this value be exceeded during operation.

Every 5000 hrs. of operation:

- Change the synthetic oil and bearing grease if the gear unit is not life lubricated.
- Replace all externally accessible seal rings unless this has already been done as a result of problems occurring before the scheduled maintenance deadline.



8.2 - OIL CHANGES

- 1. Place an adequate container under the drain plug.
- 2. Remove the filler and drain plugs and allow the oil to drain out.



The oil will drain better if it is warm.

- 3. Wait for a few minutes until all the oil has drained out, then screw the drain plug back on after first changing the plug seal.
- 4. Fill with new oil until it reaches the level mark. Do not mix oils of different makes or specifications and check that the oil is highly resistant to foaming and is EP rated.
- 5. Tighten down the filler plug after changing its seal.




The gear unit may be supplied with or without lubricant, as requested by the User. The quantity of charge oil required is specified in the Sales Catalogue. This specification is however, approximate, and reference must always be made to the mark on the level plug, the placement of which depends on the mounting position specified in the purchase order.

Life lubricated gear units which are not subject to external contamination do not normally require periodic lubricant changes. If the same type of oil as that already in use is not available, drain the gear unit casing completely and wash its interior thoroughly with a light solvent before refilling with the new lubricant.



If a leak is found, identify the cause of the fault and repair it before topping up the lubricant and operating the unit.

Lubricants, solvents and detergents are toxic/harmful to health:



- they may cause intoxication if inhaled

- they may be fatal if swallowed.

Handle them with care using suitable individual safety equipment. Do not dump them into the environment and dispose of in accordance with applicable legislation.

8.3 - CHECKING OPERATIONAL EFFICIENCY

- Remove any dust from the gear unit and motor casings.
- Check that the noise generated at continuous load does not vary. Excessive vibration or noise can indicate wear of the gear train or failure of a bearing.
- Check the power absorption and voltage against the rated values given on the motor's nameplate.
- Check the wear of the friction surfaces and braking gasket on the brake motors (if fitted) and, if necessary, adjust the gap.
- Check for lubricant leaks from the gaskets/seals, plugs and casings.
- Check all bolted couplings for wear, deformation and corrosion and tighten them down fully, but without over tightening.

8.4 - CLEANING

Remove all dust and process waste from the gear unit. Do not use solvents or other products that are incompatible with the unit's construction material and do not direct high pressure jets of water at the gear unit.






9.0 - REPLACING PARTS

- Immediately replace parts and components if they are not able to guarantee safe and reliable operation.
- Never improvise repairs.
- The use of non-original spare parts not only renders the warranty null and void but can jeopardise the gear unit's operation.

9.1 - REMOVING THE MOTOR

If during operation the mobile coupling between the motor and gear unit has not rusted significantly, it should be possible to remove the motor without applying excessive force.

If instead, it proves difficult to remove the motor, do not use screwdrivers or levers to apply force as this may damage the flanges and mating surfaces, but proceed as illustrated below.



9.2 - DECOMMISSIONING THE GEAR UNIT

The unit must only be taken out of service by operators trained in the observance of applicable laws on health and safety at work.

Do not dump non-biodegradable products, lubricants and non-ferrous materials (rubber, PVC, resins, etc.) into the environment. Dispose of all such materials as stipulated by established environmental legislation.

Do not re-use parts or components which appear to be in good condition after they have been checked or replaced by qualified personnel and declared unsuitable for use.




10.0 - TROUBLESHOOTING

The following information is intended to serve as an aid in locating and eliminating defects and faults. In some cases, problems may be caused by the plant or machine to which the gear unit is assembled and hence, the cause and remedy will be described in the Manufacturer's technical documentation for the machine/plant in question.

FAULT	CAUSE	REMEDY
	Oil level too low	Top up oil level
Bearing temperature too high	Oil spent	Replace oil
	Defective bearings	Contact authorised workshop
	Oil level too high	Check oil level
Operating temperature too high	Oil spent	Replace oil
	Contaminant in oil	Replace oil
	Gears damaged	Contact authorised workshop
	Bearing axial backlash too high	Contact authorised workshop
Abnormal running noise	Bearings defective or worn	Contact authorised workshop
	Excessive load applied	Correct load to rated values given in Sales Catalogue
	Contaminant in oil	Replace oil
Abnormal noise at gear unit	Mounting bolts loose	Tighten bolts to specified torque
mounting	Mounting bolts worn	Replace bolts
	Oil level too high	Check oil level
Oil leaks	Casing/coupling seals inadequate	Contact authorised workshop
	Gaskets worn	Contact authorised workshop
	Oil viscosity too high	Replace oil (see recommended lubricant chart)
Gear unit does not run or runs with difficulty	Oil level too high	Check oil level
	Excessive load applied	Redesign drive for actual load required
Output shaft does not turn with motor running	Gears damaged	Contact authorised workshop



ANNEX 1 - CHECKING THE OIL LEVEL ON ATEX-SPECIFIED GEAR UNITS





ANNEX 2 - LUBRICANT CHARGE QUANTITY

Туре					Туре							
Type		M	ounting posit	ion	Type		Mo	ounting positi	on			
		Α	Т	0		_	B0	U*	P*			
	L1	0.6	1.0	0.9		R2	1.2	1.7	1.5			
300	L2	0.9	1.3	1.2	300	R3	1.5	2.0	1.8			
300	L3	1.2	1.6	1.5	500	R4	1.8	2.3	2.1			
	L4	1.5	1.9	1.8								
	L1	0.8	1.2	1.1		R2	1.6	2.1	1.9			
301	L2 L3	<u> </u>	1.5 1.8	1.4	301	R3 R4	<u>1.9</u> 2.2	2.4	2.2 2.5			
	L3 L4	1.4	2.1	2.0		R4	2.2	2.1	2.5			
	L1	1.3	2.3	2.0		R2	2.2	2.8	2.6			
	L2	1.6	2.6	2.3		R3	2.5	3.1	2.9			
303	L3	1.9	2.9	2.6	303	R4	2.8	3.4	3.2			
	L4	2.2	3.2	2.9					-			
	L1	1.6	2.6	2.4		R2	2.5	3.1	2.9			
~~=	L2	2.1	3.1	2.9	005	R3	3.0	3.6	3.4			
305	L3	2.4	3.4	3.2	305	R4	3.3	3.9	3.7			
	L4	2.7	3.7	3.5								
	L1	2.5	3.5	3.2		R2	4.0	5.0	4.8			
306	L2	3.3	4.3	4.0	306	R3	4.8	5.8	5.6			
300	L3	3.6	4.6	4.3	- 300	R4	5.1	6.1	5.9			
	L4	3.9	4.9	4.6					7.0			
	L1 L2	3.5	5.0	4.5		R2	6.0	8.0	7.0			
307	L2 L3	4.5	6.0	5.5	307	R3 R4	7.0	9.0	8.0			
	L3 L4	<u>5.0</u> 5.3	6.5 6.8	6.0 6.3		R4	7.5	9.5	8.5			
	L4 L1	4.0	5.5	5.0		R2	6.5	8.5	7.5			
	L2	5.0	6.5	6.0		R3	7.5	9.5	8.5			
309	L3	5.5	7.0	6.5	309	R4	8.0	10	9			
	L4	5.8	7.3	6.8								
	L1	5.0	6.5	6.0								
040	L2	6.3	7.8	7.3	0.4.0	R3	11	13	12			
310	L3	7.1	8.6	8.1	310	R4	12	14	13			
	L4	7.4	8.9	8.4								
	L1	7.0	12	10		R2	14	19	17			
311	L2	9.0	14	12	311	R3	16	21	19			
311	L3	10	15	13	311	R4	17	22	20			
	L4	10.5	15.5	13.5			10	01	10			
	L1	9.0	14	12		R2	16	21	19			
313	L2 L3	11.5 12.5	16.5 17.5	14.5 15.5	313	R3 R4	<u>19</u> 20	24 25	22 23			
	L3 L4	12.5	17.5	16		R4	20	25	23			
	L4 L1	15	23	19								
	L2	19	27	23		R3	27	35	31			
315	L2 L3	21	29	25	315	R4	30	38	34			
	L4	22	30	26								
	L1	18	26	22								
246	L2	22	30	26	240	R3	30	38	34			
316	L3	24	32	28	316	R4	33	41	37			
	L4	25	33	29								
	L1	20	35	30								
317	L2	26	41	36	317	R3	38	52	48			
	L3	29	44	39		R4	42	56	52			
	L4 L1	30	45	40								
	L1 L2	<u>25</u> 35	40 50	35 45								
318	L2 L3	40	55	50	318	R4	48	63	58			
	L3	40	58	53			70					
	L1	35	55	45								
	L2	45	65	55								
319	L3	50	70	60								
	L4	53	73	63								
	L1	35	55	45								
224	L2	50	70	60								
321	L3	56	76	66								
	L4	60	80	70								

N.B. The quantities indicated are approximate only. Fill the unit according to the position of the level plug or level rod supplied with the gear unit.





							(]						
	A	A - EA - F	D	AF - E	F - FE	AE - E	E - FF	AD - E	D - FA	TA - TE VA - VC			- OF- OD - QF- QD
		inp &	out Pe		input		input		input		input		input
		P(IEC)	HS		P(IEC) HS		P(IEC) HS		P(IEC) HS		P(IEC) HS		P(IEC) HS
3/V 00 L3 3/V 01 L3	0.9 1.1	0.12	0.12	0.9 1.1	0.12	0.9 1.1	0.12	0.9 1.1	0.12	1.3 1.5	0.12	1.2 1.4	0.12
3/V 03 L3	1.6	0.25	0.25	1.6	0.31	1.6	0.31	1.6	0.38	2.6	0.31	2.3	0.25
3/V 05 L3	2.1	0.38	0.38	2.1	0.43	2.1	0.43	2.1	0.52	3.1	0.52	2.9	0.38
3/V 06 L3 3/V 10 L4	3.3 7.1	0.64	0.64	3.3 7.1	0.76	3.3 7.1	0.76	3.3 7.1	0.85	4.3 8.6	0.76	4 8.1	0.76
3/V 07 L3 3/V 11 L4	4.5 10	2.4	2.8	4.5 10	2.6	4.5 10	2.6	4.5 10	1.7	6 15	1.9	5.5 13	1.9
3/V 13 L4	13			13		13		13		18		16	
3/V 09 L3 3/V 10 L3 3/V 15 L4 3/V 16 L4	5 6.3 21 24	4.3	4.5	5 6.3 21 24	3.9	5.0 6.3 21 24	3.9	5 6.3 21 24	3.0	6.5 7.8 29 32	3.5	6 7.3 25 28	3.5
3/V 11 L3 3/V 13 L3 3/V 17 L4	9 12 29	7.8	9.6	9 12 29	6.7	9 12 29	6.7	9 12 29	5.0	14 17 44	5.5	12 15 39	5.5
3/V 15 L3 3/V 16 L3 3/V 18 L4	19 22 40	11	15	19 22 40	8.9	19 22 40	9.4	19 22 40	7.5	27 30 55	9.5	23 26 50	9.5
3/V 19 L4	50			50		50		50		70		60	
3/V 17 L3 3/V 21 L4	26 56	23	28	26 56	16.8	26 56	17.5	26 56	10.7	41 76	17	36 66	17

Life lubrication

)[I]					
	AA - E	A - FD	TA - TE - VA - VC		OA - OE QA - QE		AD - E	D - FA	AF - E	F - FE	AE - E	E - FF
3/A 00 L2	0.60	1.4	1.0	1.4	0.9	1.4	0.6	1.4	0.6	1.4	0.6	1.4
3/A 01 L2	0.80	2.3	1.2	2.3	1.1	2.3	0.8	2.3	0.8	2.3	0.8	2.3
3/A 03 L2	1.3	3.2	2.3	3.2	2.0	3.2	1.3	3.2	1.3	3.2	1.3	3.2
3/A 05 L2	1.6	4.0	2.6	4.1	2.4	4.1	1.6	4.7	1.6	5.2	1.6	4.4
3/A 06 L2	2.5	4.9	3.5	8.1	3.2	4.7	2.5	8.4	2.5	11	2.5	9.2
3/A 07 L2	3.5	6.8	5.0	8.1	4.5	12	3.5	15	3.5	18	3.5	15

Life lubrication

NOTE: In combined gear units, lubrication of the planetary stage is separate from that of the worm (3/V) or helical bevel (3/A) stages.



INDEX OF REVISIONS (R)

	R1
31	Amended section 8.1 "Routine maintenance".

We reserve the right to implement modifications without notice. This catalogue cannot be reproduced, even partially, without prior consent.

MOBILE EQUIPMENT AND WIND ENERGY SOLUTIONS

INDUSTRY PROCESS AND AUTOMATION SOLUTIONS



www.bonfiglioli.com

GOD BONFIGLIOLI

OPERATION MAINTENANCE SERVICE MANUAL

600 - 8,000 lb. Axles & Related Components





Introduction

This manual is designed to provide information for you to understand, use, maintain, and service your trailer running gear system. Your axles are manufactured by Dexter Axle. The Dexter product line, the most complete in the industry, is the result of over 30 years of experience in the design, testing and manufacturing of trailer axles. The Dexter running gear system consists of spindles, hubs, drums, and brakes which are engineered to provide you the finest towing and stopping performance currently available in the industry today.

Two Dexter philosophies are at work to provide you the best product available and have enabled us to maintain our position of leadership. First, we operate on the theory that "there is always a better way" for a product to operate, to be manufactured, and/or to be serviced. We are constantly striving to find that better way.

Secondly, we maintain wall-to-wall production control so that all the major components of your running gear system are manufactured in Dexter facilities under our strict quality control standards. These manufactured components include the axle beam, hubs, drums, spindles, brakes, magnets, and most of the steel stampings used in the attachment of your axle to your trailer. Dexter has the most complete, state-of-the-art manufacturing facilities which enable us to provide you, the trailer owner, with the finest product possible.

For all your running gear needs...

Lookfirst to Dexter!

Visit us online at www.dexteraxle.com



Introduction Getting Started - Setup and Adjustment4 **Braking Systems - Electric** Electric Brakes5 Features 6 Parking Brake Option6 Self Adjusting Feature6 Brake Controllers7 How To Use Your Electric Brakes Properly11 Trailer Wire Size Chart11 Synchronizing Your Trailer Brakes12 Brake Cleaning and Inspection14 Brake Lubrication14 Introduction to Troubleshooting17 How to Measure Voltage20 How to Measure Amperage20 Magnet Amperes Chart21

Braking Systems - Hydraulic

Hydraulic Brakes	. 23
Hydraulic Brake Operation	.24
Duo-Servo	.24
Uni-Servo	.24
Self-Adjusting Mechanism for 12 ¹ /4" Brakes	. 25
Hydraulic Parking Brake Option	. 25
Disc Brakes	. 27
Actuation Systems	. 28
Electrical Schematic	
Troubleshooting Guide	. 29
General Maintenance - Hydraulic Brakes	. 31
Drum Brake Adjustment - Manual	
Wheel Cylinders	. 32
Brake Lines	. 32
Shoes and Linings	. 32
Hardware	. 33
Instructions for Brake Caliper Kit - 3.5K Disc Brakes	. 33
Instructions for Brake Rotor Kit - 3.5K Disc Brakes	. 34
Instructions for Brake Rotor Kit - 6K or 8K Disc Brakes	. 36
Instructions for Brake Pad Kit - 6K or 8K Disc Brakes	. 37
Instructions for Brake Caliper Kit - 6K or 8K Disc Brakes	. 39
Introduction to Troubleshooting	.41
Troubleshooting Chart - Hydraulic	. 42

Table of Contents

Hubs/Drums/Bearings

	J. J	
	Hubs/Drums/Bearings	44
	Hub Removal - Standard Bearings	44
	Brake Drum Inspection	45
	Bearing Inspection	
	Bearing Lubrication - Grease	
	Bearing Lubrication - Oil	48
	Recommended Wheel Bearing Lubrication Specifications	
	Seal Inspection and Replacement	49
	Bearing Adjustment and Hub Replacement	50
	Typical E-Z Lube® After Spring 2002 E-Z Lube® Lubrication	50 51
	Nev-R-Lube™ Drums/Bearings	
	Drum Removal	
	Bearing Inspection	
	Nev-R-Lube™ Bearing End Play Inspection	
	Bearing Replacement and Drum Installation	
<u>c</u> .		
ວເ	ispensions	
	Suspension Systems	57
	Double Eye Leaf Springs	57
	Grease Lubricated Suspension Bushings	
	Slipper Leaf Springs	58
	Inspection and Replacement	
	Suspension Fastener Torque Values Torflex® Suspension	59 61
	Airflex™ Suspension	
	•	02
VV	heels and Tires	
	Wheels	
	Wheel Selection	
	Torque Requirements	
	Wheel Torque Requirements	68
	Maximum Wheel Fastener Torque	
	Tires	
	Tire Wear Diagnostic Chart	/1
Re	eplacement Parts/Kits	
	Magnet Replacement Kits	72
	Brake Shoe Replacement Kits	72
	Bearing Replacement Chart	73
	Seal Replacement Reference	73
St	orage	
	Storage Preparation	74
	After Prolonged Storage - Inspection Procedures	74 75
	Trip Preparation Checklist	75 76
N.A.		70
IVI	aintenance Schedule	
	Maintenance Schedule Chart	77
W	arranty	
	Dexter Axle Limited Warranty	78





Important Safety Notice

Appropriate service methods and proper repair procedures are essential for the safe, reliable operation of all running gear as well as the personal safety of the individual doing the work. This manual provides general directions for performing service and repair work with tested, effective techniques. Following these guidelines will help assure reliability.

There are numerous variations in procedures, techniques, tools, parts for servicing axles, as well as in the skill of the individual doing the work. This manual cannot possibly anticipate all such variations and provide advice or cautions as to each. Anyone who departs from the instructions provided in this manual must first establish that they neither compromise their personal safety nor the vehicle integrity by their choice of methods, tools, or parts.

Refer to your vehicle manufacturer's owners manual for additional procedures, techniques, and warnings prior to performing any maintenance or repairs.

This is the safety alert symbol. It is used to alert you to potential injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

Getting Started - Setup and Adjustment


For proper performance, all new axles should have the following checked at the specified intervals:

- Wheel Nut Torque: at 10, 25, and 50 miles
- Brake Adjustment: at 200 and 3,000 miles
- *Tire pressure:* to manufacturer's requirements
- Brake synchronization: set brake controller per controller manufacturer's directions

ntroduction

Electric Brakes

The electric brakes on your trailer are similar to the drum brakes on your automobile. The basic difference is that your automotive brakes are actuated by hydraulic pressure while your electric trailer brakes are actuated by an electromagnet. With all of the brake components connected into the system, the brake will operate as follows:



When the electrical current is fed into the system by the controller, it flows through the electromagnets in the brakes. The high capacity electromagnets are energized and are attracted to the rotating armature surface of the drums which moves the actuating levers in the direction that the drums are turning.

The resulting force causes the actuating cam block at the shoe end of the lever to push the primary shoe out against the inside surface of the brake drum. The force generated by the primary shoe acting through the adjuster moves the secondary shoe out into contact with the brake drum.

Increasing the current flow to the electromagnet causes the magnet to grip the armature surface of the brake drum more firmly. This results in increasing the pressure against the shoes and brake drums until the desired stop is accomplished.





Features

Electrically actuated brakes have several advantages over other brake actuation systems.

- 1. They can be manually adjusted at the controller to provide the correct braking capability for varying road and load conditions.
- 2. They can be modulated to provide more or less braking force, thus easing the brake load on the towing vehicle.
- 3. They have very little lag time from the moment the tow vehicle's brakes are actuated until the trailer brakes are actuated.
- 4. In an emergency situation, they can provide some braking independent of the tow vehicle.

Parking Brake Option (not available on all sizes)

Dexter electric brakes with parking brake option are mechanically operated by a cable. Cable force applied to the parking lever creates a torque through the pivot pin and cam assembly. Torque transferred to the parking cam results in a spreading force between the primary and secondary shoes. The shoes, in turn, move towards the drum until contact is made. Friction generated between the drum and lining contact surface keeps the drum from rotating under normal loading conditions.

Self Adjusting Feature (121/4" brakes series only)

Forward self adjust electric brakes were introduced in October of 1996. This feature adjusts the brakes on both forward and reverse stops. Brake adjustment occurs when lining wear results in enough gap between the shoes and the brake drum surface. This added clearance will allow the adjuster mechanism to rotate the screw assembly at the bottom of the brake. That action expands the distance between the shoes and thus closes the gap to the drum surface.


Brake Controllers

Electric brake controllers provide power to the magnets to actuate the trailer brakes. Dexter Axle offers a state-of-the-art inertial controller called the Predator Series[™] DX2. This controller features a patented pendulum design which senses the deceleration of the towing vehicle and sends a proportional voltage to the electric trailer brakes. Other features include a visual gain setting for quick and easy adjustment and a digital LED display to show the voltage output. A manual override sends full voltage to the trailer brakes, regardless of gain setting, for emergency conditions and also illuminates the brake lights to warn of an impending stop.


Most electric brake controllers provide a modulation function that varies the current to the electric brakes with the pressure on the brake pedal or amount of deceleration of the tow vehicle. Electronic or timing controllers do not provide proportional modulation. These controllers tend to be inexpensive but not the best choice for optimum braking. It is important that your brake controller provide approximately 2 volts to the braking system when the brake pedal is first depressed and gradually increases the voltage to 12 volts as brake pedal pressure is increased. If the controller "jumps" immediately to a high voltage output, even during a gradual stop, then the electric brakes will always be fully energized and will result in harsh brakes and potential wheel lockup.








Braking Systems - Electric







Typical Trailer Wiring



View Looking into Tow Vehicle Receptacle

Braking Systems - Electric

How to Use Your Electric Brakes Properly

Your trailer brakes are designed to work in synchronization with your tow vehicle brakes. Never use your tow vehicle or trailer brakes alone to stop the combined load.

Your brake controller must be set up according to the manufacturer's recommendations to ensure proper synchronization between the tow vehicle and the trailer. Additionally, you may have to make small adjustments occasionally to accommodate changing loads and driving conditions.

Proper synchronization of tow vehicle to trailer braking can only be accomplished by road testing. Brake lockup, grabbiness, or harshness is quite often due to the lack of synchronization between the tow vehicle and the trailer being towed, too high of a threshold voltage (over 2 volts), or under adjusted brakes.

Before any synchronization adjustments are made, your trailer brakes should be burnished-in by applying the brakes 20-30 times with approximately a 20 m.p.h. decrease in speed, e.g. 40 m.p.h. to 20 m.p.h. Allow ample time for brakes to cool between application. This allows the brake shoes and magnets to slightly "wear-in" to the drum surfaces.

Number of Brakes	Hitch-to-Axle Distance In Feet		
2		12 AWG	
4	Under 30	12 AWG	
4	30-50	10 AWG	
6	Under 30	10 AWG	
6	30-50	8 AWG	

Trailer Wire Size Chart





Synchronizing Your Trailer Brakes

To insure safe brake performance and synchronization, *read the brake controller manufacturer's instructions completely before attempting any synchronization procedure.*



Before road testing, make sure the area is clear of vehicular and pedestrian traffic. Failure to brake safely could result in an accident and personal injury to yourself and/or others.

Make several hard stops from 20 m.p.h. on a dry paved road free of sand and gravel. If the trailer brakes lock and slide, decrease the gain setting on the controller. If they do not slide, slightly increase the gain setting. Adjust the controller just to the point of impending brake lockup and wheel skid.

Note: Not all trailer brakes are capable of wheel lockup. Loading conditions, brake type, wheel and tire size can all affect whether a brake can lock. It is not generally considered desirable to lock up the brakes and slide the tires. This can cause unwanted flat spotting of the tires and could also result in a loss of control.

Braking Systems - Electric

If the controller is applying the trailer brakes before the tow vehicle brakes, then the controller adjustments should be made so the trailer brakes come on in synchronization with the tow vehicle brakes. For proper braking performance, it is recommended that the controller be adjusted to allow the trailer brakes to come on just slightly ahead of the tow vehicle brakes. When proper synchronization is achieved there will be no sensation of the trailer "jerking" or "pushing" the tow vehicle during braking.

General Maintenance - Electric Brakes Brake Adjustment

Most Dexter 12¹/₄" electric brakes have a self adjusting feature. If manual adjusting is required, use the following procedure:

Brakes should be adjusted (1) after the first 200 miles of operation when the brake shoes and drums have "seated," (2) at 3,000 mile intervals, (3) or as use and performance requires. The brakes should be adjusted in the following manner:

 Jack up trailer and secure on adequate capacity jack stands. Follow trailer manufacturer's recommendations for lifting and supporting the unit. Make sure the wheel and drum rotates freely.

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury.

- 2. Remove the adjusting hole cover from the adjusting slot on the bottom of the brake backing plate.
- 3. With a screwdriver or standard adjusting tool, rotate the starwheel of the adjuster assembly to expand the brake shoes. Adjust the brake shoes out until the pressure of the linings against the drum makes the wheel very difficult to turn.

Note: For drop spindle axles, a modified adjusting tool may be necessary.

- 4. Then rotate the starwheel in the opposite direction until the wheel turns freely with a slight lining drag.
- 5. Replace the adjusting hole cover and lower the wheel to the ground.
- 6. Repeat the above procedure on all brakes. For best results, the brakes should all be set at the same clearance.





Brake Cleaning and Inspection

Your trailer brakes must be inspected and serviced immediately if a loss of performance is indicated. With normal use, servicing at one year intervals is usually adequate. With increased usage, this work should be done more frequently as required. Magnets and shoes must be changed when they become excessively worn or scored, a condition which can reduce vehicle braking.

Clean the backing plate, magnet arm, magnet, and brake shoes. Make certain that all the parts removed are replaced in the same brake and drum assembly. Inspect for any loose or worn parts, stretched or deformed springs and replace as necessary.

POTENTIAL ASBESTOS DUST HAZARD! Some older brake linings may contain asbestos dust, which has been linked to serious or fatal illnesses. Certain precautions need to be taken when servicing brakes:

- 1. Avoid creating or breathing dust.
- 2. Avoid machining, filing or grinding the brake linings.
- 3. Do not use compressed air or dry brushing for cleaning (dust can be removed with a damp brush).

Brake Lubrication

Before reassembling, apply a light film of grease or anti-seize compound on the brake anchor pin, the actuating arm bushing and pin, and the areas on the backing plate that are in contact with the brake shoes and magnet lever arm. Apply a light film of grease on the actuating block mounted on the actuating arm.

CAUTION


Do not get grease or oil on the brake linings, drums or magnets.

raking Systems - Electric

Magnets

Your electric brakes are equipped with high quality electromagnets that are designed to provide the proper input force and friction characteristics. Your magnets should be inspected and replaced if worn unevenly or abnormally. As indicated below, a straightedge should be used to check magnet condition. For best results, the magnet should be flat.

Even if wear is normal as indicated by your straightedge, the magnets should be replaced if any part of the magnet coil has become visible through the friction material facing of the magnet. It is also recommended that the drum armature surface be refaced when replacing magnets (see section on Brake Drum Inspection). Magnets should also be replaced in pairs - both sides of an axle. Use only genuine Dexter replacement parts when replacing your magnets.







Shoes and Linings

A simple visual inspection of your brake linings will tell if they are

usable. Replacement is necessary if the lining is worn (to within ¹/₁₆" or less), contaminated with grease or oil, or abnormally scored or gouged. Hairline heat cracks are normal in bonded linings and should not be cause for concern. When replacement is necessary, it is important to replace both shoes on each



brake and both brakes of the same axle. This will help retain the "balance" of your brakes.

POTENTIAL ASBESTOS DUST HAZARD!

Some older brake linings may contain asbestos dust, which has been linked to serious or fatal illnesses. Certain precautions need to be taken when servicing brakes:

- 1. Avoid creating or breathing dust.
- 2. Avoid machining, filing or grinding the brake linings.
- 3. Do not use compressed air or dry brushing for cleaning (dust can be removed with a damp brush).

After replacement of brake shoes and linings, the brakes must be re-burnished to seat in the new components. This should be done by applying the brakes 20 to 30 times from an initial speed of 40 m.p.h., slowing the vehicle to 20 m.p.h. Allow ample time for brakes to cool between applications. This procedure allows the brake shoes to seat in to the drum surface.

Introduction to Troubleshooting

Proper brake function is critical to the safe operation of any vehicle. If problems are encountered with your trailer braking system, the following guide can be used to find the causes and remedies for some of the more common problems. If you are unsure or unable to resolve the problem, please contact your nearest repair facility for professional assistance.

Troubleshooting

Most electric brake malfunctions, that cannot be corrected by either brake adjustments or synchronization adjustments, can generally be traced to electrical system failure. Voltmeters and ammeters are essential tools for proper troubleshooting of electric brakes.

Mechanical causes are ordinarily obvious, i.e. bent or broken parts, worn out linings or magnets, seized lever arms or shoes, scored drums, loose parts, etc. Replace defective parts with genuine Dexter replacements.


Please consult the following troubleshooting charts to determine the causes and solutions for common problems found in trailer braking systems.

Best braking performance is achieved with a controller setting that is just short of wheel lock up or slide. Overly aggressive braking which results in wheel lock up and sliding, can cause a dangerous loss of control and result in personal injury or death.






Troubleshooting



Braking Systems - Electric

Troubleshooting








How to Measure Voltage

System voltage is measured at the magnets by connecting the voltmeter to the two magnet lead wires at any brake. This may be accomplished by using a pin probe inserted through the insulation of the wires. The engine of the towing vehicle should be running when checking the voltage so that a low battery will not affect the readings.

Voltage in the system should begin at 0 volts and, as the controller bar is slowly actuated, should gradually increase to about 12 volts. If the controller does not produce this voltage control, consult your controller manual.



The threshold voltage of a controller is the voltage applied to the brakes when the controller first turns on. Lower threshold voltage will provide for smoother braking. If the threshold voltage is too high, the brakes may feel grabby and harsh.

How to Measure Amperage

System amperage is the current flowing in the system when all the magnets are energized. The amperage will vary in proportion to the voltage. The engine of the tow vehicle should be running with the trailer connected when checking the trailer braking system.


One place to measure system amperage is at the BLUE wire of the controller which is the output to the brakes. The BLUE wire must be disconnected and the ammeter put in series into the line. System amperage draw should be as noted in the following table. Make sure your ammeter has sufficient capacity and note polarity to prevent damaging your ammeter.

Magnet Amperes Chart

Brake Size	Amps/ Magnet	Two Brakes	Four Brakes	Six Brakes	Magnet Ohms
7 x 1 ¹ / ₄	2.5	5.0	10.0	15.0	3.9
10 x 1 ¹ / ₂	3.0	6.0	12.0	18.0	3.2
10 x 2 ¹ / ₄	3.0	6.0	12.0	18.0	3.2
12 x 2	3.0	6.0	12.0	18.0	3.2
12 ¹ / ₄ x 2 ¹ / ₂	3.0	6.0	12.0	18.0	3.2
12 ¹ / ₄ x 3 ³ / ₈	3.0	6.0	12.0	18.0	3.2

If a resistor is used in the brake system, it must be set at zero or bypassed completely to obtain the maximum amperage reading.

Individual amperage draw can be measured by inserting the ammeter in the line at the magnet you want to check. Disconnect one of the magnet lead wire connectors and attach the ammeter between the two wires. Make sure that the wires are properly





reconnected and sealed after testing is completed.

The most common electrical problem is low or no voltage and amperage at the brakes. Common causes of this condition are:

- 1. Poor electrical connections
- 2. Open circuits
- Insufficient wire size
- 4. Broken wires
- 5. Blown fuses (fusing of brakes is not recommended)
- 6. Improperly functioning controllers or resistors

Another common electrical problem is shorted or partially shorted circuits (indicated by abnormally high system amperage).





Possible causes are:

- 1. Shorted magnet coils
- 2. Defective controllers
- 3. Bare wires contacting a grounded object

Finding the cause of a short circuit in the system is done by isolating one section at a time. If the high amperage reading drops to zero by unplugging the trailer, then the short is in the trailer. If the amperage reading remains high with all the brake magnets disconnected, the short is in the trailer wiring.

All electrical troubleshooting procedures should start at the controller. Most complaints regarding brake harshness or malfunction are traceable to improperly adjusted or non-functioning controllers. See your controller manufacturer's data for proper adjustment and testing procedures. For best results, all the connection points in the brake wiring should be sealed to prevent corrosion. Loose or corroded connectors will cause an increase in resistance which reduces the voltage available for the brake magnets.

raking Systems - Electric

Hydraulic Brakes

Dexter offers several varieties of hydraulic trailer brakes. Your vehicle may be equipped with the traditional drum brakes or you may have disc brakes.

The hydraulic brakes on your trailer are much like those on your automobile or light truck. The hydraulic fluid from a master cylinder or actuation system is used to actuate the wheel cylinder which, in turn, applies force against the brake shoes and drum. The main difference between automotive hydraulic brakes and hydraulic trailer brakes is the trailers' actuation system. These systems respond to the braking signal from the tow vehicle and supply the required brake fluid volume and pressure to the trailer brakes.

In the following pages you will find a more detailed description of the hydraulic brakes and actuation system used on your trailer.

CAUTION

The operating pressure required for Dexter brakes:

- 7" diameter drum brakes maximum operating pressure is 750 psi
- 10" diameter and larger drum brakes maximum operating pressure is 1,000 psi
- Hydraulic disc brakes (all sizes) maximum operating pressure is 1,600 psi






Hydraulic Brake Operation

Duo-Servo

The duo-servo brake uses a dual piston wheel cylinder to apply the brakes. This type of brake is typically used in a vacuum/ hydraulic, electric/hydraulic or air/hydraulic system. A description of operation of this brake is as follows:

When the brakes are applied, the double-acting wheel cylinder moves the primary and secondary shoes towards the drum. The

frictional force between the brake drum and lining attempts to turn the primary shoe into the secondary shoe. The secondary shoe is forced onto the anchor pin and from this point, the secondary and primary shoes attempt to "wrap around". In essence, the brake has utilized frictional



force to help the applying force on both shoes.

If the brakes are applied while the vehicle is backing, the shoes rotate in the direction of the drum rotation. This causes the secondary shoe to leave the anchor and causes the primary shoe to move against the anchor. Action of the brake is the same in reverse as forward.


Uni-Servo

This type of hydraulic brake utilizes a single acting cylinder. Upon actuation, the primary shoe is pressed against the brake drum, which causes the shoe to move in the direction of rotation. This movement in turn actuates the secondary shoe through the adjuster assembly. Braking in reverse is significantly less effective than in the forward direction.

Another variation is called a "free backing" brake which is commonly used on trailers with a surge hitch system. When

backing with a surge brake hitch, normal brakes are applied through the surge mechanism and

if there is more brake force on the trailer than the tow vehicle can override, no backing is possible. The free backing brake was developed to allow backing in this application. This brake has a primary shoe on a pivot which allows normal application in the forward direction, but allows the



primary shoe to rotate away from the drum surface when backing.

Self Adjusting Mechanism for 12¹/4" Hydraulic Brakes

Forward self-adjust hydraulic brakes were introduced in March, 1997. This feature adjusts the brakes on both forward and reverse stops. Brake adjustment occurs only when lining wear results in enough gap between the shoes and the drum surface. This added clearance will allow the adjuster mechanism to rotate the screw assembly at the bottom of the brake. That action expands the distance between the shoes and thus closes the gap to the drum surface.

Hydraulic Parking Brake Option (Not Available on All Sizes)

The parking feature on Dexter hydraulic brakes is cable operated. On the 10" and 12" brakes, the parking cable body is mounted to the brake backing plate. The cable end is attached to the internal parking brake lever to actuate the brake. On Dexter 12¹/₄" brakes manufactured before February 2002, the parking cable body mounts to a support plate which is attached to the brake mounting flange. The cable end is routed through the dust shield and the brake spider, to attach to the internal parking brake lever. For 12¹/₄" brakes produced after February 2002, a short cable is






installed directly into the backing plate to provide a convenient means for the trailer manufacturer to attach an appropriate operating system.

The internal parking brake lever of 10" and 12" Dexter brakes, which is mounted to the secondary shoe, transfers applied cable force through a parking strut which is attached to the primary shoe. This transferred load generates a spreading force between the primary and secondary shoes. The shoes move toward the drum until contact is made. Friction generated between the drum and lining contact surface results in parking brake capability.

The internal parking brake lever of Dexter 12¹/₄" brakes transfers the applied cable force through a cam mechanism. The cam mechanism generates a spreading force between the primary and secondary shoes. The shoes move toward the drum until contact is made. Friction generated between the drum and lining contact surface results in parking brake capability.



Braking Systems - Hydraulic

Disc Brakes

Dexter Axle manufactures two types of disc brakes, the floating caliper and the fixed caliper brake. With both styles, the disc brake uses friction pads astride a ventilated rotor which is attached to the wheel hub. When the brake is actuated, the pads are pressed against the sides of the rotor causing drag to slow the rotating disc. This action converts the kinetic energy (motion) into heat. The heat is dissipated rapidly by the ventilated disc.

The floating caliper brake uses piston(s) situated on one side of the brake rotor. Hydraulic fluid pressure pushes against the piston(s) to apply the inboard brake pad. As the inboard pad exerts force against the rotating rotor surface, the caliper moves laterally towards the trailer frame and in turn applies an equivalent force to the outboard brake pad against the rotor surface. As the lining material wears, the caliper will automatically maintain the proper lining to rotor clearance. The floating caliper design is used on Dexter 3,500 lb., 10,000 lb., and 12,000 lb. axle models.

The fixed caliper method uses pistons situated on both sides of the rotor. During actuation,

hydraulic pressure pushes against the pistons to apply the inboard and outboard brake pads equally to decelerate the rotating rotor. The caliper is fixed and stays stationary during brake actuation and brake adjustment. Brake pad to rotor clearance is maintained as lining wear occurs via the brake piston and internal caliper seal. The fixed caliper design is used on the Dexter 6,000 lb. and 8,000 lb. axle models.

Disc brake effectiveness is the same going either in a forward or reverse direction. All Dexter disc brakes should be actuated with a braking system that is capable of providing a maximum hydraulic pressure of 1,600 psi.







Actuation Systems


To effectively operate your hydraulic trailer brakes we recommend the Dexter E/H electro/hydraulic actuator, controlled by the Predator series DX2[™] electronic brake controller. These high performance hydraulic power modules will supply pressurized brake fluid to your trailer brakes in proportion to the amount of braking effort called for by the towing vehicles' deceleration rate.

CAUTION

It is the responsibility of the end user to ensure that their in-cab electronic controller is compatible with the Dexter E/H actuator. Dexter Axle attempts to provide compatibility with most controllers available, but is unable to anticipate design changes that might be introduced by the various controller manufacturers.

The E/H 1000 will supply 1000 psi for your drum brakes and the E/H 1600 will generate 1600 psi for maximum performance from your Dexter disc brakes. The sealed, weather tight housing contains the electronics necessary to control the high pressure piston pump and proportioning valve for smooth, efficient braking.

ELECTRICAL SCHEMATIC



Braking Systems - Hydraulic

Troubleshooting Guide

Brakes are slow to respond

- 1. Re-bleed the trailer brakes and actuator.
- 2. If the trailer is equipped with drum brakes, readjust the drum brakes to the brake manufacture's recommended running clearance.
- 3. Slow response can be caused by trailer wiring that is too small.
- 4. For trailers where the E/H unit is located less than 10 feet from the tow vehicle, 12 gage wire is recommended for the black and white wires between the tow vehicle and the E/H unit. All other wires should be a minimum of 16 gauge.
- 5. For trailers where the E/H unit is located more than 10 feet from the tow vehicle, 10 gage wire is recommended for the black and white wires between the tow vehicle and the E/H unit. All other wires should be a minimum of 16 gauge.
- 6. Slow response can be caused by improper adjustment of the brake controller. On inertia-based electronic brake controls, adjust the pendulum (inertia sensor) to a more aggressive setting and/or increase the gain setting.

Unit will not run when the ignition is on and the brake pedal is depressed

- 1. Verify that the trailer and tow vehicle are wired as detailed on the electrical schematic.
- 2. With the ignition switch on and the brakes not applied, you should have 12-13 volts between the black and white wires on the E/H unit.
- 3. Clean and replace the ground between the trailer and the E/H unit.
- 4. Test operation of the unit using the breakaway test procedure.

Breakaway test procedure - do not leave the breakaway switch pulled for more than two minutes during any of the steps outlined below

- 1. Pull the breakaway switch on the trailer.
- 2. If the unit runs and builds pressure, that indicates the





actuator is functioning properly. The problem most likely is a defective electronic brake controller in the tow vehicle or defective wiring between the tow vehicle and the E/H unit.

- 3. If the unit runs but will not build pressure, the problem most likely is a defective solenoid valve in the E/H unit and the actuator should be returned for repair.
- 4. If the unit still does not run after the breakaway battery is fully charged, verify that the voltage between the white wire and yellow wire is at least 12 volts.
- 5. If the voltage is less than 12 volts, either the breakaway switch or the breakaway wiring is defective.
- 6. If the voltage is greater than 12 volts, the E/H unit should be returned for repair.

Trailer brakes too aggressive

1. Reduce the gain setting on the in-cab electronic brake controller.

General Maintenance - Hydraulic Brakes Drum Brake Adjustment - Manual

Most Dexter 12¹/₄" electric brakes have a self adjusting feature. If manual adjusting is required, use the following procedure:

Brakes should be adjusted (1) after the first 200 miles of operation when the brake shoes and drums have "seated," (2) at 3,000 mile intervals, (3) or as use and performance requires. The brakes should be adjusted in the following manner:

 Jack up trailer and secure on adequate capacity jack stands. Follow trailer manufacturer's recommendations for lifting and supporting the unit. Make sure the wheel and drum rotates freely.

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.

- 2. Remove the adjusting hole cover from the adjusting slot on the bottom of the brake backing plate.
- 3. With a screwdriver or standard adjusting tool, rotate the starwheel of the adjuster assembly to expand the brake shoes. Adjust the brake shoes out until the pressure of the linings against the drum makes the wheel very difficult to turn.

Note: For drop spindle axles, a modified adjusting tool may be necessary.

- 4. Then rotate the starwheel in the opposite direction until the wheel turns freely with a slight lining drag.
- 5. Replace the adjusting hole cover and lower the wheel to the ground.
- 6. Repeat the above procedure on all brakes. For best results, the brakes should all be set at the same clearance.





Most of the brake components are very similar to those used in electric brakes, and maintenance is comparable for the hub and drum, shoes and linings, and bearings. Specific maintenance activities are as follows:

Wheel Cylinders

Inspect for leaks and smooth operation. Clean with brake cleaner and flush with fresh brake fluid. Hone or replace as necessary.

Brake Lines

Check for cracks, kinks, or blockage. Flush with fresh brake fluid. Bleed system to remove all air. Replace as necessary.

Shoes and Linings

A simple visual inspection of your brake linings will tell if they are usable. Replacement is necessary if the lining is worn (to within ¹/₁₆" or less), contaminated with grease or oil, or abnormally scored or gouged. Hairline heat cracks are normal in bonded linings and should not be cause for concern. When replacement is necessary, it is important to replace both shoes on each brake and both brakes of the same axle. This will help retain the "balance" of your brakes.

POTENTIAL ASBESTOS DUST HAZARD! Some older brake linings may contain asbestos dust, which has been linked to serious or fatal illnesses. Certain precautions need to be taken when servicing

brakes:

- 1. Avoid creating or breathing dust.
- 2. Avoid machining, filing or grinding the brake linings.
- 3. Do not use compressed air or dry brushing for cleaning (dust can be removed with a damp brush).

raking Systems - Hydraulic

After replacement of brake shoes and linings, the brakes must be re-burnished to seat in the new components. This should be done by applying the brakes 20 to 30 times from an initial speed of 40 m.p.h., slowing the vehicle to 20 m.p.h. Allow ample time for brakes to cool between applications. This procedure allows the brake shoes to seat in to the drum surface.

Hardware

Check all hardware. Check shoe return spring, hold down springs, and adjuster springs for stretch or wear. Replace as required. Service kits are available.

Instructions for Brake Caliper Kit 3.5K Disc Hydraulic Brakes

Notice to Buyer

It is recommended that all brakes be replaced at the same time to insure balanced braking performance.

Remove the old brake caliper

1. Jack up trailer and secure on adequate capacity jack stands. Follow trailer manufacturers recommendations for lifting and supporting the unit.

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.

- 2. Remove the wheel from the hub, leaving the brake exposed.
- 3. Disconnect the brake actuation system. Check that the hydraulic system has zero pressure and that the hub and rotor rotates freely.





4. Remove the hose from the caliper. Then remove the two caliper mounting bolts. <u>Do not allow the caliper to hang from the hose.</u>

Installing the new brake caliper

- First inspect the brake assembly for grooves, flaking, cracks, heat checking, thickness variation, insufficient rotor thickness, and look to see that the mounting hardware is straight. Replace any component as needed (or desired) per manufacturer recommendations.
- 2. Install the new caliper assembly. <u>Make sure that the bleed</u> <u>screw points up.</u>
- 3. Remount the caliper assembly onto the caliper attaching bracket. Ensure that there is thread locking compound on the threads of the new mounting bolts. Torque mounting bolts to **40-50 Ft. Lbs.** *Note: Use two lug nuts to secure rotor against the hub face when reassembling the caliper. After the caliper is assembled remove the lug nuts.*
- 4. Reconnect the hose to the elbow adapter on the back of the caliper and torque to **10-12 Ft. Lbs.**
- 5. Reconnect the brake actuation system. Refer to your actuation systems *Operation Maintenance Service Manual* for proper operation.
- 6. Bleed and flush brake system per your actuation systems *Operation Maintenance Service Manual.*
- 7. Remount the wheel. Refer to your *Operation Maintenance Service Manual* for proper wheel nut torque procedures.

Instructions for Brake Rotor Kit 3.5K Disc Hydraulic Brakes

Notice to Buyer

It is recommended that all brakes be replaced at the same time to insure balanced braking performance.

Remove the old brake rotor

1. Jack up trailer and secure on adequate capacity jack stands. Follow trailer manufacturers recommendations for lifting and supporting the unit.

Braking Systems - Hydraulic

Braking Systems - Hydraulic

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.

- 2. Remove the wheel from the hub, leaving the brake exposed.
- 3. Disconnect the brake actuation system. Check that the hydraulic system has zero pressure and that the hub and rotor rotates freely.
- 4. Remove the two caliper mounting bolts. <u>Do not allow the</u> <u>caliper assembly to hang from the hose.</u> <u>Do not disconnect</u> <u>the hose or allow air into the hydraulic system.</u>
- 5. With the caliper assembly out of the way remove the brake rotor. Save the brake mounting hardware for reinstalling the brake calipers.

Installing the new brake rotor

- First inspect the brake assembly for grooves, flaking, cracks, heat checking, thickness variation, insufficient rotor thickness, and look to see that the mounting hardware is straight. Replace any component as needed (or desired) per manufacturer recommendations.
- 2. Install the new brake rotor by fitting it onto the hub flush with the hubface.
- 3. Remount the caliper assembly onto the caliper attaching bracket. Place thread locking compound on threads of mounting bolts. Torque mounting bolts to **40-50 Ft. Lbs.**

Note: Use two lug nuts to secure rotor against the hub face when reassembling the calipers. After the calipers are assembled remove the lug nuts.

- 4. Reconnect the brake actuation system. Refer to your *Operation Maintenance Service Manual* for proper operation.
- 5. Remount the wheel. Refer to your *Operation Maintenance Service Manual* for proper wheel nut torque procedures.





Instructions for Brake Rotor Kit 6K or 8K Disc Hydraulic Brakes

Notice to Buyer

It is recommended that all brakes be replaced at the same time to insure balanced braking performance.

Remove the old brake rotor

1. Jack up trailer and secure on adequate capacity jack stands. Follow trailer manufacturers recommendations for lifting and supporting the unit.

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.

- 2. Remove the wheel from the hub, leaving the brake exposed.
- Disconnect the brake actuation system. Check that the hydraulic system has zero pressure and that the hub and rotor rotates freely.
- 4. Remove the four caliper mounting bolts. <u>Do not allow the</u> <u>caliper assembly to hang from the hose</u>. <u>Do not disconnect</u> <u>the hose or allow air into the hydraulic system</u>.
- 5. With the caliper assembly out of the way remove the brake rotor. Save the brake mounting hardware for reinstalling the brake calipers.

Installing the new brake rotor

- 1. First inspect the brake assembly for grooves, flaking, cracks, heat checking, thickness variation, insufficient rotor thickness, and look to see that the mounting hardware is straight. Replace any component as needed (or desired) per manufacturer recommendations.
- 2. Install the new brake rotor by fitting it onto the hub flush with the hubface. *Note: Use two lug nuts to secure rotor*

Braking Systems - Hydraulic

against the hub face when reassembling the calipers. After the calipers are assembled remove the lug nuts.

- 3. Remount the caliper assembly onto the caliper attaching bracket. It may be necessary to push the piston into the calipers to obtain enough clearance. Torque mounting bolts to **25-35 Ft. Lbs.**
- 4. Spin the rotor to ensure that there is enough clearance between the rotor and the crossover brake line.
- 5. Reconnect the brake actuation system. Refer to your *Operation Maintenance Service Manual* for proper operation.
- 6. Remount the wheel. Refer to your *Operation Maintenance Service Manual* for proper wheel nut torque procedures.
- 7. Spin the wheel to ensure that there is enough clearance between the wheel, crossover brake line, and rotor.

Instructions for Brake Pad Kit 6K or 8K Disc Hydraulic Brakes

Notice to Buyer

It is recommended that all brakes be replaced at the same time to insure balanced braking performance.

Remove the old brake pads

1. Jack up trailer and secure on adequate capacity jack stands. Follow trailer manufacturers recommendations for lifting and supporting the unit.

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.





- 2. Remove the wheel from the hub, leaving the brake exposed.
- 3. Disconnect the brake actuation system. Check that the hydraulic system has zero pressure and that the hub and rotor rotates freely.
- 4. Remove the brake pad retaining bolt.
- 5. Remove the old pads from the caliper assembly. Save the brake pad retaining hardware for reinstalling the new pads onto the caliper.

POTENTIAL ASBESTOS DUST HAZARD! Some older brake linings may contain asbestos dust, which has been linked to serious or fatal illnesses. Certain precautions need to be taken when servicing brakes:

- 1. Avoid creating or breathing dust.
- 2. Avoid machining, filing or grinding the brake linings.
- 3. Do not use compressed air or dry brushing for
 - cleaning (dust can be removed with a damp brush).

Installing the new brake pads

- First inspect the brake assembly for grooves, flaking, cracks, heat checking, thickness variation, insufficient rotor thickness, and look to see that the mounting hardware is straight. Replace any component as needed (or desired) per manufacturer recommendations.
- 2. Press the caliper pistons into the calipers until enough clearance is available to fit the new pads between the pistons and the rotor. *Note: Use two lug nuts to secure rotor against the hub face when reassembling the new pads. After the pads are assembled remove the lug nuts.*
- 3. Install the new brake pads by sliding them in one at a time between the caliper pistons and the rotor. The pads are the same for the inner and outer side of the rotor. <u>Make sure the brake lining side of the pad faces the rotor, and the steel backing faces the caliper pistons.</u>

- 4. Align the brake pad mounting holes with the holes in the caliper. Insert the brake pad retaining bolt and tighten nut until snug against shoulder of bolt.
- 5. Reconnect the brake actuation system. Refer to your *Operation Maintenance Service Manual* for proper operation.
- 6. Remount the wheel. Refer to your *Operation Maintenance Service Manual* for proper wheel nut torque procedures.

Instructions for Brake Caliper Kit 6K or 8K Disc Hydraulic Brakes

Notice to Buyer

It is recommended that all brakes be replaced at the same time to insure balanced braking performance.

Remove the old brake pads

1. Jack up trailer and secure on adequate capacity jack stands. Follow trailer manufacturers recommendations for lifting and supporting the unit.

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.

- 2. Remove the wheel from the hub, leaving the brake exposed.
- 3. Disconnect the brake actuation system. Check that the hydraulic system has zero pressure and that the hub and rotor rotates freely.
- 4. Remove the hose from the caliper, then remove the four caliper mounting bolts. <u>Do not allow the caliper to hang</u> from the hose.





Installing the new brake caliper

- 1. First inspect the brake assembly for grooves, flaking, cracks, heat checking, thickness variation, insufficient rotor thickness, and look to see that the mounting hardware is straight. Replace any component as needed (or desired) per manufacturer recommendations.
- 2. Assemble the new caliper assembly. *Note: Use two lug nuts to secure rotor against the hub face when reassembling the calipers. After the brake is assembled remove the lug nuts.*
- One caliper will be used on the inboard side, with the hydraulic line fitting adapter installed on the top side of the piston boss. The other caliper will be used on the outboard side with the bleed screw installed at the top of the piston boss. Install both of these calipers onto the attaching bracket. <u>Make sure that the bleed screw points up and is</u> <u>located on the outboard caliper.</u> Torque bolts to 25-35 Ft. Lbs.
- Connect the new crossover brake line on the bottom sides of the piston boss on both calipers. *Note: Make sure the crossover line fits snug around the calipers and rotor without touching the rotor.* Spin the rotor to ensure there is <u>proper clearance.</u> Torque the crossover line to 12-15 Ft. Lbs. Torque the bleed screw and the hydraulic line fitting adapter to 60-76 Inch Lbs.
- 5. Reassemble the brake pads into the disc brake. Make sure to locate the brake lining side of the pads toward the rotor surface, and the steel side of the pads toward the calipers. Align the holes in the brake pads with the ones in the calipers. Insert the brake pad retaining bolt and tighten nut until snug against shoulder of bolt.
- 6. Reconnect the brake actuation system. Refer to your *Operation Maintenance Service Manual* for proper operation.
- 7. Bleed and flush brake system per your actuation systems *Operation Maintenance Service Manual.*
- 8. Remount the wheel. Refer to your *Operation Maintenance Service Manual* for proper wheel nut torque procedures.
- 9. <u>Spin wheel to ensure proper clearance between the wheel,</u> <u>crossover brake line, and the rotor.</u>

Braking Systems - Hydraulic

Introduction to Troubleshooting

Proper brake function is critical to the safe operation of any vehicle. A properly installed vacuum/hydraulic, electric/hydraulic or air/hydraulic system should not require any special attention with the exception of routine maintenance as defined by the manufacturer. If problems occur, the entire tow vehicle/trailer braking system should be analyzed by a qualified mechanic. Typical problems in a hydraulic braking system are:

- Air or vacuum leaks
- Hydraulic system leaks
- Air in brake lines
- Water or other impurity in brake fluid
- Rusted or corroded master or wheel cylinders
- Actuation system malfunction

Please consult the following troubleshooting charts to determine the causes and solutions for common problems found in trailer braking systems.

CAUTION


The operating pressure required for Dexter brakes:

- 7" diameter brakes maximum operating pressure is 750 psi
- 10" diameter and larger maximum operating pressure is 1,000 psi






Troubleshooting



traking Systems - Hydraulic

Troubleshooting







Hubs/Drums/Bearings

Dexter Axle offers several types of bearing arrangements and lubrications methods.

• Dexter's standard wheel bearing configuration consists of opposed tapered roller bearing cones and cups, fitted inside of a precision machined cast hub. This method of using tapered roller bearings requires that a minimal amount of axial end play be provided at assembly. This end play is essential to the longevity of the bearings service life. This design is typically lubricated with grease, packed into the bearings. Oil lubrication is another method which is available in some of the larger axle capacities.

• E-Z Lube® is another option chosen by some trailer manufacturers. If your axle is equipped with the Dexter E-Z Lube® feature, the bearings can be periodically lubricated without removing the hubs from the axle. This feature consists of axle spindles that have been specially drilled and assembled with grease fittings in their ends. When grease is pumped into the fitting, it is channeled to the inner bearing and then flows back to the outer bearing and eventually back out the grease cap hole.

• Nev-R-Lube[™] option is the latest innovation from Dexter. Nev-R-Lube[™] bearings are comprised of opposed tapered roller bearing cones sealed inside of a precision ground, one piece double cup arrangement. These bearings are designed with a small amount of axial end play. This end play is essential to the longevity of the bearings service life. They are lubricated, assembled and sealed at the factory. No further lubrication is ever needed.

Before attempting any disassembly of your Dexter axle, make sure you read and follow the instructions for the appropriate axle type.

Hub Removal - Standard Bearings

Whenever the hub equipment on your axle must be removed for inspection or maintenance the following procedure should be utilized.

1. Elevate and support the trailer unit per manufacturers' instructions.

Hubs/Drums/Bearings

You must follow the maintenance procedures to prevent damage to important structural components. Damage to certain structural components such as wheel bearings can cause the wheel end to come off of the axle. Loss of a wheel end while the trailer is moving can cause you to lose control and lead to an accident, which can result in serious injury or death.

- 2. Remove the wheel.
- 3. Remove the grease cap by carefully prying progressively around the flange of the cap. If the hub is an oil lube type, then the cap can be removed by unscrewing it counterclockwise while holding the hub stationary.
- 4. Remove the cotter pin from the spindle nut.

For E-Z Lube® axles produced after February 2002, a new type of retainer is used. Gently pry off retainer from the nut and set aside.

- 5. Unscrew the spindle nut (counterclockwise) and remove the spindle washer.
- 6. Remove the hub from the spindle, being careful not to allow the outer bearing cone to fall out. The inner bearing cone will be retained by the seal.
- 7. For 7,200 lb. and 8,000 lb. axles, a hub puller may be necessary to assist in drum removal.

Brake Drum Inspection

There are two areas of the brake drum that are subject to wear and require periodic inspection. These two areas are the drum surface where the brake shoes make contact during stopping and the armature surface where the magnet contacts (only in electric brakes).

The drum surface should be inspected for excessive wear or heavy scoring. If worn more than .020" oversized, or the drum has worn out of round by more than .015", then the drum surface should be re-machined. If scoring or other wear is greater than





.090" on the diameter, the drum must be replaced. When turning the drum surface, the maximum rebore diameter is as follows:

- 7" Brake Drum-7.090" diameter
- 10" Brake Drum-10.090" diameter
- 12" Brake Drum-12.090" diameter
- 12¹/₄" Brake Drum-12.340" diameter
- 6K and 8K Rotor-1.03" minimum thickness
- 3.5K Rotor-.85" minimum thickness

The machined inner surface of the brake drum that contacts the brake magnet is called the armature surface. If the armature surface is scored or worn unevenly, it should be refaced to a 120 micro inch finish by removing not more than .030" of material. To insure proper contact between the armature face and the magnet face, the magnets should be replaced whenever the armature surface is refaced and the armature surface should be refaced whenever the magnets are replaced.

Note: It is important to protect the wheel bearing bores from metallic chips and contamination which result from drum turning or armature refacing operations. Make certain that the wheel bearing cavities are clean and free of contamination before reinstalling bearing and seals. The presence of these contaminants will cause premature wheel bearing failure.

Bearing Inspection

Wash all grease and oil from the bearing cone using a suitable solvent. Dry the bearing with a clean, lint-free cloth and inspect each roller completely.

CAUTION


Never spin the bearing with compressed air. THIS CAN DAMAGE THE BEARING.

If any pitting, spalling, or corrosion is present, then the bearing must be replaced. The bearing cup inside the hub must be inspected. **IMPORTANT:** Bearings must always be replaced in sets of a cone and a cup.

Be sure to wear safety glasses when removing or installing force fitted parts. Failure to comply may result in serious eye injury.

When replacing the bearing cup proceed as follows:

- 1. Place the hub on a flat work surface with the cup to be replaced on the bottom side.
- 2. Using a brass drift punch, carefully tap around the small diameter end of the cup to drive out.
- 3. After cleaning the hub bore area, replace the cup by tapping in with the brass drift punch. *Be sure the cup is seated all the way up against the retaining shoulder in the hub.*



Bearing Lubrication - Grease

Along with bearing adjustment, proper lubrication is essential to the proper function and reliability of your trailer axle. Bearings should be lubricated every 12 months or 12,000 miles. The method to repack bearing cones is as follows:

- 1. Place a quantity of grease into the palm of your hand.
- 2. Press a section of the widest end of the bearing into the outer edge of the grease pile closest to the thumb forcing grease into the interior of the bearing.





Hubs/Drums/Bearings



- 3. Repeat this while rotating the bearing from roller to roller.
- 4. Continue this process until you have the entire bearing completely filled with grease.
- 5. Before reinstalling, apply a light coat of grease on the bearing cup.

Bearing Lubrication - Oil

If your axles are equipped with oil lubricated hubs, periodically check and refill the hub as necessary with a high quality hypoid gear oil to the level indicated on the clear plastic oil cap. The oil can be filled from either the oil fill hole, if present, in the hub or through the rubber plug hole in the cap itself.

Recommended Wheel Bearing Lubrication Specifications

Grease:

	Lithium Complex
Dropping Point	
Consistency	NLGI No. 2
	EP, Corrosion & Oxidation Inhibitors
Viscosity Index	
Approved Sources:	
Mobil Oil	Mobilgrease HP, Mobilith AW2
Exxon/Standard	
	Kendall L-427 Super Blu
Ashland Oil Co	Valvoline Multipurpose GM
76 Lubricants	
Citgo Petroleum	Lithoplex MP#2
Mystik	Mystik JT-6 Hi Temp Grease

Oil:

SAE 90, SAE 80W-90, SAE 75W-90


Approved Sources:

Union Oil Co.	Unocal MP Gear Lube
Exxon Co. USA	Gear Oil GX 80W-90
Mobil Oil Corp	Mobilube SHC 75W-90
•	Gear Plus 80W-90 GL-5
	Gear Plus Super 75W-90

Note: The convenient lubrication provisions of the *E-Z* Lube® and the oil lubrication must not replace periodic inspection of the bearings.

Seal Inspection and Replacement

Whenever the hub is removed, inspect the seal to assure that it is not nicked or torn and is still capable of properly sealing the bearing cavity. If there is any question of condition, replace the seal. Use only the seals specified in the Seal Replacement Chart. To replace the seal:




Bad Seal: Nicks and Tears (REPLACE SEAL)

- 1. Pry the seal out of the hub with a screwdriver. Never drive the seal out with the inner bearing as you may damage the bearing.
- 2. Apply a PERMATEX sealant to the outside of the new seal.

Note: Permatex sealant should not be used on rubber encased seals.

3. Tap the new seal into place using a clean wood block.









Bearing Adjustment and Hub Replacement


If the hub has been removed or bearing adjustment is required, the following adjustment procedure must be followed:

- 1. After placing the hub, bearings, washers, and spindle nut back on the axle spindle in reverse order as detailed in the previous section on hub removal, rotate the hub assembly slowly while tightening the spindle nut to approximately 50 lbs.-ft. (12" wrench or pliers with full hand force.)
- 2. Then loosen the spindle nut to remove the torque. *Do not rotate the hub.*
- 3. Finger tighten the spindle nut until just snug.
- 4. Back the spindle nut out slightly until the first castellation lines up with the cotter key hole and insert the cotter pin.
- 5. Bend over the cotter pin legs to secure the nut.
- 6. Nut should be free to move with only restraint being the cotter pin.

For E-Z Lube® axles using the new nut retainer:

- 1. Finger tighten the nut until just snug, align the retainer to the machined flat on the spindle and press the retainer onto the nut. The retainer should snap into place. Once in place, the retainer/nut assembly should be free to move slightly.
- 2. If the nut is too tight, remove the retainer and back the nut off approximately one twelfth of a turn and reinstall the retainer. The nut should now be free to move slightly.
- 3. Reinstall grease cap.

Typical E-Z Lube® After Spring 2002



ubs/Drums/Bearings


Hubs/Drums/Bearings

E-Z Lube® Lubrication

The procedure is as follows:

- 1. Remove the rubber plug from the end of the grease cap.
- 2. Place a standard grease gun onto the grease fitting located in the end of the spindle. Make sure the grease gun nozzle is fully engaged on the fitting.
- 3. Pump grease into the fitting. The old displaced grease will begin to flow back out the cap around the grease gun nozzle.
- When the new clean grease is observed, remove the grease gun, wipe off any excess, and replace the rubber plug in the cap.
- 5. Rotate hub or drum while adding grease.

Note: The E-Z Lube® feature is designed to allow immersion in water. Axles not equipped with E-Z Lube® are not designed for immersion and bearings should be repacked after each immersion. If hubs are removed from an axle with the E-Z Lube® feature, it is imperative that the seals be replaced BEFORE bearing lubrication. Otherwise, the chance of grease getting on brake linings is greatly increased.








Nev-R-Lube[™] Drums/Bearings

Dexter's Nev-R-Lube[™] bearings are comprised of opposed tapered roller bearing cones sealed inside of a precision ground, one piece double cup arrangement. These bearings are designed with a small amount of axial end play. This end play is essential to the longevity of the bearings service life.



Drum Removal

Whenever the hub equipment on your axle must be removed for inspection or maintenance, the following procedure should be utilized.

1. Elevate and support the trailer unit per manufacturer's instructions.

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.

- 2. Remove the wheel.
- 3. Remove the grease cap from the hub by carefully prying progressively around the flange.
- 4. Remove snap ring on the end of the spindle. Remove "torque instruction" washer.
- 5. Unscrew the spindle nut (counterclockwise) and remove the spindle washer.
- Carefully remove the hub from the spindle. The Nev-R-Lube[™] bearing cartridge will remain in the hub.

Note: Do not remove cartridge bearing from the hub bore unless replacement of the bearing cartridge is intended. Special tools and techniques are required for removal of the old bearing.

Bearing Inspection

Important:

 Elevate and support the trailer unit per manufacturer's instructions.

A CAUTION

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.





- 2. Check for excessive wheel end clearance by pulling the tire assembly towards you and by pushing the assembly away from you. Slight end play is acceptable.
- 3. Rotate tire slowly forwards and backwards. The wheel assembly should turn freely and smoothly.
- Excessive wheel end play, restriction to rotation, noise, or "bumpy" rotation should be remedied by replacing the bearing unit.
- 5. Bearing units should be inspected every year or 12,000 miles whichever comes first.

Note: A slight amount of grease weeping from the seal area is normal. Excessive leakage may indicate abnormal bearing operation.

Nev-R-Lube™ Bearing End Play Inspection

The following lists the maximum axial end play for each of the sizes of Nev-R-Lube[™] bearings and the amount of tilt that can be expected. Since there are a large number of wheel and tire combinations in use on trailers, the tilt is expressed in inches per inch. The movement as measured at the tire tread can be found by the following method:


<u>Example</u>: if the tilt value is shown as .003" per inch and the tire measures 30" in diameter, simply multiply .003" X 15" (1/2 tire diameter) = .045" which is the total expected movement at the tires' outer diameter.

Bearing size	End play	Resultant tilt value
35 MM	.005" axial	.003"/ per inch
42 MM	.006" axial	.005"/ per inch
50 MM	.008" axial	.004"/ per inch

It is important to note that most mounted tires will deflect fairly easily when enough hand pressure is applied while shaking the tire. Excessive pressure will result in the perception that the bearings' tilt is greater than it actually is. This same phenomenon will occur when checking any wheel end, even those equipped with conventional bearing sets.

Bearing Replacement and Drum Installation

- 1. Once the drum and bearing assembly is removed from the axle, remove "internal" snap ring from the bearing bore that retains bearing.
- 2. Using an arbor press and mandrel, press the bearing out of the drum. Bearing will exit on the wheel side of the drum.
- 3. When replacing a Nev-R-Lube[™] bearing pack, the bore in the hub should be cleaned and inspected for visual damage (replace as necessary).
- 4. Install the new bearing using an arbor press fitted with a hollow or stepped punch face to press only on the outer housing of the bearing. Failure to follow procedure will damage the bearing and/ or seals during installation. Press bearing until it seats against the backup shoulder machined into the hub.



- 5. Install "internal" snap ring into hub.
- 6. Clean and inspect spindle shaft. Apply a light coating of anti-seize lubricant to the spindle shaft prior to assembling drum.
- 7. Install drum assembly onto spindle (Do Not Force).
- 8. Install steel washer onto spindle end.
- 9. Start self-locking nut onto spindle thread by hand. Complete installation using a $1\frac{1}{2}$ " or $1^{7}/_{16}$ " socket and torque wrench.



Hubs/Drums/Bearings



Nut should be torqued to 145-155 lb.-ft. (this torque will set the internal bearing adjustment, no other adjustments are to be made).

- 10. Install "torque instruction" washer onto end of spindle.
- 11. Install "external" snap ring onto end of spindle to retain washer.
- 12. Inspect assembly for excessive end play, noise, and rotation restriction prior to mounting final wheel end hardware.

Suspensions

Suspension Systems


The suspension systems incorporated into Dexter axles are designed to provide the trailer owner three basic functions:

- 1. Attach the axle to the trailer
- 2. Dampen the effects of road shock
- 3. Cushion the cargo or load

All Dexter suspension systems are available in single and multiple axle configurations. The three types most commonly available are double eye leaf spring, slipper spring and Torflex®.

Double Eye Leaf Springs

Double eye springs have eyes formed in each end of the spring with anti-friction bushings fitted for wear resistance. The springs are held to the axle tube using a system of U-bolts and clamp plates and are attached to the trailer as shown.



Underslung Shown

Articulation of this suspension occurs when the spring becomes loaded and consequently lengthens. The double pivot action of the shackle links accommodates this articulation and allows the system to move freely.

In multiple axle installations, the action is the same with the additional movement of the equalizer assembly. This serves to transfer instantaneous loads from one axle to another in an effort to "equalize" the load between the axles.





Grease Lubricated Suspension Bushings


Dexter Axle offers an optional heavy duty attaching parts kit for double eye leaf spring suspensions up to 7,000 lb. axle capacity. The kit contains extra heavy shackle links, bronze bushings for the spring eyes and suspension bolts and equalizers equipped with grease fittings to provide a convenient means to lubricate all the pivot points. For availability, contact your nearest Dexter Axle facility or visit us online at **www.dexteraxle.com** for a complete listing of genuine repair parts.

Slipper Leaf Springs

Slipper springs have an eye formed in one end only with the other end formed into a reverse curve. The attachment of these springs is as follows:

- 1. The front eye is attached directly into the front hanger with a bolt and nut.
- 2. The rear end of the spring is captured in the rear hanger or equalizer with a "keeper bolt" that prevents the spring from coming out when the trailer is jacked up for service.

The articulation of this suspension occurs when the rear end of each slipper spring slides against the wear surfaces provided in the rear hangers or equalizers. This suspension is also available in single and multiple axle configurations.



Overslung Shown

Suspensions

Suspensions

Inspection and Replacement

All the components of your suspension system should be visually inspected at least every 6,000 miles for signs of excess wear, elongation of bolt holes, and loosening of fasteners. Whenever loose or replaced, the fasteners in your suspension system should be torqued as detailed in the charts below.

A CAUTION

You must follow the maintenance procedures to prevent damage to important structural components. Damage to certain structural components such as wheel bearings can cause the wheel to come off of the axle. Loss of a wheel end while the trailer is moving can cause you to lose control and lead to an accident, which can result in serious injury or death.

Torque (Ibsft.)				
Item	Min	Max		
³ /8" U-Bolt	30	50		
⁷ / ₁₆ " U-Bolt	45	70		
¹ /2" U-Bolt	45	70		
⁹ /16" U-Bolt	65	95		
⁵/ଃ" U-Bolt	100	120		
Non shoulder type	with 9/16" threa	ıds		
Shackle Bolt Snug fit only. Parts must rotate freely. Locking nuts				
Spring Eye Bolt	or cotter pins a	re provided	to retain nut-bolt	
Equalizer Bolt	assembly.			
Shoulder Type	30	50		
Shackle Bolt with 7/16" threads				

Suspension Fastener Torque Values

Worn spring eye bushings, sagging springs, or broken springs should be replaced using the following method.

1. Support the trailer with the wheels just off the ground.





Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.

- 2. After the unit is properly supported place a suitable block under the axle tube near the end to be repaired. This block is to support the weight of the axle only, so that suspension COMPONENTS can be removed.
- 3. Disassemble the U-bolts, nuts, and tie plates.
- 4. Remove the spring eye bolts and remove the spring and place on a suitable work surface.
- 5. If the spring eye bushings are to be replaced, drive out the old bushing using a suitable drift punch.

Be sure to wear safety glasses when removing or installing force fitted parts. Failure to comply may result in serious injury.

- 6. Drive the new bushing into the spring eye using a piloted drift punch or a close fitting bolt inserted through the bushing.
- 7. Reinstall repaired or replaced components in reverse order.

Note: For multiple axle units, the weight of each axle must be supported as outlined in Step 2 before disassembly of any component of the suspension system.

If the equalizer or equalizer bushings must be replaced, follow the instructions above for lifting and supporting the trailer unit and then proceed as follows:

Suspensions


- 1. With both axles blocked up, remove the spring eye bolt, shackle bolt, and equalizer bolt from the equalizer to be repaired or replaced.
- 2. Take the equalizer to suitable work surface and remove the worn bushings using a suitable drift punch.
- 3. Drive the new bushings into place using a piloted drift punch or a close fitting bolt through the bushing.
- 4. Reassemble in reverse order.

Be sure to wear safety glasses when removing or installing force fitted parts. Failure to comply may result in serious injury.

All of the pivot points on your standard suspension system have been fitted with anti-friction bearing materials which do not require routine lubrication. When otherwise servicing the unit, these pivot points may be lubricated if you so desire. If your trailer has been fitted with the Heavy Duty Attaching Parts Kit, you should lubricate periodically to ensure long component life.

Torflex® Suspension

The Torflex® suspension system is a torsion arm type suspension which is completely self contained within the axle tube. It attaches directly to the trailer frame using brackets which are an integral part







surrounded by four natural rubber cords encased in the main structural member of the axle beam.

The wheel/hub spindle is attached to a lever, called the torsion arm, which is fastened to the rubber encased bar. As load is applied, the bar rotates causing a rolling/compressive resistance in the rubber cords. This action provides the same functions as conventional sprung axles with several operating advantages including independent suspension.

Except for periodic inspection of the fasteners used to attach the Torflex® axle to the vehicle frame, no other suspension maintenance is required on Torflex® axles. They are, of course, subject to the maintenance and inspection procedures regarding brakes, hubs, bearings, seals, wheels, and tires as outlined in this manual.

CAUTION

DO NOT WELD ON THE TORFLEX® BEAM. It has rubber cords inside and the heat generated by welding could damage the cords.

Airflex™ Suspension

The Dexter Airflex[™] suspension is a unique combination of Torflex[®] axle and conventional air suspension technology. This low maintenance suspension system carries the load on a cushion of air, usually supplied by an on-board compressor and storage tank. A load leveling valve maintains a constant ride height, regardless of load. As load is added to the trailer, the valve will automatically signal the compressor to supply more air. As loads are removed, the same valve will exhaust air to maintain the same height and ride characteristics.

The Airflex[™] suspension can be supplied with a dump valve which allows the trailer to be lowered several inches to facilitate loading or leveling. Once loaded, the valve is reversed and the system is pressurized to raise the trailer back up to normal running height.

Suspensions

Axle Adjustment


 Support the trailer frame on a level surface. If the wheels are already mounted, make sure they are clear of the ground. If the air actuation system has been installed, make sure the air pressure in the air bags is bled off before lifting the trailer. CAUTION: Lifting the trailer with air system pressurized will overextend the air bags and can result in damage to the air bags.

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.

- Measure from king pin to spindle center on each side. To simplify this process, plumb lines may be dropped from the king pin and from the centerline of each spindle end. Measurements "A" and "B" can then be taped on the floor to eliminate any miss measurement due to sagging of the tape long measurements. Compare A and B measurements (see Figure 1).
- 3. Loosen all the U-bolt nuts slightly and move the axle assembly with the adjusting screws, located on the front and rear of the axle seat. Move front axle to correct alignment position based on previous findings of A and B measurements. Make sure both front and rear adjusting screws are snug after axle is realigned. Then, retighten the U-bolt nuts to 100 to 120 lb ft.







Suspensions

Suspensions

Tandem Axle Adjustment

- 1. Adjust the second axle using it's left hand spring seat adjusters to assure distances "C" and "D" are within tolerance.
- Measure the distances "C" and "D" between the front and rear tandem axles. These distances must be within ¹/₈" of each other.
- 3. After alignment is completed make sure all nuts and bolts are tightened to their respective torque values.
- 4. The limits of ¹/₁₆" and ¹/₈" appear very small in comparison to the overall dimensions of the vehicle but they are recognized as the maximum permissible limit of misalignment. Also, the relatively small size of those limits makes accurate measurements important.





Wheels

Wheel Selection

Wheels are very important and critical components of your running gear system. When specifying or replacing your trailer wheels it is important that the wheels, tires, and axle are properly matched. The following characteristics are extremely important and should be thoroughly checked when replacement wheels are considered.

- 1. *Bolt Circle*. Many bolt circle dimensions are available. Some vary by so little that it might be possible to attach an improper wheel that does not match the axle hub. Be sure to match your wheel to the axle hub.
- 2. *Capacity*. Make sure that the wheels have enough load carrying capacity and pressure rating to match the rated load of the tire.
- 3. Offset. This refers to the relationship of the center line of the tire to the hub face of the axle. Care should be taken to match any replacement wheel with the same offset wheel as originally equipped. Failure to match offset can result in reducing the load carrying capacity of your axle.
- 4. Rim Contour.

Replacement tires must meet the same specifications as the originals. Mismatched tires and rims may come apart with explosive force and cause personal injury to yourself or others. Mismatched tires and rims can also blow out and cause you to lose control and have an accident which can result in serious injury or death.

Wheels and Tires

Do not attempt to repair or modify a damaged wheel. Even minor modifications can cause a dangerous failure of the wheel and result in personal injury or death.

Torque Requirements

In June of 2004, Dexter Axle ceased production of trailer wheels. If your vehicle is equipped with Dexter steel wheels manufactured before that date, the following wheel torque information will be applicable.

If your trailer is equipped with wheels produced by other manufacturers, you must consult with the vehicle manufacturer to determine the appropriate torque level for your wheels. However, you must not exceed the limits of the wheel mounting studs on the axles.

It is extremely important to apply and maintain proper wheel mounting torque on your trailer axle. Torque is a measure of the amount of tightening applied to a fastener (nut or bolt) and is expressed as length force. For example, a force of 90 pounds applied at the end of a wrench one foot long will yield 90 lbs.-ft. of torque. Torque wrenches are the best method to assure the proper amount of torque is being applied to a fastener.

Wheel nuts or bolts must be tightened and maintained at the proper torque levels to prevent loose wheels, broken studs, and possible dangerous separation of wheels from your axle, which can lead to an accident, personal injuries or death.





Be sure to use only the fasteners matched to the cone angle of your wheel (usually 60° or 90°). The proper procedure for attaching your wheels is as follows:

- 1. Start all bolts or nuts by hand to prevent cross threading.
- 2. Tighten bolts or nuts in the sequence shown for Wheel Torque Requirements.
- 3. The tightening of the fasteners should be done in stages. Following the recommended sequence, tighten fasteners per wheel torque chart below.
- 4. Wheel nuts/bolts should be torqued before first road use and after each wheel removal. Check and re-torque after the first 10 miles, 25 miles, and again at 50 miles. Check periodically thereafter.

Wheel Torque Requirements (For Dexter Steel Wheels Prior to June 2004)

Wheel	Torque Sequence				
Size	1st Stage	2nd Stage	3rd Stage		
12"	20-25	35-40	50-75		
13"	20-25	35-40	50-75		
14"	20-25	50-60	90-120		
15"	20-25	50-60	90-120		
16"	20-25	50-60	90-120		
16.5" x 6.75"	20-25	50-60	90-120		
16.5" x 9.75"	55-60	120-125	175-225		
14.5" Demount.	Tighten	sequentially to	85-95		
17.5" Hub Pilot Clamp Ring & C		100-120	190-210		
17.5" Hub Pilot ⁵ /8" Flange Nuts	50-60	90-200	275-325		
4 4 2 4 BC	1 3 4 2 0LT 5 BOI	$\int_{5}^{3} \int_{2}^{6} \int_{2}^{1} \int_{2}^{3} \delta$	$ \begin{array}{c} 1 \\ 6 \\ 7 \\ 4 \\ 2 \\ 8 BOLT \end{array} $		

Wheels and Tires

Maximum Wheel Fastener Torque

The wheel mounting studs used on Dexter axles conform to the SAE standards for grade 8. The maximum torque level that can be safely applied to these studs is listed in the following chart:

Max. Torque
120 lb ft.
170 lb ft.
325 lb ft.

Exceeding the above listed torque limits can damage studs and/or nuts and lead to eventual fractures and dangerous wheel separation.





Tires

Before mounting tires onto the wheels, make certain that the rim size and contour is approved for the tire as shown in the Tire and Rim Association Yearbook or the tire manufacturers catalog. Also, make sure the tire will carry the rated load. If the load is not equal on all tires due to trailer weight distribution, use the tire rated for the heaviest wheel position.

Note: The capacity rating molded into the sidewall of the tire is not always the proper rating for the tire if used in a trailer application. Use the following guidelines:

- 1. LT and ST tires. Use the capacity rating molded into the tire.
- 2. Passenger Car Tires. Use the capacity rating molded into the tire sidewall **divided by 1.10** for trailer use.

Use tire mounting procedures as outlined by the Rubber Manufacturer's Association or the tire manufacturers.

Tire inflation pressure is the most important factor in tire life. Inflation pressure should be as recommended by the manufacturer for the load. Pressure should be checked cold before operation. Do not bleed air from tires when they are hot. Check inflation pressure weekly during use to insure the maximum tire life and tread wear. The following tire wear diagnostic chart will help you pinpoint the causes and solutions of tire wear problems.

CAUTION

Tire wear should be checked frequently because once a wear pattern becomes firmly established in a tire it is difficult to stop, even if the underlying cause is corrected.

Tire Wear Diagnostic Chart

Wea	Wear Pattern Cause Action		
	Center Wear	Over Inflation	Adjust pressure to particular load per tire catalog
	Edge Wear	Under Inflation	Adjust pressure to particular load per tire catalog
	Side Wear	Loss of camber or overloading	Make sure load doesn't exceed axle rating. Align at alignment shop.
	Toe Wear	Incorrect toe-in	Align at alignment shop.
	Cupping	Out-of-balance	Check bearing adjust- ment and balance tires.
	Flat Spots	Wheel lockup & tire skidding	Avoid sudden stops when possible and adjust brakes.

Wheels and Tires





Replacement Parts/Kits

Magnet Replacement Kits

Brake Size	Magnet Kit No. (one magnet per kit)	Wire Color	Nut Torque Brake Mounting
7 x 1 ¹ / ₄	K71-057-00	White	45-70
10 x 2 ¹ / ₄	K71-104-00	Green	45-70
12 x 2	K71-105-00	White	25-50
12 x 2	K71-125-00 (7K)	Black	25-50
12 ¹ / ₄ x 2 ¹ / ₂	2 K71-441-00	Red	55-80
12 ¹ / ₄ x 3 ³ / ₅	K71-375-00 oval magnet	White	55-80

Brake Shoe Replacement Kits

Shoe and Lining Re	Shoe and Lining Replacement (1 Brake) Electric Hydraulic		
K71-045-00	N/A		
N/A	K71-466-00		
K71-047-00	K71-267-00		
	K71-393-00		
ant	K71-423 -00		
K71-048-00	K71-268-00		
K71-127-00	K71-269-00 LH K71-270-00 RH		
	К71-394-00 ьн К71-395-00 вн		
orrosion Resistant	К71-427-00 LH К71-428-00 RH		
К71-497-00ьн К71-496-0	00вн N/A		
К71-499-00 _{LH} К71-498-0	Опн К71-165-00 цн К71-166-00 кн		
К71-049-00∟н К71-050-(00 _{BH} Stamped Backing Plate		
(prior to A	pril 2000)		
N/A	K71-623-00 (1 axle set)		
N/A	K71-629-00 (1 axle set)		
N/A	K71-629-00 (1 axle set)		
	Electric K71-045-00 N/A K71-047-00 ant K71-048-00 K71-127-00 brrosion Resistant K71-497-00LH K71-049-00LH K71-049-00LH K71-050-0 K71-049-00LH K71-049-00LH K71-050-0 K71-049-00LH K71-049-00LH		

Replacement Parts/Kits

Replacement Parts/Kits

Bearing Replacement Chart

Brake Size	Hub Size	Bearings	Dexter Kit Number	Industry Part # Cup /Cone	Axle Capacity
7 x 1 ¹ / ₄	4 or 5 Bolt	Inner Outer	K71-306-00 K71-306-00	L44610 / L44649 L44610 / L44649	2K
10 x 1 ¹ / ₂	4 or 5 Bolt	Inner Outer	K71-307-00 K71-306-00	LM67010 / LM6704 L44610 / L44649	8 2.8K
10 x 2 ¹ / ₄	4 or 5 Bolt	Inner Outer	K71-390-00 K71-306-00	L68111 / L68149 L44610 / L44649	3.5K
12 x 2	6 Bolt	Inner Outer	K71-308-00 K71-307-00	25520 / 25580 LM67010 / LM6704	5.2K 8
12 x 2	5 Bolt Demount	Inner Outer	K71-308-00 K71-309-00	25520 / 25580 15245 / 15123	6K
12 x 2*	6 Bolt	Inner Outer	K71-308-00 K71-309-00	25520 / 25580 15245 / 15123	6K
12 x 2	8 Bolt	Inner Outer	K71-308-00 K71-310-00	25520 / 25580 14145A / 14276	7K
12 ¹ / ₄ x 2 ¹ / ₂	8 Bolt	Inner Outer	K71-308-00 K71-415-00	25520 / 25580 02420 / 02475	7.2K
12 ¹ / ₄ x 3 ³ / ₈	8 Bolt	Inner Outer	K71-308-00 K71-415-00	25520 / 25580 02420 / 02475	8K

* Special Application

Seal Replacement Reference

Brake	Hub		Seal Part No.	
Size	Size	Std.	E-Z Lube®	Oil
7 x 1 ¹ / ₄	4 or 5 Bolt	010-009-00	K71-301-00	NA
10 x 2 ¹ / ₄	4, 5 or 6 Bolt	010-004-00	K71-303-00	NA
12 x 2**	5 Bolt Demount;			
	6 or 8 Bolt	010-054-00	K71-305-00	K71-305-00
12 ¹ / ₄ x 2 ¹ / ₂	8 Bolt	K71-386-00	K71-386-00	K71-386-00
12 ¹ / ₄ x 3 ³ / ₈	8 Bolt	K71-386-00	K71-386-00	K71-386-00

** 2.12" diameter seal journal prior to 10/97

2.25" diameter seal journal after 10/97





Storage

Storage Preparation

If your trailer is to be stored for an extended period of time or over the winter, it is important that the trailer be prepared properly.

- Remove the emergency breakaway battery and store inside, out of the weather. Charge the battery at least every 90 days.
- 2. Jack up the trailer and place jack stands under the trailer frame so that the weight will be off the tires. Follow trailer manufacturer's guidelines to lift and support the unit. Never jack up or place jack stands on the axle tube or on the equalizers.

Do not lift or support the trailer on any part of the axle or suspension system. Never go under any trailer unless it is properly supported on jack stands which have been rated for the load. Improperly supported vehicles can fall unexpectedly and cause serious injury or death.

- 3. Lubricate mechanical moving parts such as the hitch, and suspension parts, that are exposed to the weather.
- 4. Boat trailer axles are subject to repeated immersion. Before storing, remove brake drums; clean, dry and re-lubricate moving brake components; inspect bearings clean and re-lubricate.
- 5. On oil lubricated hubs the upper part of the roller bearings are not immersed in oil and are subject to potential corrosion. For maximum bearing life, it is recommended that you revolve your wheels periodically (every 2-3 weeks) during periods of prolonged storage.

Storage

Storage

After Prolonged Storage -Inspection Procedures

Before removing trailer from jack stands:

- 1. Remove all wheels and hubs or brake drums. Note which spindle and brake that the drum was removed from so that it can be reinstalled in the same location.
- 2. Inspect suspension for wear.
- 3. Check tightness of hanger bolt, shackle bolt, and U-bolt nuts per recommended torque values.
- 4. Check brake linings, brake drums and armature faces for excessive wear or scoring.
- 5. Check brake magnets with an ohmmeter. The magnets should check 3.2 ohms. If shorted or worn excessively, they must be replaced.
- 6. Lubricate all brake moving parts using a high temperature brake lubricant (LUBRIPLATE or Equivalent).

CAUTION

Do not get grease or oil on brake linings or magnet face.

- 7. Remove any rust from braking surface and armature surface of drums with fine emery paper or crocus cloth. Protect bearings from contamination while so doing.
- 8. Inspect oil or grease seals for wear or nicks. Replace if necessary.
- 9. Lubricate hub bearings. Refer to procedure in manual.
- 10. Reinstall hubs and adjust bearings per instructions in manual.
- 11. Mount and tighten wheels per instructions in manual.





Trip Preparation Checklist

There are a number of simple rules to follow in caring for your trailer axle assembly that can add to its life and in the case of some of these rules, you may be protecting your own life as well. Using the following checklist before starting a trip with your trailer is highly recommended. Some of these items should be checked 2-3 weeks prior to a planned trip to allow sufficient time to perform maintenance.

- 1. Check your maintenance schedule and be sure you are up-to-date.
- 2. Check hitch. Is it showing wear? Is it properly lubricated?
- Fasten safety chains and breakaway switch actuating chain securely. Make certain the breakaway battery is fully charged.
- 4. Inspect towing hookup for secure attachment.
- 5. Load your trailer so that approximately 10% of the trailers total weight is on the hitch. For light trailers this should be increased to 15%.
- 6. *Do Not Overload.* Stay within your gross vehicle rated capacity (consult your trailers identification plate).
- 7. Inflate tires according to manufacturer's specifications; inspect tires for cuts, excessive wear, etc.
- Check wheel mounting nuts/bolts with a torque wrench. Torque, in proper sequence, to the levels specified in this manual.
- 9. Make certain brakes are synchronized and functioning properly.
- 10. Check tightness of hanger bolt, shackle bolt, and U-bolt nuts per torque values specified in manual.
- 11. Check operation of all lights.
- 12. Check that your trailer is towing in a level position and adjust hitch height if required.

Storage

Maintenance Schedule

Item	Function Required	Weekly	3 Months or 3000 Miles	6 Months or 6000 Miles	12 Months or 12000 Miles
Brakes	Test that they are operational.		At Every Use		
Brake Adjustment	Adjust to proper operating clearance.		•		
Brake Magnets	Inspect for wear and current draw.			•	
Brake Linings	Inspect for wear or contamination.				•
Brake Controller	Check for correct amperage & modulation.			•	
Brake Cylinders	Check for leaks, sticking.				•
Brake Lines	Inspect for cracks, leaks, kinks.				•
Trailer Brake Wiring	Inspect wiring for bare spots, fray, etc.				•
Breakaway System	Check battery charge and switch operation.		At Every Use		
Hub/Drum	Inspect for abnormal wear or scoring.				•
Wheel Bearings & Cups	Inspect for corrosion or wear. Clean & repack.				•
Seals	Inspect for leakage. Replace if removed.				•
Springs	Inspect for wear, loss of arch.				•
Suspension Parts	Inspect for bending, loose fasteners, wear.			•	
Hangers	Inspect Welds.				•
Wheel Nuts and Bolts	Tighten to specified torque values.		•		
Wheels	Inspect for cracks, dents or distortion.			•	
Tire Inflation Pressure	Inflate tires to mfg's. specifications.	•			
Tire Condition	Inspect for cuts, wear, bulging, etc.		•		





Dexter Axle Limited Warranty

WHAT PRODUCTS ARE COVERED

All Dexter trailer axles, suspensions, and brake control systems excluding Dexter 6000 series Manufactured Housing Axles.

LIMITED 2 YEAR WARRANTY

Dexter Axle warrants to the original purchaser that its axles, suspension systems, and E/H hydraulic brake actuators shall be free from defects in material and workmanship for a period of <u>two (2) years</u> from the date of first sale of the trailer incorporating such components.

LIMITED 5 YEAR WARRANTY

Dexter Axle warrants to the original purchaser that its Nev-R-Lube[™] bearings and the suspension components only of its Torflex® axles shall be free from defects in material and workmanship for a period of <u>five years</u> from the date of first sale of the trailer incorporating such components.

LIMITED 7 YEAR WARRANTY

Dexter Axle warrants to the original purchaser that its Predator SeriesTM electric brake controllers shall be free from defects in material and workmanship for a period of <u>seven (7) years</u> from the date of purchase.

EXCLUSIVE REMEDY

Dexter Axle will, at its option, repair or replace the affected components of any defective axle, repair or replace the entire defective axle, or refund the then-current list price of the axle. In all cases, a reasonable time period must be allowed for warranty repairs to be completed. Allowance will only be made for installation costs specifically approved by Dexter Axle.

WHAT YOU MUST DO

In order to make a claim under these warranties:

- 1. You must be the original purchaser of the vehicle in which the Spring Suspension Axles or Torflex® Axles were originally installed.
- You must promptly notify us within the warranty period of any defect and provide us with the axle serial number and any substantiation which may include, but is not limited to, the return of parts(s) that we may reasonably request.
- 3. The axles or suspensions must have been installed and maintained in accordance with good industry practice and any specific Dexter Axle recommendations, <u>including those specified</u> in Dexter Axle's publication "Operation Maintenance Service Manual."

Varranty

Warranty

EXCLUSIONS

These warranties do not extend to or do not cover defects caused by:

- 1. The connecting of brake wiring to the trailer wiring or trailer wiring to the towing vehicle wiring.
- 2. The attachment of the running gear to the frame.
- 3. Hub imbalance, or any damage caused thereby.
- 4. Parts not supplied by Dexter Axle.
- 5. Any damage whatever caused by or related to any alteration of the axle including welding supplemental brackets to the axle.
- 6. Use of an axle on a unit other than the unit to which it was originally mounted.
- 7. Normal wear and tear.
- 8. Alignment.
- 9. Improper installation.
- 10. Unreasonable use (including failure to provide reasonable and necessary maintenance <u>as specified in Dexter Axle's publication</u> <u>"Operation Maintenance Service Manual" including required</u> <u>maintenance after "Prolonged Storage").</u>
- 12. Improper wheel nut torque.
- 13. Cosmetic finish or corrosion.

LIMITATIONS

- 1. In all cases, Dexter Axle reserves the right to fully satisfy its obligations under the Limited Warranties by refunding the then-current list price of the defective axle (or, if the axle has been discontinued, of the most nearly comparable current product).
- 2. Dexter Axle reserves the right to furnish a substitute or replacement component or product in the event an axle or any component of the axle is discontinued or is otherwise unavailable.
- 3. These warranties are nontransferable.

<u>GENERAL</u>

THE FOREGOING WARRANTIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES EXCEPT THAT OF TITLE, WHETHER WRITTEN, ORAL OR IMPLIED, IN FACT OR IN LAW (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE).





These warranties give you specific legal rights, and you may also have other rights which vary from state to state.

THE DURATION OF ANY IMPLIED WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THE EXPRESS WARRANTIES HEREIN. DEXTER AXLE HEREBY EXCLUDES INCIDENTAL AND CONSEQUENTIAL DAMAGES, INCLUDING LOSS OF TIME, INCONVENIENCE, LOSS OF USE, TOWING FEES, TELEPHONE CALLS OR COST OF MEALS, FOR ANY BREACH OF ANY EXPRESS OR IMPLIED WARRANTY, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Some states do not allow limitations on how long an implied warranty lasts, or the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you.

Inquiries regarding these warranties should be sent to:

Dexter Axle P.O. Box 250 Elkhart, Indiana 46515

<u> Warranty</u>

Dexter Online Parts Store

From magnet and seal kits to complete brake and hub kits, Dexter offers a complete line of genuine replacement parts for your trailer. Most products are available in-stock and ready to ship within 24 hours direct to you from the factory. With dedicated customer support, quick turnaround and a 30-day money back guarantee, the Dexter Online Parts Store helps keep your trailer going.

- Hub Components
 - Brake Components
 - Suspension Components
 - Complete Hub Kits
 - Brake Assemblies & Kits
 - Brake Controllers & Actuators



Ready for Immediate Shipment Direct to Your Door

Visit us online at www.dexteraxle.com

Service Record

Date	Service Performed	Mileage


Service Record

Date	Service Performed	Mileage

Service Record			
Date	Service Performed	Mileage	

Genuine Dexter axles and components are available nationwide from our plant locations listed below or through our network of distributors. Check our website for the distributor nearest you.





NO PART OF THIS CATALOG MAY BE REPRODUCED WITHOUT DEXTER AXLE'S PERMISSION. ALL PART NUMBERS, DIMENSIONS AND SPECIFICATIONS IN THIS CATALOG ARE SUBJECT TO CHANGE WITHOUT NOTICE.



www.dexteraxle.com 2900 Industrial Parkway East • Elkhart, IN 46516 Fax: 574-295-8666 • Ph. 574-295-7888